
# **LUNA2000-2.0MWH Series Smart String ESS**

# **User Manual**

**Issue** 15

**Date** 2023-11-01





#### Copyright © Huawei Technologies Co., Ltd. 2023. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

#### **Trademarks and Permissions**

HUAWEI and other Huawei trademarks are trademarks of Huawei Technologies Co., Ltd. All other trademarks and trade names mentioned in this document are the property of their respective holders.

#### **Notice**

The purchased products, services and features are stipulated by the contract made between Huawei and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

# Huawei Technologies Co., Ltd.

Address: Huawei Industrial Base

Bantian, Longgang Shenzhen 518129

People's Republic of China

Website: <a href="https://e.huawei.com">https://e.huawei.com</a>

# **About This Document**

# **Purpose**

This document describes the installation, electrical connections, commissioning and troubleshooting of LUNA2000-2.0MWH-1H0, LUNA2000-2.0MWH-2H0, LUNA2000-2.0MWH-1H1, LUNA2000-2.0MWH-2H1 and LUNA2000-2.0MWH-HE2H1 Smart String Energy Storage Systems (also referred to as ESS). Before installing and operating the ESS, ensure that you are familiar with the features, functions, and safety precautions provided in this document.

# **Intended Audience**

This document is intended for plant operating personnel and qualified electricians.

# **Symbol Conventions**

The symbols that may be found in this document are defined as follows.

| Symbol           | Description   |
|------------------|---|
| ▲ DANGER         | Indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.   |
| ⚠ WARNING        | Indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.  |
| <b>⚠</b> CAUTION | Indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.  |
| NOTICE           | Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance deterioration, or unanticipated results.  NOTICE is used to address practices not related to personal injury. |
| ☐ NOTE           | Supplements the important information in the main text.  NOTE is used to address information not related to personal injury, equipment damage, and environment deterioration.   |

# **Change History**

Changes between document issues are cumulative. The latest document issue contains all updates made in previous issues.

#### Issue 15 (2023-11-01)

Updated 2.1 Model Description.

Updated 2.6.4.4 Extinguishant Control Panel.

Updated 2.6.4.12 (Optional) Water Sprinkler System.

Updated 2.7.1 Battery circuit diagram.

Updated 2.8 Typical Application Scenarios.

Updated 3.2 Storage Requirements.

Updated 3.3 Charging Requirements for a Single Battery.

Updated 5.4.1 Installing Copper Bars Between Battery Packs.

Updated 5.4.3 Installing the Battery in the Extinguishant Control Panel.

Updated 9 Deployment and Commissioning (SmartLogger WebUI).

Updated 10.5 Powering Off the ESS.

Updated 14 Technical Specifications.

Add E Certificate Management and Maintenance.

Updated F Contact Information.

#### Issue 14 (2023-07-30)

Updated 2.4 Appearance.

#### Issue 13 (2023-06-30)

Updated **2.4 Appearance**.

Updated 2.6.4.5 Fire Cylinder.

Updated 2.8 Typical Application Scenarios.

#### Issue 12 (2023-06-15)

Updated 2.6.4.9 Smoke Detector.

Updated 4.1 Site Selection Requirements.

#### Issue 11 (2023-04-28)

Updated 1.3 Environment Requirements.

Updated 5.2 Unpacking and Acceptance.

Updated 12 Emergency Handling.

#### Issue 10 (2023-03-30)

Updated 1 Safety Information.

Updated 4.1 Site Selection Requirements.

Updated 4.3 Foundation Requirements.

#### Issue 09 (2023-02-20)

Updated 1 Safety Information.

Updated 3 Transportation and Storage.

Updated 4.1 Site Selection Requirements.

Updated 4.2 Clearance Requirements.

Updated 5.2 Unpacking and Acceptance.

Updated 5.3.2 Hoisting the ESS.

Updated 5.3.5 Securing the ESS.

Updated 5.4.2 (Optional) Filling the Fire Cylinder with Extinguishant.

Updated 5.4.3 Installing the Battery in the Extinguishant Control Panel.

Updated 6.5 (Optional) Connecting Single-phase AC Input Power Cables.

Updated 8.2 Installing the Solenoid Valve.

Updated 12 Emergency Handling.

#### Issue 08 (2022-11-15)

Updated **2.4 Appearance**.

Updated 2.5.1 Battery Cabin.

Updated 2.5.2 Control Unit Cabin.

Updated 2.7.1 Battery circuit diagram.

Updated 2.8 Typical Application Scenarios.

Updated **6.1 Preparing Cables**.

Updated 6.2 Connecting Socket Circuit Wires.

Updated 6.5 (Optional) Connecting Single-phase AC Input Power Cables.

Updated 8.1 Installing the PSU.

Updated 8.2 Installing the Solenoid Valve.

Updated 8.3 Power-on Process.

Updated 8.7 Powering On the ESS.

Updated 9 Deployment and Commissioning (SmartLogger WebUI).

Updated A.2.1 Preparations and WebUI Login.

Updated 10.5 Powering Off the ESS.

Updated 13.7 How Do I Perform a Dielectric Voltage Withstand Test on the AC Side of an ESS?.

Updated 14 Technical Specifications.

#### Issue 07 (2022-06-30)

Updated 4.3 Foundation Requirements, and updated the diagram of foundation.

Updated 11 Alarm Reference.

Updated 14 Technical Specifications, and added LUNA2000-2.0MWH-1H1.

#### Issue 06 (2022-06-08)

Updated 5 Installation.

Updated 8.2 Installing the Solenoid Valve.

Updated 9 Deployment and Commissioning (SmartLogger WebUI).

#### Issue 05 (2022-04-30)

Updated 5.4.1 Installing Copper Bars Between Battery Packs.

Updated 5.4.2 (Optional) Filling the Fire Cylinder with Extinguishant.

Updated 13.2 How to Ensure that the Solenoid Valve Is Not Activated.

#### Issue 04 (2022-03-30)

Updated About This Document.

Updated 1-Safety Information.

Updated 2 Overview.

Updated 2.6.4.6-Input/Output modules.

Updated 2.7.2 Working Modes.

Updated 3-Site Requirements.

Updated 5.3.4 Grounding the ESS.

Updated 5.3.5 Securing the ESS.

Updated 4.3.2-(Optional) Filling the Fire Cylinder with Extinguishant.

Updated 6.2 Connecting Socket Circuit Wires.

Updated 6.6 Installing Signal Cables.

Updated 8.1 Installing the PSU.

Updated 8.2 Installing the Solenoid Valve.

Updated 9 Deployment and Commissioning (SmartLogger WebUI).

Updated 10 Powering Off the System.

Updated 11 Alarm Reference.

Updated 13.6 What Should I Do If the ESU Cable Connection Detection Abnormal Alarm Is Generated on the WebUI?.

Updated 12-Technical Data.

#### Issue 03 (2022-01-04)

Updated 1 Safety Information.

Updated 4 Site Requirements.

#### Issue 02 (2021-11-15)

Updated 1.3-Electrical Safety.

Updated 1.4-Storage and Installation Environment Requirements.

Updated 1.5-Transportation requirements.

Updated 1.5.2 Battery Safety.

Updated **2-Overview**.

Updated 3.2-Space Requirements.

Updated 3.3-Foundation Requirements.

Updated 4.2-Installing the ESS.

Updated 4.3-Installing Components.

Updated 5-Installing Cables.

Updated 7.4-Powering On the Distribution Transformer.

Updated 7.5-Powering On the ESS.

Updated 8-SmartLogger Web-based Deployment.

Updated 9.5-Powering Off the ESS.

Updated 9.6-Powering Off the Distribution Transformer.

Updated 10-Alarm Reference.

Updated 11-FAQ.

#### Issue 01 (2021-08-30)

This issue is used for first office application (FOA).

# **Contents**

| About This Document                               | ii |
|---|----|
| 1 Safety Information                              | 1  |
| 1.1 Personal Safety                               | 2  |
| 1.2 Electrical Safety                             | 4  |
| 1.3 Environment Requirements                      | 8  |
| 1.4 Mechanical Safety                             | 10 |
| 1.5 Equipment Safety                              | 15 |
| 1.5.1 ESS Safety                                  | 15 |
| 1.5.2 Battery Safety                              | 16 |
| 2 Overview  | 23 |
| 2.1 Model Description                             | 23 |
| 2.2 Label Description                             | 24 |
| 2.3 Functions and Features                        | 25 |
| 2.4 Appearance                                    | 26 |
| 2.5 ESS Composition                               | 34 |
| 2.5.1 Battery Cabin                               | 34 |
| 2.5.2 Control Unit Cabin                          | 39 |
| 2.5.3 Smart Rack Controller Cabin                 | 45 |
| 2.6 Components                                    | 46 |
| 2.6.1 Power Supply and Distribution System        | 46 |
| 2.6.1.1 Battery Pack                              | 47 |
| 2.6.1.2 Smart Rack Controller                     | 48 |
| 2.6.1.3 Embedded Power Subrack                    | 49 |
| 2.6.1.4 Rectifier Module PSU                      | 50 |
| 2.6.1.5 SMU                                       | 52 |
| 2.6.2 Monitoring System                           | 55 |
| 2.6.2.1 CMU                                       | 56 |
| 2.6.2.2 SmartModule                               | 58 |
| 2.6.2.3 Input/Output Board (IO Board)             | 59 |
| 2.6.3 Environmental Control System                | 60 |
| 2.6.3.1 T/H Sensor                                |    |
| 2.6.3.2 Air Conditioner in the Control Unit Cabin | 62 |

| 2.6.3.3 Air Conditioner in the Battery Cabin           | 63  |
|--|-----|
| 2.6.3.4 Electrode Water Sensor                         | 64  |
| 2.6.3.5 Door Status Sensor                             | 65  |
| 2.6.3.6 Light  | 66  |
| 2.6.4 Fire Suppression System                          | 66  |
| 2.6.4.1 CO Sensor                                      | 67  |
| 2.6.4.2 Air Exhaust Module                             | 68  |
| 2.6.4.3 Air Exhaust Controller                         | 68  |
| 2.6.4.4 Extinguishant Control Panel                    | 69  |
| 2.6.4.5 Fire Cylinder                                  | 72  |
| 2.6.4.6 Input/Output Modules                           | 74  |
| 2.6.4.7 Fire Signal Transfer Board                     | 76  |
| 2.6.4.8 Heat Detector                                  | 77  |
| 2.6.4.9 Smoke Detector                                 | 79  |
| 2.6.4.10 Fire Alarm Horn/Strobe                        | 81  |
| 2.6.4.11 Extinguishant Release Indicator               | 83  |
| 2.6.4.12 (Optional) Water Sprinkler System             | 85  |
| 2.7 Working Principles                                 | 87  |
| 2.7.1 Battery circuit diagram                          | 87  |
| 2.7.2 Working Modes                                    | 94  |
| 2.8 Typical Application Scenarios                      | 95  |
| 3 Transportation and Storage                           | 96  |
| 3.1 Transportation Requirements                        |     |
| 3.2 Storage Requirements                               | 99  |
| 3.3 Charging Requirements for a Single Battery         | 103 |
| 4 Site Requirements                                    |     |
| 4.1 Site Selection Requirements                        |     |
| 4.2 Clearance Requirements                             |     |
| 4.3 Foundation Requirements                            |     |
| ·  |     |
| 5 Installation   |     |
| 5.1 Installation Preparations                          |     |
| 5.1.1 Preparing Tools                                  |     |
| 5.1.2 Installation Environment Check                   |     |
| 5.2 Unpacking and Acceptance                           |     |
| 5.3 Installing the ESS                                 |     |
| 5.3.1 Determining the Installation Position of the ESS |     |
| 5.3.2 Hoisting the ESS                                 |     |
| 5.3.3 Opening the Doors of the ESS                     |     |
| 5.3.4 Grounding the ESS                                |     |
| 5.3.5 Securing the ESS                                 |     |
| 5.4 Installing Components                              | 125 |

| 5.4.1 Installing Copper Bars Between Battery Packs                         | 125 |
|--|-----|
| 5.4.2 (Optional) Filling the Fire Cylinder with Extinguishant              |     |
| 5.4.3 Installing the Battery in the Extinguishant Control Panel            | 133 |
| 6 Installing Cables  | 137 |
| 6.1 Preparing Cables   |     |
| 6.2 Connecting Socket Circuit Wires  | 140 |
| 6.3 Installing DC Power Cables   | 147 |
| 6.4 Installing AC Input Power Cables (With External Grid Power Supply)     | 152 |
| 6.5 (Optional) Connecting Single-phase AC Input Power Cables               | 157 |
| 6.6 Installing Signal Cables   | 159 |
| 6.6.1 Installing FE Communications Cables                                  | 159 |
| 6.6.2 Installing Optical Cables  | 162 |
| 6.7 Sealing the Cable Holes  | 166 |
| 7 Checking Before Power-On   | 167 |
| 8 Powering On the System   | 169 |
| 8.1 Installing the PSU   | 169 |
| 8.2 Installing the Solenoid Valve  | 171 |
| 8.3 Power-on Process   | 174 |
| 8.4 Powering On the Smart Transformer Station (STS)                        | 177 |
| 8.5 Powering On the Smart Array Controller (SACU)                          | 177 |
| 8.6 Powering On the Distribution Transformer                               | 177 |
| 8.7 Powering On the ESS  | 178 |
| 8.8 (Optional) Powering On the Battery Side of the DC LV Panel             | 184 |
| 8.9 Powering On the Smart PCS  | 185 |
| 9 Deployment and Commissioning (SmartLogger WebUI)                         | 187 |
| 10 Powering Off the System   | 188 |
| 10.1 Delivering a Shutdown Command on the SmartLogger                      | 188 |
| 10.2 Power-off Process   | 189 |
| 10.3 Powering Off the Smart PCS  |     |
| 10.4 (Optional) Powering Off the Battery Side of the DC LV Panel           | 191 |
| 10.5 Powering Off the ESS  | 191 |
| 10.6 Powering Off the Distribution Transformer                             | 193 |
| 11 Alarm Reference   | 194 |
| 12 Emergency Handling  | 195 |
| 13 FAQ   | 197 |
| 13.1 (Optional) How to Level the ESS When Doors Cannot Be Opened or Closed |     |
| 13.2 How to Ensure that the Solenoid Valve Is Not Activated                | 198 |
| 13.3 How to Connect the ESS to the Smart PV Management System              | 199 |
| 13.4 How to Create a Plant   | 199 |

| 13.5 Why Does the PSU Not Start After the Water and Fire Alarms Are Cleared             | 200 |
|---|-----|
| 13.6 What Should I Do If the ESU Cable Connection Detection Abnormal Alarm Is Generated |     |
| WebUI?  |     |
| 13.7 How Do I Perform a Dielectric Voltage Withstand Test on the AC Side of an ESS?     |     |
| 14 Technical Specifications   | 204 |
| A Operations on the CMU WebUI   | 208 |
| A.1 CMU WebUI Operations  |     |
| A.1.1 WebUI Layout  | 208 |
| A.1.2 Icon Description  | 209 |
| A.1.3 WebUI Menus   | 210 |
| A.2 Maintenance Operations  | 211 |
| A.2.1 Preparations and WebUI Login  | 211 |
| A.2.2 Upgrading the Software Version  | 216 |
| A.2.3 Exporting Device Logs   | 216 |
| A.2.4 Checking Alarms   | 217 |
| A.2.5 Clearing Alarms   | 217 |
| B APP Commissioning   | 218 |
| B.1 Downloading and Installing the App  | 218 |
| B.2 Logging In to the App   | 218 |
| B.3 Change Password   | 220 |
| C Crimping an OT or DT Terminal   | 222 |
| D How Do I Repair Paint Damage?   | 225 |
| E Certificate Management and Maintenance  | 230 |
| F Contact Information   | 232 |
| G Acronyms and Abbreviations  | 234 |

# **1** Safety Information

#### Statement

Before transporting, storing, installing, operating, using, and/or maintaining the equipment, read this document, strictly follow the instructions provided herein, and follow all the safety instructions on the equipment and in this document. In this document, "equipment" refers to the products, software, components, spare parts, and/or services related to this document; "the Company" refers to the manufacturer (producer), seller, and/or service provider of the equipment; "you" refers to the entity that transports, stores, installs, operates, uses, and/or maintains the equipment.

The Danger, Warning, Caution, and Notice statements described in this document do not cover all the safety precautions. You also need to comply with relevant international, national, or regional standards and industry practices. The Company shall not be liable for any consequences that may arise due to violations of safety requirements or safety standards concerning the design, production, and usage of the equipment.

The equipment shall be used in an environment that meets the design specifications. Otherwise, the equipment may be faulty, malfunctioning, or damaged, which is not covered under the warranty. The Company shall not be liable for any property loss, personal injury, or even death caused thereby.

Comply with applicable laws, regulations, standards, and specifications during transportation, storage, installation, operation, use, and maintenance.

Do not perform reverse engineering, decompilation, disassembly, adaptation, implantation, or other derivative operations on the equipment software. Do not study the internal implementation logic of the equipment, obtain the source code of the equipment software, violate intellectual property rights, or disclose any of the performance test results of the equipment software.

# The Company shall not be liable for any of the following circumstances or their consequences:

- The equipment is damaged due to force majeure such as earthquakes, floods, volcanic eruptions, debris flows, lightning strikes, fires, wars, armed conflicts, typhoons, hurricanes, tornadoes, and other extreme weather conditions.
- The equipment is operated beyond the conditions specified in this document.

- The equipment is installed or used in environments that do not comply with international, national, or regional standards.
- The equipment is installed or used by unqualified personnel.
- You fail to follow the operation instructions and safety precautions on the product and in the document.
- You remove or modify the product or modify the software code without authorization.
- You or a third party authorized by you cause the equipment damage during transportation.
- The equipment is damaged due to storage conditions that do not meet the requirements specified in the product document.
- You fail to prepare materials and tools that comply with local laws, regulations, and related standards.
- The equipment is damaged due to your or a third party's negligence, intentional breach, gross negligence, or improper operations, or other reasons not related to the Company.

# 1.1 Personal Safety

#### **⚠** DANGER

Ensure that power is off during installation. Do not install or remove a cable with power on. Transient contact between the core of the cable and the conductor will cause electric arcs, sparks, fire, or explosion, which may result in personal injury.

#### **⚠** DANGER

Non-standard and improper operations on the energized equipment may cause fire, electric shocks, or explosion, resulting in property damage, personal injury, or even death.

#### **⚠** DANGER

Before operations, remove conductive objects such as watches, bracelets, bangles, rings, and necklaces to prevent electric shocks.


#### **DANGER**

During operations, use dedicated insulated tools to prevent electric shocks or short circuits. The dielectric withstanding voltage level must comply with local laws, regulations, standards, and specifications.

#### **MARNING**

During operations, wear personal protective equipment such as protective clothing, insulated shoes, goggles, safety helmets, and insulated gloves.

Figure 1-1 Personal protective equipment



#### **General Requirements**

- Do not stop protective devices. Pay attention to the warnings, cautions, and related precautionary measures in this document and on the equipment.
- If there is a likelihood of personal injury or equipment damage during operations, immediately stop, report the case to the supervisor, and take feasible protective measures.
- Do not power on the equipment before it is installed or confirmed by professionals.
- Do not touch the power supply equipment directly or with conductors such as damp objects. Before touching any conductor surface or terminal, measure the voltage at the contact point to ensure that there is no risk of electric shock.
- Do not touch operating equipment because the enclosure is hot.
- Do not touch a running fan with your hands, components, screws, tools, or boards. Otherwise, personal injury or equipment damage may occur.
- In the case of a fire, immediately leave the building or the equipment area and activate the fire alarm or call emergency services. Do not enter the affected building or equipment area under any circumstances.

#### **Personnel Requirements**

- Only professionals and trained personnel are allowed to operate the equipment.
  - Professionals: personnel who are familiar with the working principles and structure of the equipment, trained or experienced in equipment operations and are clear of the sources and degree of various potential hazards in equipment installation, operation, maintenance

- Trained personnel: personnel who are trained in technology and safety, have required experience, are aware of possible hazards on themselves in certain operations, and are able to take protective measures to minimize the hazards on themselves and other people
- Personnel who plan to install or maintain the equipment must receive adequate training, be able to correctly perform all operations, and understand all necessary safety precautions and local relevant standards.
- Only qualified professionals or trained personnel are allowed to install, operate, and maintain the equipment.
- Only qualified professionals are allowed to remove safety facilities and inspect the equipment.
- Personnel who will perform special tasks such as electrical operations, working at heights, and operations of special equipment must possess the required local qualifications.
- Only authorized professionals are allowed to replace the equipment or components (including software).
- Only personnel who need to work on the equipment are allowed to access the equipment.

# 1.2 Electrical Safety

#### **DANGER**

Before connecting cables, ensure that the equipment is intact. Otherwise, electric shocks or fire may occur.

#### **A** DANGER

Non-standard and improper operations may result in fire or electric shocks.

#### **DANGER**

Prevent foreign matter from entering the equipment during operations. Otherwise, equipment damage, load power derating, power failure, or personal injury may occur.

#### **↑** WARNING


For the equipment that needs to be grounded, install the ground cable first when installing the equipment and remove the ground cable last when removing the equipment.



Do not route cables near the air intake or exhaust vents of the equipment.

#### **General Requirements**

- Follow the procedures described in the document for installation, operation, and maintenance. Do not reconstruct or alter the equipment, add components, or change the installation sequence without permission.
- Obtain approval from the national or local electric utility company before connecting the equipment to the grid.
- Observe the power plant safety regulations, such as the operation and work ticket mechanisms.
- Install temporary fences or warning ropes and hang "No Entry" signs around the operation area to keep unauthorized personnel away from the area.
- Before installing or removing power cables, turn off the switches of the equipment and its upstream and downstream switches.
- If any liquid is detected inside the equipment, disconnect the power supply immediately and do not use the equipment.
- Before performing operations on the equipment, check that all tools meet the requirements and record the tools. After the operations are complete, collect all of the tools to prevent them from being left inside the equipment.
- Before installing power cables, check that cable labels are correct and cable terminals are insulated.
- When installing the equipment, use a torque tool of a proper measurement range to tighten the screws. When using a wrench to tighten the screws, ensure that the wrench does not tilt and the torque error does not exceed 10% of the specified value.
- Ensure that bolts are tightened with a torque tool and marked in red and blue after double-check. Installation personnel mark tightened bolts in blue.
   Quality inspection personnel confirm that the bolts are tightened and then mark them in red. (The marks must cross the edges of the bolts.)



- After the installation is complete, ensure that protective cases, insulation tubes, and other necessary items for all electrical components are in position to avoid electric shocks.
- If the equipment has multiple inputs, disconnect all the inputs before operating the equipment.
- Before maintaining a downstream electrical or power distribution device, turn off the output switch on the power supply equipment.
- During equipment maintenance, attach "Do not switch on" labels near the upstream and downstream switches or circuit breakers as well as warning signs to prevent accidental connection. The equipment can be powered on only after troubleshooting is complete.

- If fault diagnosis and troubleshooting need to be performed after power-off, take the following safety measures: Disconnect the power supply. Check whether the equipment is live. Install a ground cable. Hang warning signs and set up fences.
- Check equipment connections periodically, ensuring that all screws are securely tightened.
- Only qualified professionals can replace a damaged cable.
- Do not scrawl, damage, or block any labels or nameplates on the equipment. Promptly replace labels that have worn out.
- Do not use solvents such as water, alcohol, or oil to clean electrical components inside or outside of the equipment.

#### Grounding

- Ensure that the grounding impedance of the equipment complies with local electrical standards.
- Ensure that the equipment is connected permanently to the protective ground. Before operating the equipment, check its electrical connection to ensure that it is reliably grounded.
- Do not work on the equipment in the absence of a properly installed ground conductor.
- Do not damage the ground conductor.
- For the equipment that uses a three-pin socket, ensure that the ground terminal in the socket is connected to the protective ground point.
- If high touch current may occur on the equipment, ground the protective ground terminal on the equipment enclosure before connecting the power supply; otherwise, electric shock as a result of touch current may occur.

## **Cabling Requirements**

- When selecting, installing, and routing cables, follow local safety regulations and rules.
- When routing power cables, ensure that there is no coiling or twisting. Do not join or weld power cables. If necessary, use a longer cable.
- Ensure that all cables are properly connected and insulated, and meet specifications.
- Ensure that the slots and holes for routing cables are free from sharp edges, and that the positions where cables are routed through pipes or cable holes are equipped with cushion materials to prevent the cables from being damaged by sharp edges or burrs.
- If a cable is routed into the cabinet from the top, bend the cable in a U shape outside the cabinet and then route it into the cabinet.
- Ensure that cables of the same type are bound together neatly and straight and that the cable sheath is intact. When routing cables of different types, ensure that they are at least 30 mm away from each other.
- When cable connection is completed or paused for a short period of time, seal the cable holes with sealing putty immediately to prevent small animals or moisture from entering.

- Secure buried cables using cable supports and cable clips. Ensure that the cables in the backfill area are in close contact with the ground to prevent cable deformation or damage during backfilling.
- If the external conditions (such as the cable layout or ambient temperature) change, verify the cable usage in accordance with the IEC-60364-5-52 or local laws and regulations. For example, check that the current-carrying capacity meets requirements.
- When routing cables, reserve at least 30 mm clearance between the cables and heat-generating components or areas. This prevents deterioration or damage to the cable insulation layer.
- When the temperature is low, violent impact or vibration may damage the plastic cable sheathing. To ensure safety, comply with the following requirements:
  - Cables can be laid or installed only when the temperature is higher than 0°C. Handle cables with caution, especially at a low temperature.
  - Cables stored at subzero temperatures must be stored at room temperature for at least 24 hours before they are laid out.
- Do not perform any improper operations, for example, dropping cables directly from a vehicle. Otherwise, the cable performance may deteriorate due to cable damage, which affects the current-carrying capacity and temperature rise.

#### **ESD**

#### **NOTICE**

The static electricity generated by human bodies may damage the electrostaticsensitive components on boards, for example, the large-scale integrated (LSI) circuits.

 When touching the equipment and handling boards, modules with exposed circuit boards, or application-specific integrated circuits (ASICs), observe ESD protection regulations and wear ESD clothing and ESD gloves or a wellgrounded ESD wrist strap.

Figure 1-2 Wearing an ESD wrist strap

DC15000001

- When holding a board or a module with exposed circuit boards, hold its edge without touching any components. Do not touch the components with bare hands.
- Package boards or modules with ESD packaging materials before storing or transporting them.

# 1.3 Environment Requirements

#### **A** DANGER

Do not expose the equipment to flammable or explosive gas or smoke. Do not perform any operation on the equipment in such environments.

#### **A** DANGER

Do not store any flammable or explosive materials in the equipment area.

#### **DANGER**

Do not place the equipment near heat sources or fire sources, such as smoke, candles, heaters, or other heating devices. Overheat may damage the equipment or cause a fire.

#### **№ WARNING**

Install the equipment in an area far away from liquids. Do not install it under areas prone to condensation, such as under water pipes and air exhaust vents, or areas prone to water leakage, such as air conditioner vents, ventilation vents, or feeder windows of the equipment room. Ensure that no liquid enters the equipment to prevent faults or short circuits.

#### **WARNING**


To prevent damage or fire due to high temperature, ensure that the ventilation vents or heat dissipation systems are not obstructed or covered by other objects while the equipment is running.

#### **General Requirements**

- Ensure that the equipment is stored in a clean, dry, and well ventilated area with proper temperature and humidity and is protected from dust and condensation.
- Keep the installation and operating environments of the equipment within the allowed ranges. Otherwise, its performance and safety will be compromised.
- Do not install, use, or operate outdoor equipment and cables (including but not limited to moving equipment, operating equipment and cables, inserting connectors to or removing connectors from signal ports connected to outdoor facilities, working at heights, performing outdoor installation, and opening doors) in harsh weather conditions such as lightning, rain, snow, sandstorm, and level 6 or stronger wind.
- Do not install the equipment in an environment with dust, smoke, volatile or corrosive gases, infrared and other radiations, organic solvents, or salty air.
- Do not install the equipment in an environment with conductive metal or magnetic dust.
- Do not install the equipment in an area conducive to the growth of microorganisms such as fungus or mildew.
- Do not install the equipment in an area with strong vibration, noise, or electromagnetic interference.
- Ensure that the site complies with local laws, regulations, and related standards.
- Ensure that the ground in the installation environment is solid, free from spongy or soft soil, and not prone to subsidence. The site must not be located in a low-lying land prone to water or snow accumulation, and the horizontal level of the site must be above the highest water level of that area in history.
- Do not install the equipment in a position that may be submerged in water.
- If the equipment is installed in a place with abundant vegetation, in addition to routine weeding, harden the ground underneath the equipment using cement or gravel.
- Before opening doors during the installation, operation, and maintenance of the equipment, clean up any water, ice, snow, or other foreign objects on the

top of the equipment to prevent foreign objects from falling into the equipment.

- When installing the equipment, ensure that the installation surface is solid enough to bear the weight of the equipment.
- All cable holes must be sealed. Seal the used cable holes with sealing putty.
   Seal the unused cable holes with the caps delivered with the equipment. The following figure shows the criteria for correct sealing with sealing putty.



After installing the equipment, remove the packing materials such as cartons, foam, plastics, and cable ties from the equipment area.

# 1.4 Mechanical Safety

#### **DANGER**

When working at heights, wear a safety helmet and safety harness or waist belt and fasten it to a solid structure. Do not mount it on an insecure moveable object or metal object with sharp edges. Make sure that the hooks will not slide off.

#### **WARNING**

Ensure that all necessary tools are ready and inspected by a professional organization. Do not use tools that have signs of scratches or fail to pass the inspection or whose inspection validity period has expired. Ensure that the tools are secure and not overloaded.

# **⚠** WARNING

Before installing equipment in a cabinet, ensure that the cabinet is securely fastened with a balanced center of gravity. Otherwise, tipping or falling cabinets may cause bodily injury and equipment damage.

#### **MARNING**

When pulling equipment out of a cabinet, be aware of unstable or heavy objects in the cabinet to prevent injury.

#### **MARNING**

Do not drill holes into the equipment. Doing so may affect the sealing performance and electromagnetic containment of the equipment and damage components or cables inside. Metal shavings from drilling may short-circuit boards inside the equipment.

#### **General Requirements**

- Repaint any paint scratches caused during equipment transportation or installation in a timely manner. Equipment with scratches must not be exposed for an extended period of time.
- Do not perform operations such as arc welding and cutting on the equipment without evaluation by the Company.
- Do not install other devices on the top of the equipment without evaluation by the Company.
- When performing operations over the top of the equipment, take measures to protect the equipment against damage.
- Use correct tools and operate them in the correct way.

## **Moving Heavy Objects**

• Be cautious to prevent injury when moving heavy objects.



< 18 kg (< 40 lbs)



18-32 kg (40-70 lbs)



32-55 kg (70-121 lbs)




55-68 kg (121-150 lbs)



> 68 kg (> 150 lbs)

- If multiple persons need to move a heavy object together, determine the manpower and work division with consideration of height and other conditions to ensure that the weight is equally distributed.
- If two persons or more move a heavy object together, ensure that the object is lifted and landed simultaneously and moved at a uniform pace under the supervision of one person.
- Wear personal protective gears such as protective gloves and shoes when manually moving the equipment.
- To move an object by hand, approach to the object, squat down, and then lift the object gently and stably by the force of the legs instead of your back. Do not lift it suddenly or turn your body around.
- Move or lift the equipment by holding its handles or lower edges. Do not hold the handles of modules that are installed in the equipment.

- Do not quickly lift a heavy object above your waist. Place the object on a workbench that is half-waist high or any other appropriate place, adjust the positions of your palms, and then lift it.
- Move a heavy object stably with balanced force at an even and low speed. Put
  down the object stably and slowly to prevent any collision or drop from
  scratching the surface of the equipment or damaging the components and
  cables.
- When moving a heavy object, be aware of the workbench, slope, staircase, and slippery places. When moving a heavy object through a door, ensure that the door is wide enough to move the object and avoid bumping or injury.
- When transferring a heavy object, move your feet instead of turning your waist around. When lifting and transferring a heavy object, ensure that your feet point to the target direction of movement.
- When transporting the equipment using a pallet truck or forklift, ensure that
  the tynes are properly positioned so that the equipment does not topple.
  Before moving the equipment, secure it to the pallet truck or forklift using
  ropes. When moving the equipment, assign dedicated personnel to take care
  of it.
- Choose sea or roads in good conditions for transportation. Do not transport the equipment by railway or air. Avoid tilt or jolt during transportation.
- The tilt angle of the ESS shall meet the requirements shown in the figure:  $\alpha \le 5^{\circ}$ .



## **Working at Heights**

- Any operations performed 2 m or higher above the ground shall be supervised properly.
- Only trained and qualified personnel are allowed to work at heights.
- Do not work at heights when steel pipes are wet or other risky situations exist. After the preceding conditions no longer exist, the safety owner and relevant technical personnel need to check the involved equipment. Operators can begin working only after safety is confirmed.
- Set a restricted area and prominent signs for working at heights to warn away irrelevant personnel.
- Set guard rails and warning signs at the edges and openings of the area involving working at heights to prevent falls.

- Do not pile up scaffolding, springboards, or other objects on the ground under the area involving working at heights. Do not allow people to stay or pass under the area involving working at heights.
- Carry operation machines and tools properly to prevent equipment damage or personal injury caused by falling objects.
- Personnel involving working at heights are not allowed to throw objects from the height to the ground, or vice versa. Objects shall be transported by slings, hanging baskets, highline trolleys, or cranes.
- Do not perform operations on the upper and lower layers at the same time. If unavoidable, install a dedicated protective shelter between the upper and lower layers or take other protective measures. Do not pile up tools or materials on the upper layer.
- Dismantle the scaffolding from top down after finishing the job. Do not dismantle the upper and lower layers at the same time. When removing a part, ensure that other parts will not collapse.
- Ensure that personnel working at heights strictly comply with the safety regulations. The Company is not responsible for any accident caused by violation of the safety regulations on working at heights.
- Behave cautiously when working at heights. Do not rest at heights.

#### **Using Ladders**

- Use wooden or insulated ladders when you need to perform live-line working at heights.
- Platform ladders with protective rails are preferred. Do not use single ladders.
- Before using a ladder, check that it is intact and confirm its load bearing capacity. Do not overload it.
- Ensure that the ladder is securely positioned and held firm.




- When climbing up the ladder, keep your body stable and your center of gravity between the side rails, and do not overreach to the sides.
- When a step ladder is used, ensure that the pull ropes are secured.

# Hoisting

- Only trained and qualified personnel are allowed to perform hoisting operations.
- Install temporary warning signs or fences to isolate the hoisting area.

- Ensure that the foundation where hoisting is performed on meets the load-bearing requirements.
- Before hoisting objects, ensure that hoisting tools are firmly secured onto a fixed object or wall that meets the load-bearing requirements.
- During hoisting, do not stand or walk under the crane or the hoisted objects.
- Do not drag steel ropes and hoisting tools or bump the hoisted objects against hard objects during hoisting.
- Ensure that the angle between two hoisting ropes is no more than 90 degrees, as shown in the following figure.



# **Drilling Holes**

- Obtain consent from the customer and contractor before drilling holes.
- Wear protective equipment such as safety goggles and protective gloves when drilling holes.
- To avoid short circuits or other risks, do not drill holes into buried pipes or cables.
- When drilling holes, protect the equipment from shavings. After drilling, clean up any shavings.

## Welding

- A welder must have a work permit. Obtain consent from the customer before welding.
- Ensure that at least two persons are present onsite for welding and that fire extinguishers, wet cloth, and water containers are available.
- Ensure that the welding site is free from inflammables.
- Do not weld or cut on pressurized containers or pipes. Electric devices must be powered off before welding.
- A burning welding torch must not be placed on a component or on the floor, and must not be placed in a metal container with acetylene and oxygen.
   Otherwise, the gas may leak and cause a fire.

• High-temperature pipes after welding must be promptly cooled.

#### **Using a Jack**

- A hydraulic jack is used to lift the container. Load bearing requirement: 30 t
- Only one side of the equipment can be raised or lowered. Before applying force, place wood sleepers and pads and take measures to prevent the jack from slipping and the equipment from vibrating.
- You can use two jacks to apply even forces simultaneously at two points on a short side of the equipment. Lift the equipment only from one side and then the other side, alternately. The height shall not exceed 120 mm each time the equipment is lifted.

# 1.5 Equipment Safety

# 1.5.1 ESS Safety

#### **A** DANGER

Do not open battery cabin doors when the system is running.

#### **A** DANGER

If the ESS is faulty, do not stand within the opening range of the battery cabin doors.

# **⚠** CAUTION

The equipment is equipped with a fire suppression system. Start the fire suppression system only in emergency.

# **♠** CAUTION

Do not disable the protection devices.

# **CAUTION**

Evacuate from the site immediately once the fire alarm horn/strobe is triggered.

#### **NOTICE**

Take protection and isolation measures for the ESS, such as installing fences, walls, and safety warning signs to prevent personal injury or property damage caused by unauthorized access during operations.

- When installing the ESS, comply with the fire separation distance or fire wall requirements specified in local standards, including but not limited to GB 51048-2014 Design Code for Electrochemical Energy Storage Station and NFPA 855 Standard for the Installation of Stationary Energy Storage Systems.
- Check the fire safety of the ESS regularly, at least once a month.
- When inspecting the system with power on, pay attention to the hazard warning signs on the equipment. Do not stand at the battery cabin doors. You are advised to perform the inspection near the control unit cabin.
- After power components of the ESS are replaced or cable connections are changed, you need to manually start cable connection detection and topology identification to prevent system malfunction.
- After the equipment is powered off, wait for 15 minutes and ensure that the equipment is not energized before operations.
- It is recommended that you prepare a camera to record the detailed processes of equipment installation, operation, and maintenance.

# 1.5.2 Battery Safety

#### **⚠** DANGER

Do not connect the positive and negative poles of a battery together. Otherwise, the battery may be short-circuited. Battery short circuits can generate high instantaneous current and releases a large amount of energy, which may cause battery leakage, smoke, flammable gas release, thermal runaway, fire, or explosion. To avoid battery short circuits, do not maintain batteries with power on.

#### **A** DANGER

Do not expose batteries at high temperatures or around heat sources, such as scorching sunlight, fire sources, transformers, and heaters. Battery overheating may cause leakage, smoke, flammable gas release, thermal runaway, fire, or explosion.

#### ▲ DANGER

Protect batteries from mechanical vibration, falling, collision, punctures, and strong impact. Otherwise, the batteries may be damaged or catch fire.

#### **DANGER**

To avoid leakage, smoke, flammable gas release, thermal runaway, fire, or explosion, do not disassemble, alter, or damage batteries, for example, insert foreign objects into batteries, squeeze batteries, or immerse batteries in water or other liquids.

#### **DANGER**

Do not touch battery terminals with other metal objects, which may cause heat or electrolyte leakage.

#### **A** DANGER

There is a risk of fire or explosion if the model of the battery in use or used for replacement is incorrect. Use a battery of the model recommended by the manufacturer.

#### **⚠** DANGER

Battery electrolyte is toxic and volatile. Do not get contact with leaked liquids or inhale gases in the case of battery leakage or odor. In such cases, stay away from the battery and contact professionals immediately. Professionals must wear safety goggles, rubber gloves, gas masks, and protective clothing, power off the equipment, remove the battery, and contact technical engineers.

#### **⚠** DANGER

A battery is an enclosed system and will not release any gases under normal operations. If a battery is improperly treated, for example, burnt, needle-pricked, squeezed, struck by lightning, overcharged, or subject to other adverse conditions that may cause battery thermal runaway, the battery may be damaged or an abnormal chemical reaction may occur inside the battery, resulting in electrolyte leakage or production of gases such as CO and H<sub>2</sub>. To prevent fire or device corrosion, ensure that flammable gas is properly exhausted.

#### **⚠** DANGER

The gas generated by a burning battery may irritate your eyes, skin, and throat. Take protective measures promptly.

#### **MARNING**

Install batteries in a dry area. Do not install them under areas prone to water leakage, such as air conditioner vents, ventilation vents, feeder windows of the equipment room, or water pipes. Ensure that no liquid enters the equipment to prevent faults or short circuits.

#### **WARNING**

Before installing and commissioning batteries, prepare fire fighting facilities, such as fire sand and carbon dioxide fire extinguishers, according to construction standards and regulations. Before putting into operation, ensure that fire fighting facilities that comply with local laws and regulations are installed.

#### **MARNING**

Before unpacking, storage, and transportation, ensure that the packing cases are intact and the batteries are correctly placed according to the labels on the packing cases. Do not place a battery upside down or vertically, lay it on one side, or tilt it. Stack the batteries according to the stacking requirements on the packing cases. Ensure that the batteries do not fall or get damaged. Otherwise, they will need to be scrapped.

#### **↑** WARNING

After unpacking batteries, place them in the required direction. Do not place a battery upside down or vertically, lay it on one side, tilt it, or stack it. Ensure that the batteries do not fall or get damaged. Otherwise, they will need to be scrapped.

# **MARNING**

Tighten the screws on copper bars or cables to the torque specified in this document. Periodically confirm whether the screws are tightened, check for rust, corrosion, or other foreign objects, and clean them up if any. Loose screw connections will result in excessive voltage drops and batteries may catch fire when the current is high.

# **MARNING**

After batteries are discharged, charge them in time to avoid damage due to overdischarge.

#### Statement

# The Company shall not be liable for any damage or other consequences to the batteries it provides due to the following reasons:

- Batteries are damaged due to force majeure such as earthquakes, floods, volcanic eruptions, debris flows, lightning strikes, fires, wars, armed conflicts, typhoons, hurricanes, tornadoes, and other extreme weather conditions.
- Batteries are damaged because the onsite equipment operating environment or external power parameters do not meet the environment requirements for normal operation, for example, the actual operating temperature of batteries is too high or too low, or the power grid is unstable and experiences outages frequently.
- Batteries are damaged, fall, leak, or crack due to improper operations or incorrect connection.
- After being installed and connected to the system, the batteries are not powered on in time due to your reasons, which causes damage to the batteries due to overdischarge.
- Batteries are damaged because they are not accepted in time due to your reasons.
- You set battery operating parameters incorrectly.
- You use batteries of different types together, causing acceleration of capacity attenuation. For example, you use our batteries together with batteries of other vendors or with batteries of different rated capacity.
- You maintain batteries improperly, causing frequent overdischarge; you expand the load capacity without notifying us; or you have not fully charged the batteries for a long time.
- You do not perform battery maintenance based on the operation guide, such as failure to check battery terminals regularly.
- Batteries are damaged because you do not store them in accordance with storage requirements (for example, in an environment that is damp or prone to rain).
- Batteries are not charged as required during storage due to your reasons, resulting in capacity loss or other irreversible damages to the batteries.
- Batteries are damaged due to your or a third party's reasons, for example, relocating or reinstalling the batteries without complying with the Company's requirements.
- You change the battery use scenarios without notifying the Company.
- You connect extra loads to the batteries.
- The battery storage period has exceeded the upper limit.
- The battery warranty period has expired. You are advised not to use a battery whose warranty period has expired, as this poses safety risks.

#### **General Requirements**

#### **NOTICE**

To ensure battery safety and battery management accuracy, use batteries provided by the Company. The Company is not responsible for any faults of batteries not provided by it.

- Before installing, operating, and maintaining batteries, read the battery
  manufacturer's instructions and comply with their requirements. The safety
  precautions specified in this document are highly important and require
  special attention. For additional safety precautions, see the instructions
  provided by the battery manufacturer.
- Use batteries within the specified temperature range. When the ambient temperature of the batteries is lower than the allowed range, do not charge the batteries to prevent internal short circuits caused during low-temperature charging.
- Before unpacking batteries, check whether the packaging is intact. Do not use batteries with damaged packaging. If any damage is found, notify the carrier and manufacturer immediately.
- Install batteries within 24 hours after unpacking. If the batteries cannot be installed in time, put them in the original packaging and place them in a dry indoor environment without corrosive gases. The process from unpacking batteries to powering on the system must be completed within 72 hours. During routine maintenance, ensure that the power-off time does not exceed 24 hours.
- Do not use a damaged battery (such as damage caused when a battery is dropped, bumped, bulged, or dented on the enclosure), because the damage may cause electrolyte leakage or flammable gas release. In the case of electrolyte leakage or structural deformation, contact the installer or professional O&M personnel immediately to remove or replace the battery. Do not store the damaged battery near other devices or flammable materials and keep it away from non-professionals.
- Before working on a battery, ensure that there is no irritant or scorched smell around the battery.
- When installing batteries, do not place installation tools, metal parts, or sundries on the batteries. After the installation is complete, clean up the objects on the batteries and the surrounding area.
- Do not install battery packs on rainy, snowy, or foggy days. Otherwise, the battery packs may be corroded by moisture or rain.
- If batteries are exposed to water accidentally, do not install them. Instead, transport the batteries to a safe isolation point and dispose of them in a timely manner.
- Before installing a battery pack, check that its enclosure is not deformed or damaged.
- Check whether the positive and negative battery terminals are grounded unexpectedly. If so, disconnect the battery terminals from the ground.
- Do not perform welding or grinding work around batteries to prevent fire caused by electric sparks or arcs.

- If batteries are left unused for a long period of time, store and charge them according to the battery requirements.
- Do not charge or discharge batteries by using a device that does not comply with local laws and regulations.
- Keep the battery loop disconnected during installation and maintenance.
- Monitor damaged batteries during storage for signs of smoke, flame, electrolyte leakage, or heat.
- If a battery is faulty, its surface temperature may be high. Do not touch the battery to avoid scalds.
- Do not stand on, lean on, or sit on the top of the equipment.
- In backup power scenarios, do not use the batteries for the following situations:
  - Medical devices substantially important to human life
  - Control equipment such as trains and elevators, as this may cause personal injury
  - Computer systems of social and public importance
  - Locations near medical devices
  - Other devices similar to those described above

#### **Short-Circuit Protection**

- When installing and maintaining batteries, wrap the exposed cable terminals on the batteries with insulation tape.
- Avoid foreign objects (such as conductive objects, screws, and liquids) from entering a battery, as this may cause short circuits.

#### Leakage Handling

#### **NOTICE**

Electrolyte leakage may damage the equipment. It will corrode metal parts and boards, and ultimately damage the boards.

Electrolyte is corrosive and can cause irritation and chemical burns. If you come into direct contact with the battery electrolyte, do as follows:

- Inhalation: Evacuate from contaminated areas, get fresh air immediately, and seek immediate medical attention.
- Eye contact: Immediately wash your eyes with water for at least 15 minutes, do not rub your eyes, and seek immediate medical attention.
- Skin contact: Wash the affected areas immediately with soap and water and seek immediate medical attention.
- Intake: Seek immediate medical attention.

#### Recycling

- Dispose of waste batteries in accordance with local laws and regulations. Do not dispose of batteries as household waste. Improper disposal of batteries may result in environmental pollution or an explosion.
- If a battery leaks or is damaged, contact technical support or a battery recycling company for disposal.
- If batteries are out of service life, contact a battery recycling company for disposal.
- Do not expose waste batteries to high temperatures or direct sunlight.
- Do not place waste batteries in environments with high humidity or corrosive substances.
- Do not use faulty batteries. Contact a battery recycling company to scrap them as soon as possible to avoid environmental pollution.

# 2 Overview

# 2.1 Model Description

#### **Product Models**

This document involves the following product models:

- LUNA2000-2.0MWH-1HX<sup>[1]</sup>
- LUNA2000-2.0MWH-2HX<sup>[1]</sup>
- LUNA2000-2.0MWH-HE2HX<sup>[1]</sup>
  - **MOTE**

[1]: The number corresponding to X is on the nameplate.

Figure 2-1 Model number (LUNA2000-2.0MWH-HE2HX is used as an example)




Table 2-1 Model number description

| No. | Meaning        | Description                             |
|-----|----------------|---|
| 1   | Product family | LUNA2000: Smart String ESS              |
| 2   | Capacity level | 2.0MWH: nominal capacity <sup>[1]</sup> |
| 3   | Region         | HE: high-altitude area                  |

| No.   | Meaning      | Description   |
|---|--------------|---|
| 4   | Backup power | 1HX: Applies to scenarios where the backup duration is greater than or equal to 1 hour  |
|   |              | 2HX: Applies to scenarios where the backup duration is greater than or equal to 2 hours |
| Note [1]: The nominal capacity is on the nameplate. |              |   |

#### **Model Identification**

You can view the product model on the nameplate on the side of the container.




Figure 2-2 Position of the nameplate

(1) Position of the nameplate

# 2.2 Label Description

| Label | Name                      | Meaning   |
|-------|---------------------------|---|
| 4     | Electric shock<br>warning | High voltage may occur<br>after the device is<br>powered on. Only<br>qualified and trained<br>electrical technicians are<br>allowed to install and<br>operate the device. |

| Label                                  | Name   | Meaning  |
|--|--|--|
| =                                      | Grounding symbol   | Indicates the position for connecting the ground cable.  |
| ************************************** | ADR transportation<br>warning label –<br>diamond-shape label | Helps other traffic participants identify and keep away from hazardous sources in a timely manner to reduce the risk of accidents. |
|  | Scald and heat<br>warning label                              | Indicates high temperature of the equipment to prevent scald.  |
| 2,9m<br>9'6"                           | Height label   | The equipment is high. You may need tools such as an insulation stool or a step ladder to facilitate operation.                    |
|  | Height (or mind the step) warning label                      | Indicates that the container height is greater than 2.6 m to alert the personnel during transportation and operation.              |
| <b>HWFU</b> 000000 0                   | Container No. label  | Displays the equipment container number.   |

# 2.3 Functions and Features

#### **Functions**

The LUNA2000-2.0MWH series Smart String ESS (excluding the Smart PCS) can manage charge and discharge of the DC power rectified by the Smart PCS for power grid peak shaving and frequency regulation.

#### **Features**

The ESS is a prefabricated all-in-one energy storage system that integrates the prefabricated modular structure system, power supply and distribution system, monitoring system, environment control system, fire suppression system, and integrated cabling system. It features high safety and reliability, fast deployment, low cost, high energy efficiency, and intelligent management.

• One controller per rack

Each battery rack is connected to a Smart Rack Controller that manages the charge and discharge of the rack independently, improving the available capacity and system availability and supporting the mixed use of old and new batteries.

- One optimizer per pack
  - a. The battery pack capacity in the battery racks is fully leveraged.
  - The battery pack can be replaced directly without manual SOC calibration. The replacement time is reduced and experts are not required onsite.
- Flexible and phased deployment

Flexible augmentation: The capacity of a plant can be expanded by adding ESSs without changing the AC power loop.

## 2.4 Appearance

■ NOTE

The appearance and position diagrams are for reference only. The actual situation may vary.

#### LUNA2000-2.0MWH-1HX

The LUNA2000-2.0MWH-1HX models have multiple layouts. The figures use one layout as an example. For details, see the following table.

Table 2-2 LUNA2000-2.0MWH-1HX layout

| Air<br>Conditioner<br>Position in the<br>Battery Cabin | Number of<br>DC Circuit<br>Breakers in<br>the Control<br>Unit Cabin | Number of<br>Smart Rack<br>Controllers | Number<br>of<br>Exhaust<br>Fans | Number<br>of Mixed-<br>Flow<br>Fans | Numbe<br>r of<br>Pressur<br>e Relief<br>Windo<br>ws <sup>1</sup> |
|--|---|--|---------------------------------|-------------------------------------|--|
| 1/2/4/5/7/8/10<br>/11                                  | 6   | 6                                      | 2                               | 8                                   | 0 or 6   |
| 1/3/5/7/9/11   | 6   | 6                                      | 2                               | 8                                   | 0 or 6   |

| Air<br>Conditioner<br>Position in the<br>Battery Cabin | DC Circuit |  | Number<br>of<br>Exhaust<br>Fans | Number<br>of Mixed-<br>Flow<br>Fans | Numbe<br>r of<br>Pressur<br>e Relief<br>Windo<br>ws <sup>1</sup> |
|--|------------|--|---------------------------------|-------------------------------------|--|
|--|------------|--|---------------------------------|-------------------------------------|--|

Note 1: Some models are equipped with pressure relief windows. The actual products delivered may vary.

Figure 2-3 LUNA2000-2.0MWH-1HX appearance Front View ⊞ 6058 mm Right View Left View 2438 mm 2 2896 mm 3 IB04W00046 (1) Battery cabin (2) Smart Rack Controller (3) Control unit cabin

Issue 15 (2023-11-01)

cabin




Figure 2-4 Components of the LUNA2000-2.0MWH-1HX

#### LUNA2000-2.0MWH-2HX

#### □ NOTE

The LUNA2000-2.0MWH-2HX models have multiple layouts. The figures use two layouts as examples. For details, see the following table.

Table 2-3 LUNA2000-2.0MWH-2HX layouts

| Air<br>Conditione<br>r Position<br>in the<br>Battery<br>Cabin | Number of DC Circuit Breakers in the Control Unit Cabin | Number<br>of Smart<br>Rack<br>Controller<br>s | Numb<br>er of<br>Exhau<br>st<br>Fans | Numbe<br>r of<br>Mixed-<br>Flow<br>Fans | Number of<br>Pressure Relief<br>Windows <sup>1</sup> |
|---|---|---|--------------------------------------|---|--|
| 1/3/5/7/9/1<br>1  | 3   | 3   | 2                                    | 8                                       | 0 or 6   |
| 2/4/6/8/10/<br>12   | 3   | 3   | 2                                    | 8                                       | 0 or 6   |
| 1/4/7/10  | 6   | 3   | 2                                    | 8                                       | 0 or 6   |

Note 1: Some models are equipped with pressure relief windows. The actual products delivered may vary.




Figure 2-5 LUNA2000-2.0MWH-2HX appearance (1)

cabin





Figure 2-6 Components of the LUNA2000-2.0MWH-2HX (1)



2896 mm

(2) Smart Rack Controller

cabin

Figure 2-7 LUNA2000-2.0MWH-2HX appearance (2)

### Issue 15 (2023-11-01)

(1) Battery cabin

- 3

IB04W00111

(3) Control unit cabin




Figure 2-8 Components of the LUNA2000-2.0MWH-2HX (2)

LUNA2000-2.0MWH-HE2HX

Table 2-4 LUNA2000-2.0MWH-HE2HX layout

| Air<br>Conditione<br>r Position<br>in the<br>Battery<br>Cabin | Number<br>of DC<br>Circuit<br>Breakers<br>in the<br>Control<br>Unit Cabin | Number<br>of Smart<br>Rack<br>Controller<br>s | Numb<br>er of<br>Exhau<br>st<br>Fans | Numbe<br>r of<br>Mixed-<br>Flow<br>Fans | Number of<br>Pressure Relief<br>Windows <sup>1</sup> |
|---|---|---|--------------------------------------|---|--|
| 1/4/7/10  | 6   | 3   | 2                                    | 8                                       | 0 or 6   |

Note 1: Some models are equipped with pressure relief windows. The actual products delivered may vary.





Figure 2-9 LUNA2000-2.0MWH-HE2HX appearance



cabin




Figure 2-10 Components of the LUNA2000-2.0MWH-HE2HX

## 2.5 ESS Composition

## 2.5.1 Battery Cabin

2 IBO4W00048

Figure 2-11 LUNA2000-2.0MWH-1HX battery cabin configurations 1

2 IB04W00008

**Figure 2-12** LUNA2000-2.0MWH-2HX/LUNA2000-2.0MWH-HE2HX battery cabin configurations 1

Table 2-5 Battery cabin configurations 1

| No. | Component<br>Name                          | Configuration | Quantity<br>Configured<br>for an ESS   | Description   |
|-----|--|---------------|--|---|
| 1   | Door status<br>sensor                      | Mandatory     | 6  | Monitors the door status of the battery cabin.  |
| 2   | Air conditioner<br>in the battery<br>cabin | Mandatory     | <ul> <li>LUNA2000-<br/>2.0MWH-1<br/>HX: 8/6</li> <li>LUNA2000-<br/>2.0MWH-2<br/>HX: 6/4</li> <li>LUNA2000-<br/>2.0MWH-<br/>HE2HX: 4</li> </ul> | Dissipates heat for components in the battery cabin.  |
| 3   | Battery pack                               | Mandatory     | 126  | The battery pack is a combination of batteries connected in series and output through a pair of positive and negative terminals. Each battery pack is configured with a pack optimizer and a battery monitoring unit (BMU). |




Figure 2-13 Battery cabin component configurations 2

**Table 2-6** Battery cabin configurations 2

| No. | Component<br>Name                     | Configuration | Quantity<br>Configured<br>for an ESS  | Description   |
|-----|---------------------------------------|---------------|---|---|
| 1   | Temperature and humidity (T/H) sensor | Mandatory     | 4   | Detects the indoor<br>temperature and<br>humidity in real time.                                 |
| 2   | Smoke<br>detector                     | Mandatory     | 2   | Common photoelectric smoke detector (voltage output type)                                       |
| 3   | CO sensor                             | Mandatory     | 6   | Detects the concentration of CO in combustible gases.   |
| 4   | Heat<br>detector                      | Mandatory     | 2   | Monitors the temperature of the battery cabin.  |
| 5   | Circuit<br>breaker                    | Mandatory     | 6   | Provides short-circuit protection and disconnects the high-voltage circuit of the battery rack. |
| 6   | Fuse                                  | Mandatory     | <ul> <li>LUNA2000-<br/>2.0MWH-1<br/>HX: 12</li> <li>LUNA2000-<br/>2.0MWH-2<br/>HX: 6</li> <li>LUNA2000-<br/>2.0MWH-<br/>HE2HX: 6</li> </ul> | Provides short-circuit protection.  |
| 7   | Black start<br>button                 | Optional      | 1   | Used for black start of the ESS.  |
| 8   | Light                                 | Mandatory     | 6 (apply only<br>to some<br>models)   | Used to illuminate the interior of the battery cabin.   |
| 9   | Mixed-flow<br>fan                     | Mandatory     | 10  | Facilitates the exhaust fans.   |
| 10  | Water<br>sensor                       | Mandatory     | 1   | Detects water based on the resistance change between both electrodes.                           |

Figure 2-14 Battery cabin configurations 3

**Table 2-7** Battery cabin configurations 3

| No. | Component<br>Name     | Configuration | Quantity<br>Configured for<br>an ESS | Description                                     |
|-----|-----------------------|---------------|--------------------------------------|---|
| 1   | Air intake<br>module  | Mandatory     | 2                                    | Consists of the labyrinth and air filter foam.  |
| 2   | Air exhaust<br>module | Mandatory     | 1                                    | Consists of the fan module and air filter foam. |

## 2.5.2 Control Unit Cabin




Figure 2-15 Control unit cabin component configuration 1

Table 2-8 Control unit cabin component configuration 1

| No. | Component<br>Name            | Configuration | Quantity<br>Configured<br>for an ESS | Description   |
|-----|------------------------------|---------------|--------------------------------------|---|
| 1   | Extinguishant release button | Mandatory     | 1                                    | -   |
| 2   | Extinguishant abort button   | Mandatory     | 1                                    | -   |
| 3   | Fire alarm<br>horn/strobe    | Mandatory     | 1                                    | Used for audible and visual alarm in the area where an accident occurs. |
| 4   | Gas release<br>alarm         | Mandatory     | 1                                    | Used for audible and visual alarm in the extinguishant protection area. |
| 5   | ESS emergency stop           | Mandatory     | 1                                    | _   |




Figure 2-16 Control unit cabin component configuration 2

**Table 2-9** Control unit cabin component configuration 2


| No. | Component<br>Name                                  | Configuration | Quantity<br>Configured for<br>an ESS | Description   |
|-----|--|---------------|--------------------------------------|---|
| 1   | Door status<br>sensor                              | Mandatory     | 2                                    | Monitors the door status of the control unit cabin.             |
| 2   | Air<br>conditioner<br>in the control<br>unit cabin | Mandatory     | 1                                    | Dissipates heat for components in the control unit cabin.       |
| 3   | Document<br>holder                                 | Mandatory     | 1                                    | -   |
| 4   | T/H sensor   | Mandatory     | 1                                    | Detects the indoor<br>temperature and<br>humidity in real time. |
| 5   | Lights   | Mandatory     | 1                                    | Used to illuminate the interior of the control unit cabin.      |

| No. | Component<br>Name              | Configuration | Quantity<br>Configured for<br>an ESS | Description   |
|-----|--------------------------------|---------------|--------------------------------------|---|
| 6   | Extinguishant<br>control panel | Mandatory     | 1                                    | Used for fire alarms and automatic fire extinguishing control. For details, see the extinguishant control panel manual included with the ESS. |
| 7   | Exhaust controller             | Mandatory     | 2                                    | Controls exhaust fans.  |
| 8   | Fire cylinder                  | Mandatory     | 1                                    | Stores fire extinguishant and its components include a solenoid valve, pressure gauges, and pipes.  |

#### □ NOTE

The control unit cabin has multiple internal layouts. The following figures are for reference only.


**Figure 2-17** LUNA2000-2.0MWH-1HX control unit cabin component configuration 3



2 3 1 (a ----- axia 010 ..... оно 8 - 10 ¥ 7 - J - 11 0 0 12 0 13 IB04W00049

**Figure 2-18** LUNA2000-2.0MWH-2HX control unit cabin component configuration 3






**Table 2-10** Control unit cabin component configuration 3


| No. | Component<br>Name            | Configuration | Quantity<br>Configured for<br>an ESS   | Description  |
|-----|------------------------------|---------------|--|--|
| 1   | DC circuit<br>breaker        | Mandatory     | <ul> <li>LUNA2000-2.<br/>0MWH-1HX:<br/>6</li> <li>LUNA2000-2.<br/>0MWH-2HX:<br/>3/6</li> <li>LUNA2000-2.<br/>0MWH-HE<br/>2HX: 6</li> </ul> | Provides short-circuit protection and DC circuit disconnection.  |
| 2   | AC meter                     | Mandatory     | 1  | Collects information about the auxiliary AC input power supply.  |
| 3   | PSU                          | Mandatory     | 6/4  | Converts AC input power into stable DC power.  |
| 4   | SMU                          | Mandatory     | 1  | Collects PSU information and controls PSU output.  |
| 5   | Embedded<br>Power<br>Subrack | Mandatory     | 1  | An embedded power subrack  |
| 6   | SmartModule                  | Optional      | 1  | Converges interfaces, converts protocols, and collects data for devices in the ESS, and expands ports for the CMU. |
| 7   | Adapter                      | Mandatory     | 1  | Supplies power to<br>the CMU and<br>SmartModule of<br>the ESS.   |

| No. | Component<br>Name                      | Configuration | Quantity<br>Configured for<br>an ESS | Description   |
|-----|--|---------------|--------------------------------------|---|
| 8   | Central<br>monitoring<br>unit (CMU)    | Mandatory     | 1                                    | Aggregates interfaces, converts protocols, collects, stores, and monitors data, and performs unified monitoring and local maintenance for devices in the ESS. |
| 9   | SmartModule                            | Mandatory     | 1                                    | Converges interfaces, converts protocols, and collects data for devices in the ESS, and expands ports for the CMU.  |
| 10  | AC circuit<br>breaker                  | Mandatory     | 1                                    | Provides short-circuit protection and disconnects the auxiliary power supply circuit of the ESS.  |
| 11  | AC surge<br>protective<br>device (SPD) | Mandatory     | 1                                    | Provides AC surge protection.   |
| 12  | Fiber<br>management<br>tray            | Mandatory     | 1                                    | Holds optical fibers.   |
| 13  | Water sensor                           | Mandatory     | 1                                    | Detects water<br>based on the<br>resistance change<br>between both<br>electrodes.   |

# 2.5.3 Smart Rack Controller Cabin

**Figure 2-20** Configuration of components in the Smart Rack Controller cabin of LUNA2000-2.0MWH-1HX





**Figure 2-21** Configuration of components in the Smart Rack Controller cabin of LUNA2000-2.0MWH-2HX/LUNA2000-2.0MWH-HE2HX

Table 2-11 Configuration of components in the Smart Rack Controller cabin

| No. | Component<br>Name        | Configuration | Quantity<br>Configured for<br>an ESS  | Description   |
|-----|--------------------------|---------------|---|---|
| 1   | Smart Rack<br>Controller | Mandatory     | <ul> <li>LUNA2000-2.0<br/>MWH-1HX: 6</li> <li>LUNA2000-2.0<br/>MWH-2HX: 3</li> <li>LUNA2000-2.0<br/>MWH-HE2HX: 3</li> </ul> | Manages charge<br>and discharge of<br>the battery rack. |

# 2.6 Components


# 2.6.1 Power Supply and Distribution System

## 2.6.1.1 Battery Pack

#### **Ⅲ** NOTE

The appearance of the battery pack is for reference only, and that of the actual product may vary.

Figure 2-22 Appearance



| Technical<br>Specifications   | Battery Pack                |                          |  |
|-------------------------------|-----------------------------|--------------------------|--|
| Model                         | ESM51320AS1                 | ESM-57280AS1             |  |
| Cell material                 | Lithium iron phosphate      | Lithium iron phosphate   |  |
| Cell capacity                 | 3.2 V/320 Ah                | 3.2 V/280 Ah             |  |
| Battery configuration         | 16S1P                       | 18S1P                    |  |
| Rated voltage                 | 51.2 V                      | 57.6 V                   |  |
| Nominal energy                | 16.38 kWh                   | 16.128 kWh               |  |
| Charging and discharging rate | ≤ 1C                        | ≤ 1C                     |  |
| Net weight                    | ≤ 140 kg                    | ≤ 140 kg                 |  |
| Dimensions (H x W x D)        | 307 mm x 442 mm x 660<br>mm | 307 mm x 442 mm x 660 mm |  |
| Cooling mode                  | Air cooled                  | Air cooled               |  |
| IP rating                     | IP20                        | IP20                     |  |
| Storage<br>temperature        | -40°C to +60°C              | -40°C to +60°C           |  |
| Transportation temperature    | -20°C to +60°C              | -20°C to +60°C           |  |

| Technical<br>Specifications | Battery Pack              |                           |
|-----------------------------|---------------------------|---------------------------|
| Equalization mode           | Passive cell equalization | Passive cell equalization |
| Communication s port        | CAN 2.0                   | CAN 2.0                   |

### 2.6.1.2 Smart Rack Controller

Figure 2-23 Appearance




Table 2-12 Technical specifications of efficiency

| Technical Specifications | Smart Rack Controller |  |
|--------------------------|-----------------------|--|
| Maximum efficiency       | ≥ 99.0%               |  |

**Table 2-13** Technical specifications of battery side

| Technical Specifications               | Smart Rack Controller |
|--|-----------------------|
| Number of battery strings              | 2                     |
| Minimum startup voltage                | 350 V                 |
| Rated power of a single battery string | 172 kW                |
| Rated power of a battery pack          | 344 kW                |

**Table 2-14** Technical specifications of bus side

| Technical Specifications                         | Smart Rack Controller |
|--|-----------------------|
| Number of battery strings connected to the bus   | 2                     |
| Maximum DC voltage                               | 1500 V                |
| Rated operating voltage                          | 1200 V                |
| Rated working current of a single battery string | 143.3 A               |


**Table 2-15** General specifications

| Technical Specifications            | Smart Rack Controller   |
|-------------------------------------|---|
| Parallel mode                       | Two parallel Smart Rack Controllers on<br>the battery side and two on the bus<br>side |
| Overvoltage category                | Bus side DC II  |
| Dimensions (H x W x D)              | 270 mm x 600 mm x 820 mm  |
| Net weight                          | ≤ 90 kg   |
| IP rating                           | IP66  |
| DC surge protection on the bus side | Type II   |
| Operating temperature range         | -30°C to +60°C  |
| Operating humidity range            | 0–100% (non-condensing)   |
| Storage temperature                 | -40°C to +70°C  |
| Storage humidity                    | 5%-95% RH   |
| Cooling mode                        | Intelligent air cooling   |
| Maximum Operating Altitude          | 4000 m  |
| Communications port                 | CAN, RS485, FE  |

#### 2.6.1.3 Embedded Power Subrack

#### ETP48400-C3B1

Embedded Power Subrack (ETP48400-C3B1) is an embedded power system that converts AC power into DC power. It supplies DC constant voltage to the equipment.




| Technical specification | Embedded Power Subrack                               |
|-------------------------|--|
| AC input system         | Three-phase 380 V/400 V AC; 3W + N + PE; 50 Hz/60 Hz |

#### ETP48200-B2A1

Embedded power subrack (ETP48200-B2A1) provides positions for installing components.

Figure 2-25 Appearance




#### 2.6.1.4 Rectifier Module PSU

The PSU (R4875G) converts AC input power into stable DC power.

## **Appearance**

Figure 2-26 Appearance



(4) Locking latch

(5) Handle

#### **Indicators**

Table 2-16 Indicator description

| Indicator          | Color  | Status                | Description  |
|--------------------|--------|-----------------------|--|
| Power              | Green  | Steady on             | The PSU has an AC input.   |
| indicator          |        | Off                   | There is no AC input.  |
|                    |        |                       | The PSU is damaged.  |
|                    |        | Blinking at<br>0.5 Hz | Querying is in progress.   |
|                    |        | Blinking at 4<br>Hz   | The PSU is loading the application program.  |
| Alarm<br>indicator | Yellow | Off                   | The PSU does not generate any protection alarm.  |
|                    |        | Steady on             | <ul> <li>A warning is generated due to<br/>ambient overtemperature.</li> <li>A shutdown protection alarm is<br/>generated due to ambient<br/>overtemperature or<br/>undertemperature.</li> </ul> |
|                    |        |                       | AC input overvoltage or undervoltage protection is triggered.  |


| Indicator | Color | Status                | Description   |
|-----------|-------|-----------------------|---|
|           |       |                       | The PSU is hibernating.   |
|           |       | Blinking at<br>0.5 Hz | The communication between the PSU and the monitoring module is interrupted. |
| Fault     | r Red | Off                   | The PSU is normal.  |
| indicator |       | Steady on             | The PSU locks out due to output overvoltage.                                |
|           |       |                       | The PSU has no output due to an internal fault.                             |

#### 2.6.1.5 SMU

SMU collects PSU information and controls PSU output.

#### SMU02C

Figure 2-27 Appearance



- (1) SD card slot
- (2) Running indicator
- (3) Minor alarm indicator

- (4) Major alarm indicator
- (5) Buttons
- (6) USB port (protected by a security protection mechanism)

- (7) RS485/RS232 communications port
- (8) FE communications port
- (9) CAN communications port

(10) Liquid crystal display (LCD)

(LCD)

Table 2-17 Indicator description

| Name              | Color | Status | Description                           |
|-------------------|-------|--------|---------------------------------------|
| Running indicator | Green | Off    | The SMU is faulty or has no DC input. |

| Name                  | Color  | Status                         | Description   |
|-----------------------|--------|--------------------------------|---|
|                       |        | Blinking<br>slowly (0.5<br>Hz) | The SMU is running properly and communicating with the host properly. |
|                       |        | Blinking fast<br>(4 Hz)        | The SMU is running properly but fails to communicate with the host.   |
| Minor alarm indicator | Yellow | Off                            | No minor or warning alarm is generated.                               |
|                       |        | Steady on                      | A minor or warning alarm is generated.                                |
| Major alarm indicator | Red    | Off                            | No critical or major alarm is generated.                              |
|                       |        | Steady on                      | A critical or major alarm is generated.                               |

Table 2-18 Button description

| Button | Name   | Description  |  |
|--------|--------|--|--|
|        | Up     | Press or to scroll through the menus or to   |  |
| ▼      | Down   | change the value of a parameter.   |  |
| 5      | Cancel | Returns to the previous menu without saving the settings.  |  |
| •      | Enter  | <ul> <li>Enters the main menu from the standby screen.</li> <li>Enters a submenu from the main menu.</li> <li>Saves menu settings on a submenu.</li> </ul> |  |

#### Note:

- The LCD screen becomes dark if no button is pressed within 30s.
- You need to log in again if no button is pressed within 1 minute.
- Press and hold and for 10s to restart the SMU.
- Press and hold and (or ) for 2s to increase or decrease the LCD contrast.

The LCD supports two-level password management for different users.


Table 2-19 Two-level password management

| Operation Permission  | Password  |
|---|---|
| All permissions except for changing the administrator password and resetting the web password | 000001  |
| All permissions   | 012589 <sup>a</sup>   |
|   | All permissions except for changing the administrator password and resetting the web password |

Note a: The administrator password can be used only by administrators. Do not provide the password to third-party maintenance personnel.

#### SMU11B

Figure 2-28 Appearance



TM10I20150

(1) Running indicator

(2) Minor alarm indicator

(3) Major alarm indicator

(4) Wiring terminals

(5) COM port

(6) Handle

(7) SN label

(8) FE communications port

Table 2-20 Indicator description

| Indicator         | Colo<br>r | Status | Description                           |
|-------------------|-----------|--------|---------------------------------------|
| Running indicator | Gree<br>n | Off    | The SMU is faulty or has no DC input. |


| Indicator             | Colo<br>r  | Status                         | Description   |
|-----------------------|------------|--------------------------------|---|
|                       |            | Blinking<br>slowly (0.5<br>Hz) | The SMU is running properly and communicating with the host properly. |
|                       |            | Blinking fast<br>(4 Hz)        | The SMU is running properly but fails to communicate with the host.   |
| Minor alarm indicator | Yello<br>w | Off                            | No minor or warning alarm is generated.                               |
|                       |            | Steady on                      | A minor or warning alarm is generated.                                |
| Major alarm indicator | Red        | Off                            | No critical or major alarm is generated.                              |
|                       |            | Steady on                      | A critical or major alarm is generated.                               |

# 2.6.2 Monitoring System

#### 2.6.2.1 CMU

### **Appearance**

Figure 2-29 Appearance



- (1) LED indicator
- (4) Guide rail clamp
- (7) SFP port
- (10) USB port
- (13) 12 V output power port
- (16) COM port
- (19) Protective ground point

- (2) SIM card slot
- (5) MBUS port (reserved)
- (8) 4G antenna port (reserved) (9) RST button
- (11) GE port (LAN)
- (14) Al port
- (17) 24 V input power port

(3) Mounting ear

(6) GE port (WAN)

- (12) DI port
- (15) DO port
- (18) 12 V input power port

### **Indicators**


Table 2-21 Indicators

| Indicator                              | Status                            |  | Description   |
|--|-----------------------------------|--|---|
| Running indicator (RUN)                | Green off                         |  | Not powered on  |
|  | Blinking green and then off fo    | slowly (on for 1s<br>r 1s)   | The communication with the management system is normal.                     |
|  | Blinking green<br>and then off fo | fast (on for 0.125s<br>r 0.125s)                                     | The communication with the management system is interrupted.                |
| Alarm/maintenance indicator (ALM)  ALM | Alarm status                      | Red off  | No system alarm is generated.   |
|  |                                   | Blinking red<br>slowly (on for 1s<br>and then off for<br>4s)         | The system raises a warning alarm.  |
|  |                                   | Blinking red fast<br>(on for 0.5s and<br>then off for 0.5s)          | The system raises a minor alarm.  |
|  |                                   | Steady red   | The system raises a major alarm.  |
|  | Maintenance<br>status             | Green off  | No local maintenance is in progress.  |
|  |                                   | Blinking green<br>slowly (on for 1s<br>and then off for<br>1s)       | Local maintenance is in progress.   |
|  |                                   | Blinking green<br>fast (on for<br>0.125s and then<br>off for 0.125s) | Local maintenance fails or<br>the connection to the app<br>is to be set up. |
|  |                                   | Steady green   | Local maintenance succeeded.  |

#### 2.6.2.2 SmartModule

### **Appearance**

Figure 2-30 Appearance



- (1) LED indicator
- (2) Mounting ear
- (3) Guide rail clamp

- (4) COM port
- (5) DI port
- (6) 12 V output power port

(7) Al port

- (8) PT port
- (9) Protective ground point

- (10) 12 V input power port
- (11) 24 V input power port
- (12) GE port

- (13) RST button
- -

## **Indicators**

| Indicator                                   | Status                              |  | Description   |
|---|-------------------------------------|--|---|
| Running indicator (RUN)                     | Green off                           |  | Not powered on  |
|   | Blinking green s<br>1s and then off | • ,  | The communication with the CMU is normal.                 |
|   | Blinking green to 0.125s and ther   | fast (on for<br>n off for 0.125s)                              | The communication with the CMU is interrupted.            |
| Alarm/<br>maintenance<br>indicator<br>(ALM) | Alarm status                        | Red off  | No alarm is raised for the SmartModule.                   |
|   |                                     | Blinking red<br>slowly (on for<br>1s and then<br>off for 4s)   | The SmartModule runs with an expired digital certificate. |
|   |                                     | Blinking red<br>fast (on for<br>0.5s and then<br>off for 0.5s) | The SmartModule digital certificate is invalid.           |
|   |                                     | Steady red   | Reserved  |

## 2.6.2.3 Input/Output Board (IO Board)

Only some models are equipped with the IO Board.

The IO Board controls and monitors some devices in the ESS, such as door status sensors, detectors, and air conditioners, as well as connects cables to the fire suppression system.

Figure 2-31 Position of IO board


(1) Position of IO Board

| Technical Specifications | IO Board                    |
|--------------------------|-----------------------------|
| Model                    | ENF1DETC                    |
| Operating voltage        | 220 V AC/12 V DC/24 V DC    |
| Operating current        | ≤1 A                        |
| Operating temperature    | -30°C to +55°C              |
| Humidity                 | ≤ 95% RH (non-condensing)   |
| Dimensions (W x H x D)   | 251 mm x 113.7 mm x 54.5 mm |

# 2.6.3 Environmental Control System

### 2.6.3.1 T/H Sensor

Figure 2-32 Appearance



**Ⅲ** NOTE

The appearance of the T/H sensor depends on the actual delivery.

Table 2-22 T/H sensor technical specifications

| Technical Specifications    | T/H sensor                              |
|-----------------------------|---|
| Temperature measuring range | -20°C to +80°C                          |
| Temperature precision       | ≤ ±0.5°C (25°C)                         |
|                             | ≤ ±1°C (full measuring range)           |
| Operating temperature       | -20°C to +80°C                          |
| Operating voltage           | 9–16 V DC                               |
| Storage temperature         | -40°C to +80°C                          |
| Signal output               | Two RJ45 ports, bidirectional cascading |

The T/H sensor uses an RJ45 connector.

**Figure 2-33** Pins of an RJ45 connector RJ45 female connector





Table 2-23 Pin definitions of an RJ45 connector

| Pin            | Description |
|----------------|-------------|
| Pin 1 or Pin 4 | Α           |
| Pin 2 or Pin 5 | В           |
| Pin 3          | V+          |
| Pin 6          | Reserved    |
| Pin 7          | Reserved    |
| Pin 8          | V-          |

## 2.6.3.2 Air Conditioner in the Control Unit Cabin

Figure 2-34 Appearance of the air conditioner in the control unit cabin




| Technical Specifications       | Air Conditioner in the Control Unit Cabin |  |
|--------------------------------|---|--|
| Air conditioner model          | PC3000D-3                                 |  |
| Operating temperature          | -30°C to +55°C                            |  |
| Rated DC input voltage         | -48 V DC                                  |  |
| Rated DC input power           | 1015 W                                    |  |
| Rated input current            | 20.5 A                                    |  |
| Cooling capacity (L35/<br>L35) | 2000 W                                    |  |

| Technical Specifications | Air Conditioner in the Control Unit Cabin   |
|--------------------------|---|
| Heating capacity         | 1100 W  |
| Dimensions (H x W x D)   | <ul> <li>746 mm x 446 mm x 300 mm (without flanges)</li> <li>783 mm x 479 mm x 300 mm (with flanges)</li> </ul> |
| Net weight               | 40 kg   |
| IP rating                | IP55  |
| Refrigerant              | R134a   |
| Surface treatment        | Electrostatic spraying  |

# 2.6.3.3 Air Conditioner in the Battery Cabin

Figure 2-35 Appearance




| Technical Specifications       | Air Conditioner in the Battery Cabin                          |  |
|--------------------------------|---|--|
| Air conditioner model          | РС6Н  |  |
| Rated voltage                  | 208-230 V AC  |  |
| Rated cooling capacity         | <ul><li>6350 W (L25/L45)</li><li>9300 W (L25/L35)</li></ul>   |  |
| Rated heating capacity<br>(W)  | 3000 W (PTC)  |  |
| Rated cooling power            | <ul><li>4150 W (L25/L45)</li><li>4120 W (L25/L35)</li></ul>   |  |
| Rated heating power            | 3000 W (PTC)  |  |
| Refrigerant (g)                | R134a   |  |
| Operating temperature          | -30°C to +55°C  |  |
| Humidity                       | 5%-100% RH  |  |
| Dimensions (H x W x D)         | 1770 mm x 620 mm x 300 mm (with flanges)                      |  |
| Transport performance          | Transported by train, vehicle, air, or sea                    |  |
| IP rating                      | IP55  |  |
| Fire-retardant performance     | Complies with UL94.   |  |
| External circulation corrosion | Complies with DKBA0.450.0065.                                 |  |
| Safety                         | Complies with EN60335, IEC 60950, UL60950, UL1995, and UL484. |  |
| Net weight                     | 125 kg  |  |

#### 2.6.3.4 Electrode Water Sensor

The water sensor detects water based on the resistance change between both electrodes.

When the electrodes detect water, they are short-circuited and the CMU reports an alarm.


Figure 2-36 Appearance



| Technical Specifications | Electrode Water Sensor |
|--------------------------|------------------------|
| Operating temperature    | -40°C to +80°C         |
| Storage temperature      | -40°C to +80°C         |

## 2.6.3.5 Door Status Sensor

Figure 2-37 Appearance




(1) Switch (2) Magnet

| Technical<br>Specifications | Door Status Sensor |
|-----------------------------|--------------------|
| Connection method           | Wiring terminals   |
| Rated current               | 500 mA             |
| Startup distance            | 25–45 mm           |
| Rated Power                 | 10 W               |
| Securing method             | Screw              |
| Hole spacing                | 40±0.8 mm          |

| Technical<br>Specifications | Door Status Sensor  |
|-----------------------------|---|
| Switch voltage              | 100 V DC (Max)  |
| Contact withstand voltage   | 150 V DC (Max)  |
| Impedance                   | 0.3 ohms  |
| Switch status               | Steady on   |
| Outer material              | White acrylonitrile butadiene styrene (ABS) engineering plastic |

## 2.6.3.6 Light

Figure 2-38 Appearance



| Technical Specifications | Light                      |
|--------------------------|----------------------------|
| Installation mode        | Ceiling-mounting           |
| Туре                     | LED lights                 |
| Light holder             | Integrated with the lights |
| IP rating                | IP20                       |
| Rated voltage            | 220 V AC                   |
| Frequency                | 50 Hz                      |
| Power                    | 10.5 W (68 x 0.2 W)        |
| Color temperature        | 5700 k                     |
| Color                    | White                      |

# 2.6.4 Fire Suppression System


□ NOTE

The component models in this section may vary.

#### 2.6.4.1 CO Sensor

CO sensor detects the concentration of CO in combustible gases.

Figure 2-39 Appearance



**Table 2-24** Technical specifications of the CO sensor

| Technical Specifications | CO Sensor                             |
|--------------------------|---------------------------------------|
| Dimensions (H x W x D)   | 40 mm x 97 mm x 25 mm                 |
| Operating voltage        | 8–30 V DC                             |
| Stability                | ≤ ±3% FS/year                         |
| Precision                | ≤ ±10% FS                             |
| Power consumption        | 0.12 W                                |
| Output signal            | RS485                                 |
| Operating temperature    | -25°C to +55°C                        |
| Humidity                 | 5%–95% RH (non-condensing)            |
| Resolution               | ≤ 30 ppm                              |
| Response time            | ≤ 60s                                 |
| Cabling mode             | RJ45 network port                     |
| Installation mode        | Gourd-shaped mounting hole/nut/magnet |

**Figure 2-40** Pins of an RJ45 connector RJ45 female connector





Table 2-25 Pin definitions of an RJ45 connector

| Pin            | Description |
|----------------|-------------|
| Pin 1 or Pin 4 | A           |
| Pin 2 or Pin 5 | В           |
| Pin 3          | V+          |
| Pin 6          | Reserved    |
| Pin 7          | Reserved    |
| Pin 8          | V-          |

#### 2.6.4.2 Air Exhaust Module

The air exhaust module is the actuator of the active air exhaust system. When the combustible gas is released from the battery, the air exhaust module reduces the concentration of combustible gas in the battery cabin.

Figure 2-41 Appearance



| Technical Specifications | Air Exhaust Module     |  |
|--------------------------|------------------------|--|
| Dimensions (H x W x D)   | 38 mm x 194 mm x 99 mm |  |
| Operating voltage        | 36-72 V DC             |  |
| Rated rotating speed     | 9500±10% RPM           |  |
| Operating temperature    | -25°C to +70°C         |  |

#### 2.6.4.3 Air Exhaust Controller

The air exhaust controller TCUE receives commands from the CMU and adjusts the fan speed.

Figure 2-42 Appearance




Table 2-26 Indicator description


| Silkscr<br>een | Color | Status                | Description  |
|----------------|-------|-----------------------|--|
| RUN            | Green | Steady on             | Power supply to the board is normal but no program is running.           |
|                |       | Blinking at 0.5<br>Hz | The system is running properly.  |
|                |       | Blinking at 4 Hz      | Serial port communication is interrupted or the board is not registered. |
|                |       | Off                   | The system is not powered on.  |
| ALM            | Red   | Steady on             | Power supply to the board is normal but no program is running.           |
|                |       | Blinking at 0.5<br>Hz | An alarm is generated.   |
|                |       | Off                   | No alarm is generated.   |

## 2.6.4.4 Extinguishant Control Panel

Used for fire alarms and automatic fire suppression control. For details, see the extinguishant control panel manual delivered with the ESS.

## Model: K11031M2

Figure 2-43 Appearance




| Technical<br>Specifications | Extinguishant Control Panel  |  |
|-----------------------------|--|--|
| Model                       | K11031M2   |  |
| Dimensions (H x W x D)      | 310 mm x 385 mm x 90 mm  |  |
| Operating voltage           | • 230 V+10%/-15% AC  |  |
|                             | <ul> <li>Sealed lead-acid batteries connected in series 12 V/7 Ah x 2</li> </ul> |  |
| Power                       | AC input ≤ 100 W   |  |
| Capacity                    | Number of detector loops: 3  |  |
|                             | • Number of detectors connected to each loop: ≤ 32                               |  |
| Detector loop               | Wire system of the detector loop: two-wire system                                |  |
| requirements                | • Length of the detector loop: ≤ 1000 m  |  |
| Enclosure<br>material       | Low-carbon steel   |  |
| Operating temperature       | -5°C (±3°C) to +55°C (±2°C)  |  |
| Humidity                    | ≤ 95% RH (non-condensing)  |  |
| IP rating                   | IP30   |  |

| Technical<br>Specifications | Sealed Lead-Acid Battery |  |
|-----------------------------|--------------------------|--|
| Standard voltage            | 12 V                     |  |
| Capacity                    | 7 Ah                     |  |

| Technical<br>Specifications | Sealed Lead-Acid Battery |  |
|-----------------------------|--------------------------|--|
| Required certification      | CE or UL certification   |  |
| Complied standard           | IEC 61056                |  |

# Model: JB-QBL-QM210

Figure 2-44 Appearance



| Technical<br>Specifications | Extinguishant Control Panel   |
|-----------------------------|---|
| Model                       | JB-QBL-QM210  |
| Dimensions (H x W x D)      | 440 mm x 340 mm x 99 mm   |
| Operating voltage           | AC input voltage: 220±20% V AC, 50 Hz   |
|                             | Maintenance-free battery 12 V DC/5 Ah x 2   |
| 24 V DC output              | Long-term and continuous: 3 A   |
| Power                       | AC input ≤ 120 W  |
| Capacity                    | <ul> <li>Number of detector loops: 3 (One is connected to a common heat detector, one is connected to a common smoke detector, and the remaining one is reserved.)</li> <li>Number of detectors connected to each loop: ≤ 24</li> </ul> |
| Wiring mode                 | Non-polarized two-wire system   |

| Technical<br>Specifications | Extinguishant Control Panel  |
|-----------------------------|--|
| Detector loop requirements  | <ul> <li>Wire system of the detector loop: two-wire system</li> <li>Length of the detector loop: ≤ 1000 m</li> </ul> |
| Enclosure<br>material       | A3 steel   |
| Installation mode           | Wall-mounted   |
| Operating temperature       | −10°C to +55°C   |
| Humidity                    | ≤ 95% RH (non-condensing)  |
| IP rating                   | IP30   |

| Technical<br>Specifications | Sealed Lead-Acid Battery |
|-----------------------------|--------------------------|
| Standard voltage            | 12 V                     |
| Capacity                    | 5 Ah                     |
| Required certification      | CE or UL certification   |
| Complied standard           | GB 19639                 |

## 2.6.4.5 Fire Cylinder

Fire cylinder stores fire extinguishant and its components include an electromagnetic valve, pressure gauges, and pipes.

#### NOTICE

• Fire cylinders should be protected from direct sunlight.



Figure 2-45 Appearance of a fire cylinder

(1) Position of the electromagnetic valve after installation

IB04W00054

| Technical<br>Specificatio<br>ns      | Fire Cylinder                      |                                |                                |                                |                                |                                    |
|--------------------------------------|------------------------------------|--------------------------------|--------------------------------|--------------------------------|--------------------------------|------------------------------------|
| Model                                | 227M38<br>UFAA                     | SPS020-<br>MS-032B<br>-EN      | P000943<br>8                   | NCM38UF<br>AA                  | GQQ40/<br>2.5                  | YF40/2<br>.5                       |
| Operating voltage                    | 24 V DC                            | 24 V DC                        | 24 V DC                        | 24 V DC                        | 24 V DC                        | 24 V<br>DC                         |
| Storage<br>pressure (at<br>20°C)     | 2.5 Mpa                            | 2.5 Mpa                        | 2.5 Mpa                        | 2.5 Mpa                        | 2.5 Mpa                        | 2.5Mp<br>a                         |
| Maximum operating pressure (at 50°C) | 4.2 Mpa                            | 4.2 Mpa                        | 3 Мра                          | 3 Мра                          | 4.2 Mpa                        | 4.2Mp<br>a                         |
| Startup<br>mode                      | Electro<br>magneti<br>c<br>startup | Electrom<br>agnetic<br>startup | Electrom<br>agnetic<br>startup | Electromag<br>netic<br>startup | Electrom<br>agnetic<br>startup | Electro<br>magne<br>tic<br>startup |

| Technical<br>Specificatio<br>ns                       | Fire Cylinder                                      |   |  |   |  |   |
|---|--|---|--|---|--|---|
| Electromag<br>netic<br>startup<br>voltage/<br>current | 24 V<br>DC/0.6<br>A                                | 24 V<br>DC/0.6 A                                | 24 V<br>DC/0.6 A                                   | 24 V<br>DC/0.6 A                            | 24 V<br>DC/1 A                           | 24 V<br>DC/1<br>A                       |
| Operating temperatur e                                | -10°C to<br>+55°C                                  | -10°C to<br>+60°C                               | -10°C to<br>+55°C                                  | -10°C to<br>+55°C                           | 0°C to<br>50°C                           | 0°C to<br>50°C                          |
| Relative<br>humidity                                  | ≤ 95%<br>RH<br>(non-<br>condens<br>ing at<br>40°C) | ≤ 95%<br>RH (non-<br>condensi<br>ng at<br>40°C) | ≤ 95%<br>RH<br>(non-<br>condensi<br>ng at<br>40°C) | ≤ 95% RH<br>(non-<br>condensing<br>at 40°C) | ≤ 95%<br>RH<br>(non-<br>condensi<br>ng)  | ≤ 95%<br>RH<br>(non-<br>conde<br>nsing) |
| Outer<br>diameter of<br>cylinder                      | ≤ 324<br>mm  | 324 mm  | 330 mm   | 300 mm                                      | 328 mm                                   | 328<br>mm                               |
| Cylinder<br>height                                    | ≤ 706<br>mm  | 730 mm  | ≤ 850<br>mm  | ≤ 850 mm                                    | 918 mm                                   | 918<br>mm                               |
| Gas release time                                      | 6s to<br>10s                                       | ≤ 10s   | ≤ 10s  | ≤ 10s                                       | ≤ 10s                                    | ≤ 10s                                   |
| Hose  | Length:<br>800<br>mm;<br>diamete<br>r: DN20        | Length:<br>800 mm;<br>diameter<br>: DN30        | Length:<br>800 mm;<br>diameter<br>: DN20           | Length:<br>700 mm;<br>diameter:<br>DN20     | Length:<br>800 mm;<br>diameter<br>: DN20 | Length: 800 mm; diamet er: DN20         |
| Extinguishin<br>g Chemical                            | Heptafl<br>uoropro<br>pane                         | Heptaflu<br>oropropa<br>ne                      | Perfluoro<br>hexanon<br>e                          | Perfluoroh<br>exanone                       | Heptaflu<br>oropropa<br>ne               | Perflu<br>orohex<br>anone               |
| Nominal<br>Capacity                                   | 38 L   | 32 L  | 40 L   | 38 L  | 40 L                                     | 40 L                                    |

# 2.6.4.6 Input/Output Modules

□ NOTE

Only some models are equipped with input/output modules.

Figure 2-46 Appearance





Figure 2-47 Position of input/output modules



(1) Position of input/output modules.

| Technical Specifications        | Input/Output modules          |  |
|---------------------------------|-------------------------------|--|
| Model                           | KZJ-956                       |  |
| Cabling mode                    | Non-polarized two-wire system |  |
| Quiescent current               | <0.6 mA                       |  |
| Operating current               | <10 mA                        |  |
| Output control contact capacity | 2 A @ DC 30 V                 |  |


| Technical Specifications  | Input/Output modules   |  |  |
|---------------------------|--|--|--|
| Working status indication | The indicator blinks about every 12 seconds in the inspection state, and is steady on in the output state. |  |  |
|                           | The input indicator is steady on in the input state.   |  |  |
| Operating temperature     | –10°C to +50°C   |  |  |
| Relative humidity         | ≤ 95% RH (non-condensing at 40°C ± 2°C)  |  |  |
| Terminal load             | 47 kilo-ohm resistor   |  |  |
| Dimensions (H x W x D)    | 86 mm x 86 mm x 40 mm (with base)  |  |  |
| Weight                    | Approx. 130 g (with base)  |  |  |

## 2.6.4.7 Fire Signal Transfer Board

## □ NOTE

Only some models are equipped with the fire signal transfer board.








Figure 2-49 Position of the fire signal transfer board

(1) Position of the fire signal transfer board

| Technical Specifications | Fire Extinguishing Board  |  |
|--------------------------|---------------------------|--|
| Model                    | ENF1DETAA                 |  |
| Operating voltage        | 24 V                      |  |
| Operating current        | ≤ 1 A                     |  |
| Operating temperature    | -30°C to +55°C            |  |
| Humidity                 | ≤ 95% RH (non-condensing) |  |
| Dimensions (H x W x D)   | 95 mm x 55 mm x 24 mm     |  |

#### 2.6.4.8 Heat Detector

Figure 2-50 Appearance




Table 2-27 Indicator description

| Item       | Color        | Status                   | Description         |
|------------|--------------|--------------------------|---------------------|
| Indicators | dicators Red | Steady on                | Enters alarm status |
|            | Blinking     | Enters monitoring status |                     |

Table 2-28 Technical specifications of the heat detector

| Technical<br>Specifications | Heat Detector   |   |
|-----------------------------|---|---|
| Configuring model           | 55000-121-EH/<br>55000-121-WZ   | JTW-ZD-920  |
| Dimensions                  | 100 mm diameter x 50 mm height (with base)  | 100 mm diameter x 56 mm height (with base)  |
| Operating voltage           | Supply voltage: 9 V to 33 V   | 24 V  |
| Net weight                  | Approx. 80 g  | Approx. 65 g  |
| Alarm category              | A1R   | A2R, 54°C to 70°C   |
| Enclosure material          | Polycarbonate, white  | ABS, white  |
| Cabling mode                | Polarized two-wire system   | Non-polarized two-wire system   |
| Operating current           | Monitoring status < 55<br>μA @24 V DC; alarm<br>status < 52 mA  | Monitoring status < 300<br>μA; alarm status < 1.5<br>mA   |
| Operating temperature       | -20°C to +90°C  | -10°C to +50°C  |
| Humidity                    | ≤ 95% RH (non-<br>condensing)   | ≤ 95% RH (non-<br>condensing)   |
| Installation mode           | Ceiling-mounted   | Ceiling-mounted   |
| Encoding mode               | No encoding   | The encoder can be used for onsite encoding. The address ranges from 1 to 324.  |
| Protected area              | About 50 m <sup>2</sup> (storey<br>height ≤ 8 m), referring<br>to GB50116-2013 Code<br>for Design of Automatic<br>Fire Alarm System | About 30 m <sup>2</sup> (storey<br>height ≤ 8 m), referring<br>to GB50116-2013 Code<br>for Design of Automatic<br>Fire Alarm System |
| Applicable base             | 45681-200   | DZ-916  |

| Technical<br>Specifications | Heat Detector |      |
|-----------------------------|---------------|------|
| IP rating                   | IP54          | IP30 |

#### 2.6.4.9 Smoke Detector

The smoke detector can detect the smoke concentration in the environment.



Do not use smoke detectors in condensation scenarios. Otherwise, false alarms may be generated. If a false alarm is generated, handle the alarm by referring to section 2.4 "3802 Fire Alarm" in the *LUNA2000-2.0MWH and 1.0MWH Series Smart String ESS Alarm Reference*.

Figure 2-51 Appearance




Table 2-29 Indicator description

| Item      | Color       | Status    | Description              |
|-----------|-------------|-----------|--------------------------|
| Indicator | dicator Red | Steady on | Enters alarm status      |
|           |             | Blinking  | Enters monitoring status |

**Table 2-30** Technical specifications

| Technical Specifications | Smoke Detector                                      |
|--------------------------|---|
| Model                    | 55000-316   |
| Dimensions               | 100 mm diameter x 50 mm height (with mounting base) |
| Operating voltage        | Supply voltage: 9 V DC to 33 V DC                   |
| Net weight               | Approx. 99 g  |
| Enclosure material       | Polycarbonate, white                                |

| Technical Specifications | Smoke Detector  |
|--------------------------|---|
| Cabling mode             | Polarized two-wire system   |
| Operating current        | <ul> <li>Power-up surge current: 115 μA at 24 V</li> <li>Alarm LED current: 4 mA</li> </ul> |
| Operating temperature    | -20°C to +60°C  |
| Humidity                 | ≤ 95% RH (non-condensing)   |

**Table 2-31** Technical specifications

| Technical<br>Specifications | Smoke Detector   |
|-----------------------------|--|
| Model                       | JTY-GD-930   |
| Dimensions                  | 100 mm diameter x 54 mm height (with mounting base)  |
| Operating voltage           | 24 V   |
| Net weight                  | Approx. 82 g   |
| Enclosure<br>material       | ABS, white   |
| Cabling mode                | Non-polarized two-wire system  |
| Operating current           | Monitoring status < 300 uA; alarm status < 1.5 mA  |
| Operating temperature       | -10°C ~ +55°C  |
| Humidity                    | ≤ 95% RH (non-condensing)  |
| Installation height         | ≤ 12 m   |
| Encoding mode               | The encoder can be used for onsite encoding. The address ranges from 1 to 324.   |
| Protection area             | About 80 m <sup>2</sup> (storey height ≤ 12 m), referring to GB50116-2013 Code for Design of Automatic Fire Alarm System |
| Installation mode           | Ceiling-mounted  |
| Applicable base             | DZ-916   |


## 2.6.4.10 Fire Alarm Horn/Strobe

Table 2-32 Indicator description

| Item       | Color | Status    | Description                   |
|------------|-------|-----------|-------------------------------|
| Indicators | Red   | Steady on | Enters the alarm status.      |
|            |       | Blinking  | Enters the monitoring status. |

## Model: 958CHL1001

Figure 2-52 Appearance



| Technical Specifications | Fire Alarm Horn/Strobe             |
|--------------------------|------------------------------------|
| Model                    | 958CHL1001                         |
| Operating voltage        | Bus 24 V DC                        |
| Operating current        | 55 mA MAX @24 V DC                 |
| Blinking frequency       | 1 Hz                               |
| Operating temperature    | -20°C to +70°C                     |
| Humidity                 | ≤ 95% RH (non-condensing)          |
| Alarm volume             | 88+ dBA @24 V                      |
| Dimensions (H x W x D)   | 92 mm x 109 mm x 92 mm (with base) |
| Enclosure material       | ABS, red                           |
| Cabling mode             | Polarized two-wire system          |

| Technical Specifications | Fire Alarm Horn/Strobe |
|--------------------------|------------------------|
| IP rating                | IP33C                  |

Model: SG-993

Figure 2-53 Appearance



| Technical Specifications | Fire Alarm Horn/Strobe   |
|--------------------------|--|
| Model                    | SG-993   |
| Operating voltage        | 24 V DC  |
| Operating current        | Monitoring status < 1 mA; alarm status < 120 mA                                |
| Blinking frequency       | 1 Hz to 1.5 fHz  |
| Operating temperature    | 0°C to 55°C  |
| Humidity                 | ≤ 95% RH (non-condensing)  |
| Alarm volume             | 75 dB to 95 dB   |
| Dimensions (H x W x D)   | 99 mm x 152 mm x 53 mm (with base)   |
| Weight                   | Approx. 155 g (with base)  |
| Enclosure material       | ABS, red   |
| Installation mode        | Wall-mounted   |
| Encoding mode            | The encoder can be used for onsite encoding. The address ranges from 1 to 324. |

| Technical Specifications | Fire Alarm Horn/Strobe                    |
|--------------------------|---|
| Cabling mode             | Non-polar two-line (L1, L2) + power cable |
| IP rating                | IP30                                      |

## 2.6.4.11 Extinguishant Release Indicator

Model: K27102

Figure 2-54 Appearance



IB04W00059

| Technical Specifications | Extinguishant Release Indicator |
|--------------------------|---------------------------------|
| Model                    | K27102                          |
| Operating voltage        | -15 V DC to 30 V DC             |
| Operating current        | 140 mA MAX @24 V DC             |
| Operating temperature    | -15°C to +40°C                  |
| Humidity                 | ≤ 95% RH (non-condensing)       |
| Dimensions (H x W x D)   | 300 mm x 195 mm x 50 mm         |
| Net weight               | Approx. 2 kg                    |
| Enclosure material       | BS 00 A 05 grey - fine texture  |
| Cabling mode             | Polarized two-wire system       |
| IP rating                | IP30                            |

## Model: QM-ZSD-02

Figure 2-55 Appearance



IB04W00017

| Technical Specifications         | Extinguishant Release Indicator   |
|----------------------------------|---|
| Model                            | QM-ZSD-02   |
| Operating voltage                | 24 V + 24 V DC  |
| Operating current                | <ul> <li>Bus current in static state: ≤ 500 µA</li> <li>When an alarm is generated, bus current ≤ 4 mA, 24 V DC current ≤ 150 mA</li> </ul> |
| Blinking frequency               | 1 Hz to 2 Hz  |
| Operating temperature            | 0°C to 55°C   |
| Humidity                         | ≤ 95% RH (non-condensing)   |
| Luminous text surface brightness | 50 cd/m <sup>2</sup> to 300 cd/m <sup>2</sup>   |
| Sound pressure level             | 75 dB to 120 dB   |
| Tone changing period             | 0.2s to 5s  |
| Dimensions (H x W x D)           | 339 mm x 150 mm x 35 mm   |
| Net weight                       | Approx. 435 g   |
| Enclosure material               | ABS, white  |
| Encoding mode                    | The encoder can be used for onsite encoding. The address ranges from 1 to 324.  |
| Cabling mode                     | Four-wire, non-polar two signal lines (L1, L2) + 24 V DC power cable (non-polar)  |
| Installation mode                | Wall-mounted  |
| IP rating                        | IP30  |

## 2.6.4.12 (Optional) Water Sprinkler System

The water sprinkler system is used to put out a fire in the ESS if the fire suppression system fails or the fire cannot be put out due to other uncontrollable factors.


#### □ NOTE

Some models are configured with a water sprinkler system. The actual configurations may vary.

#### **NOTICE**

The valve of the water sprinkler system is located on the side of the ESS and cannot be monitored through the SACU. Therefore, the customer shall enhance the management on the ESS site to prevent false triggering. Equipment damage caused by false triggering is not covered by the warranty.

Figure 2-56 Position of the water sprinkler port



(1) Position of the water sprinkler port




Figure 2-57 Water sprinkler system layout

(1) Water sprinkler system layout

Table 2-33 Port specifications

| Item            | Specifications |
|-----------------|----------------|
| External thread | BSPT 2"        |
| Thread length   | 20 mm          |

**Table 2-34** Water inlet requirements

| Item                      | Specifications |
|---------------------------|----------------|
| Total inlet water flow    | 175.38 L/min   |
| Water inlet pressure      | 0.94 bar       |
| Water inlet pipe diameter | DN50           |

#### **Startup Requirements**

#### NOTICE

- Check that the extinguishant monitoring devices are connected to the plant control system.
- Check that the ambient temperature monitoring devices in the ESS are connected to the plant control system.
- Check the status of the extinguishant in the ESS via the plant control system. If the extinguishant is not released, do not start the water sprinkler system.
- Check that the extinguishant has been released and at least two temperature monitoring points exceed 80°C in the ESS via the plant control system. Then start the water sprinkler system.
- Start the water sprinkler system in the ESS if open flames outside the ESS are detected through the video surveillance of the plant control system.



It is recommended that the video surveillance system with the infrared temperature measurement function be used.

## **Emergency Rescue Suggestions**

Rescue personnel are not allowed to stand in the door opening areas of the ESS, and must be away from the areas at a distance of greater than or equal to 20 m.

# 2.7 Working Principles

# 2.7.1 Battery circuit diagram

The LUNA2000-2.0MWH-1HX , LUNA2000-2.0MWH-2HX and LUNA2000-2.0MWH-HE2HX models have multiple circuit diagrams. The figures use one circuit diagram for each model as an example. For details, see the following table.

**Table 2-35** Switch configuration

| Models  | Air<br>Conditio<br>ner<br>Position<br>in the<br>Battery<br>Cabin | Air<br>Conditioner<br>Switches No.                                   | Battery<br>Pack Fans<br>Switches<br>No. | Smart Rack<br>Controller<br>Switches<br>No.                   | DC Circuit<br>Breakers<br>No. in the<br>Control<br>Unit<br>Cabin |
|---|--|--|---|---|--|
| LUNA200<br>0-2.0MW<br>H-1HX                                   | 1/2/4/5/7<br>/8/10/11  | 3FCB1, 3FCB2,<br>3FCB4, 3FCB5,<br>3FCB7, 3FCB8,<br>3FCB10,<br>3FCB11 | 7FCB7-<br>7FCB15,<br>7FCB19-<br>7FCB27  | 7FCB16,<br>7FCB17,<br>7FCB18,<br>7FCB28,<br>7FCB29,<br>7FCB30 | 1Q2-6Q2  |
| LUNA200<br>0-2.0MW<br>H-1HX                                   | 1/3/5/7/9<br>/11   | 3FCB1, 3FCB3,<br>3FCB5, 3FCB7,<br>3FCB9,<br>3FCB11                   | 7FCB7-<br>7FCB15,<br>7FCB19-<br>7FCB27  | 7FCB16,<br>7FCB17,<br>7FCB18,<br>7FCB28,<br>7FCB29,<br>7FCB30 | 1Q2-6Q2  |
| LUNA200<br>0-2.0MW<br>H-2HX                                   | 1/3/5/7/9<br>/11   | 3FCB1, 3FCB3,<br>3FCB5, 3FCB7,<br>3FCB9,<br>3FCB11                   | 7FCB7-<br>7FCB15,<br>7FCB19-<br>7FCB27  | 7FCB16,<br>7FCB17,<br>7FCB18                                  | 1Q2-3Q2  |
| LUNA200<br>0-2.0MW<br>H-2HX                                   | 2/4/6/8/1<br>0/12  | 3FCB2, 3FCB4,<br>3FCB6, 3FCB8,<br>3FCB10,<br>3FCB12                  | 7FCB7-<br>7FCB15,<br>7FCB19-<br>7FCB27  | 7FCB16,<br>7FCB17,<br>7FCB18                                  | 1Q2-3Q2  |
| LUNA200<br>0-2.0MW<br>H-2HX/<br>LUNA200<br>0-2.0MW<br>H-HE2HX | 1/4/7/10   | 3FCB1, 3FCB4,<br>3FCB7,<br>3FCB10                                    | 7FCB7-<br>7FCB12                        | 7FCB16,<br>7FCB17,<br>7FCB18                                  | 1Q2-6Q2  |

#### **LUNA2000-2.0MWH-1HX**

++DCR ++BR ++PDR 1CC1-21 1Q1 1Q2 1F1 ⇒ 1# SMART RACK CONTROLLER (TA1) OUTPUT 7 2 2 1F2 2CC1-21 2Q1 2Q2 TA2 2F1 > 2# SMART RACK CONTROLLER (TA2) OUTPUT 2 2 2F2 3CC1-21 3Q1 3Q2 TA3 3F1 ⇒ 3# SMART RACK CONTROLLER 7 (TA3) OUTPUT 2 3F2 7 4CC1-21 4Q1 4Q2 4F1 ⇒ 4# SMART RACK CONTROLLER (TA4) OUTPUT 2 2 4F2 1 5CC1-21 5Q1 5Q2 TA5 5F1 ⇒ 5# SMART RACK CONTROLLER (TA5) OUTPUT 2 2 5F2 6CC1-21 6Q1 6Q2 TA6 6F1 ⇒ 6# SMART RACK CONTROLLER 7 (TA6) OUTPUT 6F2 (BATTERY) PACK SMART RACK CONTROLLER

Figure 2-58 Battery circuit diagram 1 of the LUNA2000-2.0MWH-1HX

IB04P00028




Figure 2-59 Battery circuit diagram 2 of the LUNA2000-2.0MWH-1HX

IB04P00029







Figure 2-60 Battery circuit diagram 3 of the LUNA2000-2.0MWH-1HX






## LUNA2000-2.0MWH-2HX/LUNA2000-2.0MWH-HE2HX


**Figure 2-62** Battery circuit diagram 1 of the LUNA2000-2.0MWH-2HX/LUNA2000-2.0MWH-HE2HX



Issue 15 (2023-11-01)



**Figure 2-63** Battery circuit diagram 2 of the LUNA2000-2.0MWH-2HX/LUNA2000-2.0MWH-HE2HX



**Figure 2-64** Battery circuit diagram 3 of the LUNA2000-2.0MWH-2HX/LUNA2000-2.0MWH-HE2HX

# 2.7.2 Working Modes

The ESS has six working states: running, hibernation, self-check, fault, offline, and loading.

Table 2-36 Working states

| Working<br>State | Description   |
|------------------|---|
| Running          | The ESS is charging from an external DC source or discharging for external devices.                                       |
| Hibernation      | The ESS stops charging and discharging and shuts down the Smart Rack Controllers.   |
|                  | <ul> <li>In the running state, if the ESS receives a hibernation<br/>command, it enters the hibernation state.</li> </ul> |
|                  | In the hibernation state, if the ESS receives a running command, it enters the running state.                             |

| Working<br>State | Description   |
|------------------|---|
| Self-check       | The ESS is in progress of a self-check.   |
| Fault            | If a Smart Rack Controller or a battery pack is faulty, the ESS enters the fault state.       |
| Offline          | Smart Rack Controllers are disconnected from the CMU.   |
| Loading          | After the CMU starts, the ESS is waiting for the energy storage units (ESUs) to be connected. |

# 2.8 Typical Application Scenarios


For details about on-grid scenarios, see On-Grid Utility-Scale Energy Storage Solution Quick Guide. For details about microgrid scenarios, see Medium-Voltage Microgrid Energy Storage Solution Quick Guide.


# 3 Transportation and Storage

# 3.1 Transportation Requirements

### **General Requirements**


Be cautious to prevent injury when moving heavy objects.





- If multiple persons need to move a heavy object together, determine the manpower and work division with consideration of height and other conditions to ensure that the weight is equally distributed.
- If two persons or more move a heavy object together, ensure that the object is lifted and landed simultaneously and moved at a uniform pace under the supervision of one person.
- Wear personal protective gears such as protective gloves and shoes when manually moving the equipment.
- To move an object by hand, approach to the object, squat down, and then lift the object gently and stably by the force of the legs instead of your back. Do not lift it suddenly or turn your body around.
- Move or lift the equipment by holding its handles or lower edges. Do not hold the handles of modules that are installed in the equipment.
- Do not quickly lift a heavy object above your waist. Place the object on a workbench that is half-waist high or any other appropriate place, adjust the positions of your palms, and then lift it.
- Move a heavy object stably with balanced force at an even and low speed. Put
  down the object stably and slowly to prevent any collision or drop from
  scratching the surface of the equipment or damaging the components and
  cables.

- When moving a heavy object, be aware of the workbench, slope, staircase, and slippery places. When moving a heavy object through a door, ensure that the door is wide enough to move the object and avoid bumping or injury.
- When transferring a heavy object, move your feet instead of turning your waist around. When lifting and transferring a heavy object, ensure that your feet point to the target direction of movement.
- When transporting the equipment using a pallet truck or forklift, ensure that
  the tynes are properly positioned so that the equipment does not topple.
  Before moving the equipment, secure it to the pallet truck or forklift using
  ropes. When moving the equipment, assign dedicated personnel to take care
  of it.
- The tilt angle of the ESS shall meet the requirements shown in the figure:  $\alpha \le 5^{\circ}$ .



## **Transportation Requirements**

#### **DANGER**

Load or unload batteries with caution. Otherwise, the batteries may be short-circuited or damaged (such as leakage and crack), catch fire, or explode.

## **MARNING**

Do not move a battery by holding its terminals, bolts, or cables. Otherwise, the battery may be damaged.

Keep batteries in the correct direction during transportation. They must not be placed upside down or tilted, and must be protected against falling down, mechanical impact, rains, snows, and falling into water during transportation.

- The product has obtained the certifications of the UN38.3 (UN38.3: section 38.3 of the sixth Revised Edition of the Recommendations on the Transport of Dangerous Goods, Manual of Tests and Criteria) and SN/T 0370.2-2009 (Part 2: Performance Test of the Rules for the Inspection of Packaging for Exporting Dangerous Goods). This product belongs to class 9 dangerous goods.
- The transportation service provider must be qualified to transport dangerous goods. Open truck transportation is not allowed.

- Comply with the international regulations on the transport of dangerous goods and meet the requirements of the transportation regulatory authorities in the countries of departure, route, and destination.
- Choose sea or roads in good conditions for transportation. Do not transport the equipment by railway or air. Avoid tilt or jolt during transportation.
- Maritime transport must comply with the *International Maritime Dangerous Goods Code* (IMDG Code).
- Monitor the entire transportation process.
- Vehicles for road transport shall meet the load bearing capacity requirements: The weight of a single ESS is about 30 t.
- The speed limit for road transport is 80 km/h on flat roads and 60 km/h on rough roads. In the case of any conflict, comply with local traffic laws and regulations.
- Stacking requirements at ports and during shipping: A maximum of five ESSs shall be permitted to be stacked.
- Road transport must comply with the Agreement Concerning the International Carriage of Dangerous Goods by Road (ADR) or JT/T 617.
- Before transportation, ensure that the ESS container is intact, the cabin doors are closed and locked, no foreign matter protrudes from the container, and there is no smell of smoke or burning. Otherwise, do not transport the ESS.
- Before transportation, check that the battery package is intact and that there
  is no abnormal odor, leakage, smoke, or sign of burning. Otherwise, the
  batteries must not be transported.
- Handle the ESS with care during loading, unloading, and transportation and moisture-proof measures must be in place. The product specifications upon delivery may be affected subsequently by the environment conditions, such as temperature, transportation, and storage.
- The packing case must be secured for transportation. Handle the case with care during loading and unloading, and take moisture-proof measures during transportation.
- Exercise caution when moving batteries to prevent bumping and ensure personal safety.
- Unless otherwise specified, dangerous goods must not be mixed with goods containing food, medicine, animal feed, or their additives in the same vehicle or container.
- Unless otherwise specified, when dangerous goods packages are loaded in the same vehicle or container as ordinary goods, they shall be separated in either of the following ways:
  - Use a spacer that is as high as the packages.
  - Keep a distance of at least 0.8 m around.
- Before transporting a faulty battery (with scorch, leakage, bulge, or water intrusion), insulate its positive and negative terminals, pack it, and place it in an insulated explosion-proof box as soon as possible. Record information such as the site name, address, time, and fault symptom on the box.
- When transporting faulty batteries, avoid approaching flammable material storage areas, residential areas, or other densely populated places, such as mass transit facilities or elevators.

## 3.2 Storage Requirements

#### **General Requirements**

- Proof that the product is stored according to the requirements must be available, such as temperature and humidity log data, storage environment photos, and inspection reports.
- The storage environment must be clean and dry. The product must be protected against rain and water.
- The air must not contain corrosive or flammable gases.
- Do not tilt the product or place it upside down.
- If equipment except battery packs has been stored for more than two years, it must be checked and tested by professionals before use.

#### **ESS Storage Requirements**

- Do not stack the ESSs.
- The ground for (long-term or temporary) storage is level, and the height tolerance of the ground in contact with the container is less than 5 mm.
- The container doors are closed tightly.
- Storage temperature: -40°C to +60°C; relative humidity: 5%-95% RH
- Place desiccant in control unit cabins and battery cabins for long-term storage.
- The main power loop of the ESS must be disconnected during storage. It is recommended that the auxiliary power loop be powered on to ensure that the monitoring system works properly.

#### **Battery Storage Requirements**

#### **MARNING**

- Ensure that batteries are stored in a dry, clean, and ventilated indoor environment that is free from sources of strong infrared or other radiations, organic solvents, corrosive gases, and conductive metal dust. Do not expose batteries to direct sunlight or rain and keep them far away from sources of heat and ignition.
- If a battery is faulty (with scorch, leakage, bulge, or water intrusion), move it to a dangerous goods warehouse for separate storage. The distance between the battery and any combustible materials must be at least 3 m. The battery must be scrapped as soon as possible.
- Place batteries correctly according to the signs on the packing case during storage. Do not place batteries upside down, lay them on one side, or tilt them. Stack batteries in accordance with the stacking requirements on the packing cases.
- Store batteries in a separate place. Do not store batteries together with other devices. Do not stack batteries too high. The site must be equipped with qualified fire fighting facilities, such as fire sand and fire extinguishers.
- After batteries are powered off, static power consumption and self-discharge loss may occur in internal modules, which may cause battery damage due to overdischarge. Do not store batteries in low SOC and charge batteries in a timely manner. Permanent battery faults caused by delayed charge are not covered by the warranty. Storing the batteries in low SOC occurs in scenarios including but not limited to the following:
  - The power cables or signal cables are not connected.
  - The batteries cannot be charged due to a system fault after discharge.
  - The batteries cannot be charged due to incorrect configurations in the system.
  - The batteries cannot be charged due to long-term mains failure.
  - The batteries cannot be charged because the switch of the Smart Rack Controller, Smart PCS, or main loop component is off.

## **CAUTION**

It is recommended that batteries be used soon after being deployed onsite. Batteries that have been stored for an extended period shall be charged periodically. Otherwise, they may be damaged.

Packaging label description

| Label | Description  |
|-------|--|
|       | This way up: The package shall be vertically oriented during transport and storage.  |
|       | Fragile: The package contains fragile objects and shall be handled with care.  |
|       | Keep dry: The package shall be kept away from rain.  |
|       | Stacking limit by number: The packages shall not be vertically stacked beyond the specified number. The actual label may vary. |

- The storage environment requirements are as follows:
  - Ambient temperature: -40°C to +60°C (0°C to 30°C are recommended. If batteries are stored at a temperature higher than 40°C for extended periods, the battery performance and service life may be deteriorated.)
  - Relative humidity: 5%-95% RH (recommended: about 45% RH)
  - Dry, clean, and well-ventilated
  - Away from corrosive organic solvents and gases
  - Away from direct sunlight
  - At least 2 m away from heat sources
- The batteries in storage must be disconnected from external devices. The indicators (if any) on the batteries must be off.
- The storage duration starts from the latest charge time labeled on the battery package. If a battery is qualified after charge, update the latest charge time (recommended format: YYYY-MM-DD HH:MM) and the next charge time (Next charge time = Latest charge time + Charge interval) on the label.
- The following table lists the maximum charge intervals for batteries delivered separately. Charge the batteries promptly and calibrate the SOC to at least 50%. Otherwise, the battery performance and service life may be deteriorated.

| Storage Temperature (T) | Maximum Charge Interval <sup>a</sup> |  |
|-------------------------|--------------------------------------|--|
| -40°C < T ≤ +30°C       | 15 months                            |  |
| 30°C < T ≤ 40°C         | 11 months                            |  |
| 40°C < T < 60°C         | 7 months                             |  |

Note a: The interval starts from the latest charge time labeled on the battery package.

 The following table lists the maximum total storage and transportation time for batteries delivered with the ESS. Charge the batteries promptly and calibrate the SOC to at least 50%. Otherwise, the battery performance and service life may be deteriorated.

| Storage Temperature (T)  | Maximum Total Storage and Transportation Time <sup>a</sup> |
|--|--|
| -40°C < T ≤ +30°C  | 11 months  |
| 30°C < T ≤ 40°C  | 7 months   |
| 40°C < T < 60°C  | 3 months   |
| Note a: The total time starts from the time when the product is shipped. |  |

- Do not unpack batteries. If charging is necessary, they must be charged by professionals as required and then returned to their original packaging after charging.
- The warehouse keeper shall collect battery storage information every month and periodically report the battery inventory information. The batteries in long-term storage shall be charged in a timely manner.

## **<u>A</u>** CAUTION

- Only trained and qualified personnel are allowed to charge batteries. Wear insulated gloves and use dedicated insulated tools during the operation.
- Observe onsite during charge and handle any exceptions in a timely manner.
- If a battery experiences an abnormality such as bulging or smoking during charge, stop charging immediately and dispose of it.
- When stored in low SOC, the batteries must be charged within the maximum interval corresponding to the SOC when the batteries are powered off. If the batteries are not charged within the specified interval, they may be damaged due to overdischarge.

| Power-Off SOC Before Storage Maximum Charge Interval |   |
|--|---|
| SOC ≥ 50%  | Refer to the charge intervals for batteries delivered separately. |
| 5% ≤ SOC < 50%                                       | 20 days   |
| SOC < 5%   | 48 hours  |

- For details about how to charge batteries, see **3.3 Charging Requirements** for a Single Battery.
- If batteries have been stored for longer than allowed, promptly report the event to the person in charge.
- Ensure that batteries are delivered based on the "first in, first out" rule.
- Handle batteries with caution to avoid damage.

#### Storage Requirements for Fire Suppression Equipment

- At room temperature (about 25°C), charge the backup battery of the extinguishant control panel at least once every six months. The charge interval is halved for every 10°C increase in temperature.
- When the fire suppression equipment is stored as spare parts, the ambient temperature shall range from 0°C to 50°C and the humidity shall be less than or equal to 95% RH.

#### Storage Requirements for a Smart Rack Controller

If a spare Smart Rack Controller will not be used immediately, store it according to the following requirements:

- Do not remove the packaging. Check the packaging regularly (recommended: once every three months). Replace any packing materials that become damaged during storage. If the Smart Rack Controller is unpacked but will not be used immediately, put it back to the original packaging with the desiccant, and seal with tape.
- Storage temperature: -40°C to +70°C; relative humidity: 5%-95% RH
- Stack Smart Rack Controllers with caution to prevent them from falling over, resulting in personal injury or equipment damage.

## 3.3 Charging Requirements for a Single Battery

## **Material Delivery Check**

There must be a battery charge label on the packing case. The charge label must specify the latest charge time and the next charge time.

## **Conditions for Determining Overdue Storage**

• Do not store batteries for extended periods.

 The following table lists the maximum charge intervals for batteries delivered separately. Charge the batteries promptly and calibrate the SOC to at least 50%. Otherwise, the battery performance and service life may be deteriorated.

| Storage Temperature (T)  Maximum Charge Intervala                      |           |
|--|-----------|
| -40°C < T ≤ +30°C  | 15 months |
| 30°C < T ≤ 40°C  | 11 months |
| 40°C < T < 60°C  | 7 months  |
| Note a: The interval starts from the latest charge time labeled on the |           |

Note a: The interval starts from the latest charge time labeled on the battery package.

 The following table lists the maximum total storage and transportation time for batteries delivered with the ESS. Charge the batteries promptly and calibrate the SOC to at least 50%. Otherwise, the battery performance and service life may be deteriorated.

| Storage Temperature (T)  | Maximum Total Storage and<br>Transportation Time <sup>a</sup> |
|--|---|
| -40°C < T ≤ +30°C  | 11 months   |
| 30°C < T ≤ 40°C  | 7 months  |
| 40°C < T < 60°C  | 3 months  |
| Note a: The total time starts from the time when the product is shipped. |   |

- If batteries have been stored for longer than allowed, promptly report the event to the person in charge.
- Dispose of deformed, damaged, or leaking batteries directly irrespective of how long they have been stored.
- The storage duration starts from the latest charge time labeled on the battery package. If a battery is qualified after charge, update the latest charge time (recommended format: YYYY-MM-DD HH:MM) and the next charge time (Next charge time = Latest charge time + Charge interval) on the label.
- Batteries can be charged for a maximum of three times during storage. Dispose of batteries if the maximum charge times are exceeded.
- You can obtain the battery production completion time by querying the delivery record based on the battery pack serial number (SN) or consulting the Company's service engineers.

### **Preparing Charging Devices**

- Multimeter
- Clamp meter
- Insulated torque socket wrench
- Charger

#### **Inspection Before Charge**

- 1. Before charging a battery, you need to check its appearance. Charge the qualified battery or dispose of the unqualified one.
- 2. The battery is qualified if it is free from the following symptoms:
  - Deformation
  - Shell damage
  - Leakage
- 3. Check that the accessories are complete based on the packing list delivered with the charger.

#### **Full Charge Strategy**

The charging ambient temperature ranges from 15°C to 40°C.

| Charge and Discharge Current (Unit: Ampere) | Charging Duration (Excluding Equalization)  |
|---|---|
| 20  | 24 hours (fully discharge the battery and then charge the battery to 50% SOC)       |
| 40 <sup>[1]</sup>                           | 12 hours (fully discharge the battery<br>and then charge the battery to 50%<br>SOC) |

Note 1: In customized mode, use the AC 220 V/20 A (6 mm<sup>2</sup>) power cable delivered with the charger.

## **Charging Procedure**

□ NOTE

Prepare the battery qualified for charge.

- **Step 1** Connect the communications port on the charger to the COM-2 and 48V-2 ports on the battery using the CAN communications cable (48 V) delivered with the charger.
- **Step 2** Connect the positive and negative cable ports on the charger to the positive and negative ports on the battery using the positive and negative DC input power cables delivered with the charger.
- **Step 3** Connect the AC INPUT port on the charger to the utility power source using the power cable delivered with the charger.
- **Step 4** Turn on the AC circuit breaker of the charger.
- **Step 5** Turn on the DC circuit breaker of the charger.
- **Step 6** Operate the charger according to its manual.

**Step 7** After the discharge and charge are complete, wait until the fan in the charger keeps running for about 5 minutes to dissipate the residual heat, turn off the AC and DC circuit breakers, and remove the cables.

----End

## 4 Site Requirements

## 4.1 Site Selection Requirements

#### NOTICE

Refer to the GB 51048 *Design code for electrochemical energy storage station*, NFPA 855 *Standard for the Installation of Stationary Energy Storage Systems*, and local laws and regulations.

The site selection requirements for the ESS are as follows:

- The ESS applies only to outdoor scenarios and must not be deployed indoors.
- The horizontal level of the installation site shall be above the highest water level of that area in history and at least 300 mm above the ground. The site must not be located in a low-lying land.
- No obstacle shall be above the ESS. For example, the ESS must not be installed under a parking shed and PV modules must not be installed on the top of the ESS.
- For safety purposes, keep safety distances between the ESS and surrounding buildings and facilities.
  - The distance between the ESS and residential buildings must be greater than or equal to 12 m, and the distance between the ESS and densely populated buildings such as schools and hospitals must be greater than 30.5 m.
  - The distance between the ESS and production buildings in commercial and industrial scenarios must be greater than or equal to 12 m. If the distance does not meet the requirement, fire walls shall be installed between the ESS and production buildings. The fire walls shall have a 3hour or higher fire resistance rating and shall extend 1.5 m above and 1.5 m beyond the physical boundary of the ESS. In addition, the clearance requirements for equipment transportation, installation, and maintenance shall be considered.
- There must be no vegetation, especially flammable plants within 3 m of the ESS or the site to protect the ESS from possible fires.

- It is recommended that outdoor open electrochemical energy storage plants be equipped with fences and walls. The external walls of an electrochemical energy storage plant deployed in a power plant or power transformation and distribution station shall be permitted to serve as the enclosure and isolation walls.
- The safety distances between the ESS and buildings shall comply with local fire protection regulations or standards.
- The ESS and the site must be in an environment free from explosion risks.
- Transportation to the site shall be convenient and fire suppression facilities shall be reliable.

#### 

- When installing, commissioning, and operating the ESS, ensure that at least two gas fire extinguishers are provided near each unit to ensure fire safety.
- The distance between the exhaust device of an ESS and the heating and ventilation vents, air intake vents of air conditioners, windows, doors, unloading platforms, and fire sources of other buildings or facilities must be greater than 4.6 m.
- Reserve sockets for the water fire suppression system at the ESS site.
- Outdoor fire hydrants shall be installed around the plant. The distance between fire hydrants shall be less than or equal to 60 m. The number of outdoor fire hydrants shall be calculated based on the flow rate and protection radius of fire hydrants. The maximum protection radius shall be less than or equal to 150 m, and the flow rate shall be greater than or equal to 15 L/s.
- The site area must meet the requirements and there shall be space for capacity expansion.
- The site shall be in a well-ventilated place.
- The ESS shall not be installed in salt-affected or polluted areas because this will cause corrosion. The ESS shall be used in the following or better environments:
  - Outdoor environment more than 2000 m away from the coast. You are advised not to use the ESS in an area 500 m to 2000 m away from the coast. (If you need to use it, confirm with the vendor or the Company's engineers.) Do not use the ESS in an area less than 500 m away from the coast.
  - More than 1500-3000 m away from heavy pollution sources such as smelteries, coal mines, and thermal power plants
  - More than 1000–2000 m away from medium pollution sources such as chemical, rubber, and electroplating industries
  - More than 500–1000 m away from light pollution sources such as packing houses, tanneries, boiler rooms, slaughterhouses, landfill sites, and sewage treatment plants

#### **Ⅲ** NOTE

You are advised to select another site if the safety distance for a site cannot meet the requirements of relevant national standards.

Do not select the sites that are not recommended by industry standards and regulations, including but not limited to the following areas:

 Areas with sources of strong vibration, loud noises, and strong electromagnetic interference

- Areas with dust, oil fumes, harmful gases, corrosive gases, etc.
- Areas with corrosive, flammable, and explosive materials
- Areas with existing underground facilities
- Areas with adverse geological conditions such as rubbery soil and soft soil layer, or prone to waterlogging and land subsidence
- Under a reservoir, water landscape, and water room

#### **◯** NOTE

- If areas prone to waterlogging cannot be avoided, install water blocking and drainage facilities or raise the ground.
- Cable trenches shall not be used for drainage. Fire retardant sealing shall be implemented at cable holes (such as holes through partition walls and floors).
- Areas prone to earthquakes and with seismic fortification intensity higher than 9
- Areas prone to debris flow, landslide, quicksand, karst caves, and other direct hazards
- Areas within the mining land subsidence (dislocation) zone
- Areas within the scope of blasting hazard
- Areas prone to flood due to a dam or levee failure
- Protection areas for important water supply sources
- Protection areas for historic relics
- Populated areas, high-rise buildings, and underground buildings
- Intersections and busy roads of urban main roads

Requirements for flood and waterlogging prevention in site selection:

- The site design elevation of a large-scale electrochemical energy storage system (power ≥ 100 MW) shall be higher than the flood level with a probability of 1% or the historical highest waterlogging level.
- The site design elevation of a medium- or small-scale electrochemical energy storage system (power < 100 MW) shall be higher than the flood level with a probability of 2% or the historical highest waterlogging level.
- If the site design elevation cannot meet the preceding requirements, change the site location or take different flood and waterlogging prevention measures based on the site requirements.
- For energy storage plants prone to wind and waves from rivers, lakes, and seas, the elevation of flood prevention facilities shall consider the wind and wave height with a probability of 2% and an additional safety height of 0.5 m.
- When a large amount of catchment water flows into or passes through the site, it is recommended that side ditches or drainage ditches be built to drain water from the ground in an organized manner.

#### Security fencing:

It is recommended that physical walls or fences be used for isolation and protection in the energy storage equipment area. The fences shall be equipped with a door lock and the recommended fence height is greater than 2.2 m. Fire walls shall be permitted to be substituted for part or all of the fences, depending on the actual design plans.

## **4.2 Clearance Requirements**

Clearance must be reserved for installation and O&M, as required in the following:

• Reserve at least 3000 mm clearance on the long sides and the control unit cabin side of the ESS, respectively.

#### 

If the preceding safety distance requirements cannot be met, install fire walls between the ESSs. Ensure that the length and height of the fire walls extending above and beyond the physical boundary of the ESS installation meet the requirements in section "Site Selection Requirements".

- Set up a maintenance aisle around or on one side of the container. The net width of the aisle shall be no less than 1200 mm.
- The preceding clearance requirements are for reference only in terms of installation and O&M. The clearances must also comply with local fire control requirements.

## 4.3 Foundation Requirements

#### □ NOTE

The foundation layout design should meet the space requirements for ESS installation and O&M. The design institute can contact local Huawei pre-sales engineers to obtain the drawings about the foundation.

Before installation, build a concrete platform and trenches on the selected ground. The foundation construction requirements are as follows:


- The dimensions of the foundation should meet the installation and bearing requirements of the equipment.
- The foundation must be above the highest water level of the local area in history and at least 300 mm above the ground.
- The average foundation strength should exceed 100 kg/cm<sup>2</sup>.
- The horizontal error between the foundation and the contact surface of the equipment should be less than 5 mm.
- The resistance of a bond should be less than or equal to 0.1 ohms.
- The ESS uses bottom cabling. Cables need to be pre-buried under the control unit cabin.
- The inner diameter of the protective tube should not be less than 1.5 times of the outer diameter of the cable (including the protective layer).
- Construct drainage facilities based on the local geological conditions and municipal drainage requirements to ensure that no water will accumulate at the equipment foundation. The foundation should meet the local drainage requirements for the local historical maximum rainfall. Drained water should be disposed of in accordance with local laws and regulations.
- After the foundation is excavated, prevent water from entering the foundation. If water enters the foundation, excavate and refill the affected parts.

• A cable trench (if any) cannot be used for drainage. Fire retardant sealing should be implemented at cable holes (such as holes through partition walls and floors).

#### **Check Item**

| No. | Check Item                  | Acceptance Criteria  |  |
|-----|-----------------------------|--|--|
| 1   | Cabling space at the bottom | • If there is no maintenance space at the bottom, it is recommended that the cabling space at the bottom of the container be no less than 1.1 m. |  |
|     |                             | • If there is maintenance space at the bottom, it is recommended that the cabling space at the bottom of the container be no less than 1.3 m.    |  |
| 2   | Cable                       | The bending radius of the cables is not less than 15 times the cable diameter.   |  |
|     |                             | <ul> <li>The voltage drop of the farthest loop does not<br/>exceed 5%.</li> </ul>  |  |
|     |                             | <ul> <li>The sensitivity, voltage level, and thermal stability of<br/>the cables meet the local design specifications.</li> </ul>                |  |

Figure 4-1 Diagram of foundation



# 5 Installation

## **5.1 Installation Preparations**

## **5.1.1 Preparing Tools**


#### □ NOTE

- The tools shown in the figures are for reference only.
- The tool table may not list out some tools required onsite. Onsite installation personnel and the customer need to prepare the tools based on site requirements.

#### **Installation Tools**



Tools such as socket wrenches, torque wrenches, and screwdrivers must be insulated tools.



|  |                      |                         | A long   |
|--|----------------------|-------------------------|--|
| Flat-head insulated torque screwdriver | Wire strippers       | Diagonal pliers         | Utility knife                                  |
| Cable cutter                           | RJ45 crimping tool   |                         |  |
|  |                      | Vacuum cleaner          | Multimeter                                     |
|  |                      |                         | DC voltage<br>measurement<br>range ≥ 1500 V DC |
| ₫                                      |                      | <u>~</u>                |  |
| Marker                                 | Steel measuring tape | Digital or bubble level | Hydraulic pliers                               |
|  |                      |                         |  |
| Heat-shrink tubing                     | Heat gun             | Cable tie               | Insulation ladder                              |

| Crane                       | Hoisting rope and lifting eye | Rubber mallet | Hammer drill |
|-----------------------------|-------------------------------|---------------|--------------|
|                             | -                             | -             | -            |
|                             |                               |               |              |
| Drill bit (φ14/φ16/<br>φ20) |                               |               |              |

## Personal Protective Equipment (PPE)

|  | and the second    |                |                |
|--|-------------------|----------------|----------------|
| Insulated gloves   | Protective gloves | Safety goggles | Dust mask      |
| Call Control of the C |                   |                |                |
| Safety shoes   | Reflective vest   | Safety helmet  | Safety harness |
|  | -                 | -              | -              |
| Medical kit  |                   |                |                |

#### 5.1.2 Installation Environment Check

Check the site requirements one by one, and start installation only after all requirements are met. The Company will not be liable for any consequences in the case that the installation environment does not meet the requirements.

#### NOTICE

Mark the safe zone: Use red caution belts to delimit a safe zone, clean up obstacles in the safe zone, and place construction signs and warning signs in prominent positions.

## 5.2 Unpacking and Acceptance

#### **NOTICE**

- After placing the equipment in the installation position, unpack it with care to prevent scratches. Keep the equipment stable during unpacking.
- After unpacking, check whether the fastening components and removable components are loose. If they are loose, notify the carrier and manufacturer immediately.
- The blue adhesive plastic film on the outdoor air conditioner unit of the ESS is used to prevent foreign objects from entering the air conditioner unit during storage. Do not remove the blue adhesive plastic film during storage. Remove the blue adhesive plastic film before power-on and commissioning.

## 5.3 Installing the ESS

## 5.3.1 Determining the Installation Position of the ESS

#### **Prerequisites**

- The site requirements are met.
- Check and adjust the height of the concrete platforms to ensure that the height difference between the upper surfaces of all platforms does not exceed 5 mm.

#### **NOTICE**

Ensure that the concrete platforms meet requirements.

 Determine the installation position and orientation of the ESS based on site conditions.

#### **Procedure**

- **Step 1** Determine the reference points for installing the ESS on the concrete platforms. Mark the reference points using a marker.
- **Step 2** On the basis of the reference points, mark the mounting positions for the four corner fittings of the ESS using an ink fountain and a long soft measure tape.

#### **NOTICE**

When marking the positions for corner fittings, ensure that the four lines form a rectangle.

Foundation

Foundation

B04W00103

----End

## 5.3.2 Hoisting the ESS

#### **Prerequisites**

- Before installing the equipment, check the ESS for damage, such as holes and cracks, and check the equipment model. If the appearance is abnormal or the equipment model is incorrect, contact your dealer.
- Before hoisting, ensure that the crane and hoisting ropes meet the loadbearing requirements.
- The steel hoisting ropes are available.
- An appropriate crane is selected based on standards of the crane company and assessed by professionals onsite.
- The doors of the ESS to be hoisted have been closed.
- It is recommended that the ESS be hoisted outdoors when the weather is clear and there is no wind.

• When installing or removing the hoisting equipment, do not drag it on the ESS to prevent scratches.

## **Hoisting Precautions**

**Table 5-1** Hoisting precautions

| Stage           | Precautions   |  |
|-----------------|---|--|
| Before hoisting | Ensure that the crane can hoist a load greater than 50 t, and the working radius is not less than 10 m. If the onsite environment does not meet the required working conditions, ask a professional to assess the conditions. |  |
|                 | Only trained and qualified personnel should perform hoisting operations.  |  |
|                 | Check that hoisting tools are complete and in good condition.   |  |
|                 | Ensure that the hoisting tools are secured to a load-bearing object or wall.  |  |
|                 | Ensure that the crane and steel hoisting ropes provide the required bearing capacity.   |  |
|                 | All doors of the ESS should be locked.  |  |
|                 | Ensure that the steel hoisting ropes are securely connecte  |  |
|                 | It is recommended that the ESS be hoisted from left to right or from right to left to ensure successful hoisting.   |  |
| During hoisting | Do not allow any unauthorized person to enter the hazardous areas and do not stand under the crane arm.   |  |
|                 | Ensure that the crane is properly located and avoid long-distance hoisting.   |  |
|                 | Ensure that the ESS is stable and the diagonal gradient of the ESS is less than or equal to 5 degrees.  |  |
|                 | Ensure that the angle between two ropes is less than or equal to 90°.   |  |
|                 | Lift and land the ESS slowly to prevent shock to the devices inside it.   |  |
|                 | Remove the steel ropes after ensuring that the ESS is placed evenly on the concrete platforms.  |  |
|                 | Do not drag steel ropes and hoisting tools or bump hoisted objects against hard objects during hoisting.  |  |

#### ■ NOTE

- You are advised to level concrete platforms before hoisting the ESS.
- The horizontal error of concrete platforms cannot exceed 5 mm.
- Prepare and install the lifting eyes and steel ropes.


#### **Procedure**

**Step 1** Connect hoisting ropes, and hoist the ESS onto the concrete platforms.

#### **NOTICE**

The requirements of distances between the corner of the ESS and the edge of the foundation are the same for the four corners of the ESS. The figure uses one of the corners as an example.

Figure 5-2 Hoisting the ESS



**Step 2** Cut open the protective cover using a utility knife and remove the protective cover.

#### **↑** WARNING

- When removing the protective cover, take protective measures for working at heights.
- Do not remove the protective cover in bad weather conditions such as rain and snow.

#### ----End

## 5.3.3 Opening the Doors of the ESS




Do not open the container door in rainy, snowy, lightning, or dusty weather conditions.

#### **Procedure**

**Step 1** Use a cable cutter to cut off the TSA approved lock on the door of the control unit cabin.

Figure 5-3 Position of safety lock and TSA approved lock



**Step 2** Open the door, take the key from the control unit cabin, and use the key to open the safety lock.





Figure 5-4 Open the door of the control unit cabin

(1) Position of keys

**Step 3** Use the key to open the safety locks on the right handle of the battery cabin, and then open the doors of the battery cabin.

#### ■ NOTE

- At least two persons are required to open the door.
- After the door is opened, secure it using a door strut to prevent the door from moving.



**Step 4** Obtain the packing list and the quick guide. Check the materials against the packing list.

#### **◯** NOTE

- Lock the doors promptly and store the keys properly under the management of dedicated personnel.
- If any materials are missing, contact Huawei technical support.

#### ----End

## 5.3.4 Grounding the ESS

#### **Prerequisites**

#### **↑** WARNING

Do not connect devices such as fuses and switches to ground cables.

## **CAUTION**

The grounding should comply with the local electrical safety regulations.

- The ESS is installed.
- The grounding requirements are clear.

#### Context

The requirements of ground cable are as follows:

Table 5-2 Ground cable description

| Cable        | Туре   | Cross-<br>Sectional<br>Area | Outer<br>Diameter | Source                      |
|--------------|--|-----------------------------|-------------------|-----------------------------|
| Ground cable | Single-core<br>outdoor<br>copper cable<br>and M10,<br>M12 OT/DT<br>terminals | 16–95 mm <sup>2</sup>       | 10-32 mm          | Prepared by<br>the customer |

The specifications of the ground cable are subject to this table or calculated according to IEC 60364-5-54.

#### **Connect Ground Cables**

**Step 1** Connect the main ground bar of the control unit cabin.

#### NOTICE

- The ground cable of the main ground bar in the control unit cabin must be connected.
- After connecting the ground cable of the main ground bar in the control unit cabin, close the cabin door in time.





Figure 5-5 Position of the ground cable hole and pagoda connector cutting



(1) Ground cable hole

#### 

The position for cutting the pagoda connector is for reference only. The actual cable usage may vary.

- **Step 2** (Optional) Connect ground cables/ground lugs to the ground points of the ESS enclosure.
  - Connect ground cables to the ground points of the ESS using M12x30 stainless steel bolt assemblies. The ground cables can be routed through plastic-coated metal hoses based on site requirements.

M12 47 N·m

90

1804H50001

Figure 5-6 Installing ground cables

 Connect ground lugs to the ESS ground points using M12x30 stainless steel bolt assemblies.

#### □ NOTE

- Ground lug: Use ground lugs made of hot-dip zinc-coated flat steel sheet with a cross-sectional area of 40 mm x 4 mm, and leave 300 mm of each ground lug out of the concrete platform (same as the height between the foundation and the ground).
- Before the installation, remove the tinfoil from the ground lugs.




Figure 5-7 Installing ground lugs

----End

## 5.3.5 Securing the ESS

**Step 1** Open the door of the control unit cabin to get the angle steels in the carton. Secure the ESS using four angle steels.


#### **!** CAUTION

- Place a wooden block on the top of an expansion bolt, and then knock at the wooden block using a claw hammer to avoid damaging the expansion bolt.
- Ensure that the expansion bolts are tightened when securing the angle steel to the base.

#### ■ NOTE

- There are four mounting holes where angle steel brackets contact the base. Mark all mounting holes.
- Each angle steel bracket must be secured by two mounting holes. It is recommended that the outer two mounting holes be used. If steel bars in a concrete base block the drill bit or when the position deviation occurs during the first drilling, use the inner mounting holes.

Figure 5-8 Securing the ESS



----End

#### Follow-up Procedure

After the ESS is installed, verify the installation to ensure normal use of products and smooth subsequent installation.

**Table 5-3** Verifying the installation

| No. | Check Item  | Check Method  | Criteria   |
|-----|---|---|--|
| 1   | Bolts and nuts  | Tighten the bolts and nuts again using a wrench with the same torque. | Bolts and nuts are tightened.                                    |
| 2   | Check whether the doors of<br>the ESS can be opened and<br>closed properly. | Open and close<br>the doors of the<br>ESS.                            | All doors of the<br>ESS can be<br>opened and<br>closed properly. |

#### □ NOTE

If the doors of the ESS cannot be opened and closed properly, please refer to the first question in chapter 11, 'How do I Level the ESS When Doors Cannot Be Opened or Closed'.

## **5.4 Installing Components**

## **CAUTION**

- Ensure that the ESS is not powered on.
- The installation personnel have taken safety protection measures, for example, wearing insulated gloves and shoes.

## 5.4.1 Installing Copper Bars Between Battery Packs

## **Prerequisites**

The battery cabin door is open.

#### **Procedure**

**Step 1** Take out the copper bars from the battery cabin.





Figure 5-9 Positions of the copper bars


(1) Desiccan (Montmorillonite desiccant, 500 (2) Copper bar g)

#### **◯** NOTE

- There are 25 desiccant bags, four bags for each battery rack in the battery cabin and one bag for the control unit cabin.
- After cables are connected, do not remove the desiccants before power-on.
- If the ESS has been stored for more than six months, replace them with new ones (Montmorillonite desiccant, 500 g).

**Step 2** Press and open the battery pack cover on the right side.





**Step 3** Wear insulation gloves and install copper bars between battery packs.

#### **CAUTION**

When installing copper bar C, keep away from communications cables and fan power cables of battery packs to prevent cables from being squeezed.

#### NOTICE

- Use the copper bars delivered with the ESS. Do not use copper bars from ESSs of different models.
- When installing a nut, manually insert the nut into the screw plate, and then
  use a socket wrench to completely secure the nut in place. This prevents the
  screw thread from being stuck or stripped due to the deviation of the nut
  position.
- Pre-install nuts according to the recommended torque of 27 N·m.
- Verify the torque of the installed nuts using a torque wrench set to 27 N·m.
- Mark the nuts whose torque has been verified using a marker.
- Use an extension rod for the torque wrench.

#### ■ NOTE

Three types of copper bars are included with the equipment and are identified by the silkscreens A, B, and C printed on the front.




Figure 5-11 Installing copper bars between battery packs

#### **MOTE**

For some models, each battery rack contains only 19 battery packs. Install copper bars by referring to the following figure.




Figure 5-12 Installing copper bars between battery packs

- **Step 4** Close the battery pack cover.
- **Step 5** Close the battery cabin door.

----End

## 5.4.2 (Optional) Filling the Fire Cylinder with Extinguishant

#### **CAUTION**

- This document does not provide details about how to fill the fire cylinder with extinguishant. Perform this operation in a dedicated station.
- Protect the fire cylinder from collision during transportation and installation.

#### **NOTE**

This step applies only to some models.

- **Step 1** Remove the hose active connector from the ESS piping using a torque wrench.
- **Step 2** (Optional) Remove the extinguishant release hose from the high-pressure elbow using a torque wrench.
- **Step 3** (Optional) Remove the high-pressure elbow from the changeable-diameter joint using a torque wrench.

#### ■ NOTE

- If there is no changeable-diameter joint, remove the high-pressure elbow directly from the fire cylinder.
- If there is no changeable-diameter joint and high-pressure elbow, remove the extinguishant release hose directly from the fire cylinder.
- **Step 4** (Optional) Remove the changeable-diameter joint from the release vent using a torque wrench.

#### □ NOTE

If there is no changeable-diameter joint on the fire cylinder, skip this step.

- **Step 5** Install the safety cap of the release vent.
- **Step 6** Remove the fire cylinder from the bracket.




Figure 5-13 Removal process diagram

**Step 7** Fill the fire cylinder with extinguishant.

**Table 5-4** Requirements

| Technical Specifications                     | Values   |                   |
|--|--|-------------------|
| Extinguishant                                | Heptafluoropropane   | Perfluorohexanone |
| Extinguishant weight                         | 26-27 kg   | 31–32 kg          |
| Purity requirement                           | ≥ 99.9%  |                   |
| Fire cylinder pressure (by filling nitrogen) | Refer to the table Pressure requirements under different ambient temperatures. |                   |

**Table 5-5** Pressure requirements under different ambient temperatures

| Ambient<br>Temperature<br>(℃) | Pressure<br>(Bar) of<br>227M38UFAA | Pressure<br>(Bar) of<br>SPS020-<br>MS-032B-EN | Pressure<br>(Bar) of<br>P0009438 | Pressure<br>(Bar) of<br>NCM38UFAA |
|-------------------------------|------------------------------------|---|----------------------------------|-----------------------------------|
| 0                             | 20.2                               | 16.92   | 22.1                             | 20.2                              |
| 5                             | 21.4                               | 18.85   | 22.8                             | 21.4                              |
| 10                            | 22.6                               | 20.77   | 23.5                             | 22.6                              |
| 15                            | 23.8                               | 22.69   | 24.3                             | 23.8                              |
| 20                            | 25.0                               | 24.62   | 25                               | 25                                |

| Ambient<br>Temperature<br>(℃) | Pressure<br>(Bar) of<br>227M38UFAA | Pressure<br>(Bar) of<br>SPS020-<br>MS-032B-EN | Pressure<br>(Bar) of<br>P0009438 | Pressure<br>(Bar) of<br>NCM38UFAA |
|-------------------------------|------------------------------------|---|----------------------------------|-----------------------------------|
| 25                            | 26.2                               | 26.54   | 25.8                             | 26.2                              |
| 30                            | 27.4                               | 28.46   | 26.5                             | 27.4                              |
| 35                            | 28.6                               | 30.38   | 27.3                             | 28.6                              |
| 40                            | 29.8                               | 32.31   | 28.1                             | 29.8                              |
| 45                            | 31.0                               | 34.23   | 28.8                             | 31                                |
| 50                            | 32.2                               | 36.15   | 29.5                             | 32.2                              |

Note: The actual cylinder pressure should not be lower than 90% of the specified pressure at the corresponding ambient temperature.

- **Step 8** Install the fire cylinder.
- **Step 9** Remove the safety cap of the release vent.
- **Step 10** (Optional) Install the changeable-diameter joint to the release vent using a torque wrench.
- **Step 11** (Optional) Wrap eight turns of sealing tape around the external threads of the changeable-diameter joint, and install the high-pressure elbow to the changeable-diameter joint using a torque wrench.
- **Step 12** (Optional) Wrap eight turns of sealing tape around the external thread connector of the extinguishant release hose and install the extinguishant release hose to the high-pressure elbow using a torque wrench.

#### ■ NOTE

- Remove any old sealing tape from the threads.
- If there is no changeable-diameter joint, install the high-pressure elbow directly to the fire cylinder.
- If there is no changeable-diameter joint and high-pressure elbow, install the extinguishant release hose to the fire cylinder.
- **Step 13** Place the white gasket in the nut end of the extinguishant release hose and install the hose active connector to the ESS piping using a torque wrench.




Figure 5-14 Installation process diagram

----End

## 5.4.3 Installing the Battery in the Extinguishant Control Panel

## **Prerequisites**

#### NOTICE

- The extinguishant control panel has been configured and commissioned before delivery. Non-professional personnel are prohibited from configuring the extinguishant control panel without permission.
- Non-professional personnel are prohibited from operating the Write Enabler button.
- You are advised to power on the battery within 24 hours after unpacking. If the battery cannot be powered on in time, place it in a dry indoor environment without corrosive gases.

#### □ NOTE

- The battery is delivered with the product and can be obtained from the control unit cabin. If it needs to be replaced, purchase a battery according to the specifications in **2.6.4.4 Extinguishant Control Panel**.
- If a battery is damaged, contact your local office.
- Determine the position of the extinguishant control panel.




Figure 5-15 Position of the extinguishant control panel

(1) Position of keys

(2) Position of the extinguishant control panel

#### **Procedure**

#### **♠** CAUTION

- Do not damage components in the extinguishant control panel during the installation.
- If the power supply is disconnected, restore the power supply to the extinguishant control panel as soon as possible to prevent battery failure.

#### Model: JB-QBL-QM210



If the extinguishant control panel has been powered off for more than 24 hours, the battery switch in the extinguishant control panel must be turned off. Otherwise, the battery may be overdischarged and needs to be replaced.

- a. Remove the key from above the extinguishant control panel.
- b. Open the extinguishant control panel and remove the cover for installing the battery.
- c. Install the battery and cover in the extinguishant control panel.
- d. Connect battery cables to the extinguishant control panel.




Figure 5-16 Installing the battery in the extinguishant control panel

IB04I10001

- e. Close the extinguishant control panel.
- f. Remove the key from the extinguishant control panel.
  - □ NOTE

Hand over the key to the responsible personnel for safekeeping.

Model: K11031M2

## **CAUTION**

If the extinguishant control panel has been powered off for more than 24 hours, cables between the extinguishant control panel and the battery must be disconnected. Otherwise, the battery may be overdischarged and needs to be replaced.

- a. Remove the key from above the extinguishant control panel and open the extinguishant control panel.
- b. Cut off the cable ties from battery cables on the main board of the extinguishant control panel.
- c. Connect battery cables to the extinguishant control panel.




Figure 5-17 Installing the battery in the extinguishant control panel

- d. Close the extinguishant control panel.
- e. Remove the key from the extinguishant control panel.

#### **◯** NOTE

Hand over the key to the responsible personnel for safekeeping.

# 6 Installing Cables

#### **DANGER**

- Do not smoke or have an open flame around batteries.
- The site must be equipped with qualified fire fighting facilities, such as fire sand and carbon dioxide fire extinguishers.
- Wear personal protective equipment and use dedicated insulated tools to avoid electric shocks or short circuits.

#### **CAUTION**

- Do not connect two or more cables to the positive or negative power port of a battery in parallel.
- Stay away from the equipment when preparing cables to prevent cable scraps from entering the equipment. Cable scraps may cause sparks and result in personal injury and equipment damage.

# 6.1 Preparing Cables

## **CAUTION**

Select cables in compliance with local cable standards, especially the electrical specifications and application environment. The key factors include the rated current, cable type, routing method, maximum expected line loss, rated temperature, ambient temperature, thermal resistance, acidity, sedimentation, and environmental protection requirements.

Table 6-1 Cable description

| No. | Cable   | Туре   | Conductor Cross-<br>Sectional Area Range   | Outer<br>Diameter | Termin<br>al  | Source                         |
|-----|---|--|--|-------------------|---|--------------------------------|
| 1   | DC<br>power<br>cable  | Two-core<br>outdoor copper/<br>copper-clad<br>aluminum/<br>aluminum alloy<br>cable             | LUNA2000-2.0MWH-1<br>HX: 240-400 mm <sup>2</sup>   | 25-68 mm          | M12<br>OT/DT<br>termina<br>l  | Prepared<br>by the<br>customer |
|     |   |  | LUNA2000-2.0MWH-2<br>HX/<br>LUNA2000-2.0MWH-<br>HE2HX:  • 6 circuit breakers:<br>70–185 mm <sup>2</sup> • 3 circuit breakers:<br>240–400 mm <sup>2</sup> |                   |   |                                |
|     |   | Single-core<br>outdoor copper/<br>copper-clad<br>aluminum/<br>aluminum alloy<br>cable          | LUNA2000-2.0MWH-1<br>HX: 185–400 mm <sup>2</sup>   | 25–47 mm          |   |                                |
|     |   |  | LUNA2000-2.0MWH-2<br>HX/<br>LUNA2000-2.0MWH-<br>HE2HX: • 6 circuit breakers:<br>50–185 mm <sup>2</sup> • 3 circuit breakers:<br>185–400 mm <sup>2</sup>  |                   |   |                                |
| 2   | AC input power cable (with external grid power supply)  | Four-core/Five-<br>core outdoor<br>copper/copper-<br>clad aluminum/<br>aluminum alloy<br>cable | LUNA2000-2.0MWH-1<br>HX: 35–185 mm <sup>2</sup>  | 24.6–72 mm        | M10<br>OT/DT<br>termina<br>l  | Prepared<br>by the<br>customer |
|     |   |  | LUNA2000-2.0MWH-2<br>HX/<br>LUNA2000-2.0MWH-<br>HE2HX:<br>• 6 circuit breakers:  |                   |   |                                |
|     |   |  | 10–185 mm <sup>2</sup> • 3 circuit breakers:   |                   |   |                                |
|     |   |  | 35–185 mm <sup>2</sup>   |                   |   |                                |
| 3   | Single-<br>phase<br>AC<br>Input<br>Power<br>Cable<br>(without<br>external<br>grid<br>power<br>supply) | Two-core/Three-<br>core outdoor<br>copper cable  | 1.5–10 mm <sup>2</sup>   | 5-32 mm           | Pin<br>cord<br>end<br>termina<br>l with<br>an<br>insertio<br>n depth<br>of 14<br>mm | Prepared<br>by the<br>customer |

| No. | Cable                              | Туре  | Conductor Cross-<br>Sectional Area Range | Outer<br>Diameter | Termin<br>al                       | Source                         |
|-----|------------------------------------|---|--|-------------------|------------------------------------|--------------------------------|
| 4   | FE<br>commu<br>nication<br>s cable | CAT 5E outdoor<br>shielded network<br>cable, internal<br>resistance ≤ 1.5<br>ohms/10 m                      | -  | < 9 mm            | Shielde<br>d RJ45<br>connect<br>or | Prepared<br>by the<br>customer |
| 5   | Optical cable                      | Supports the four-core or eight-core single-mode armored cable with the transmission wavelength of 1310 nm. | -  | ≤ 18 mm           | -                                  | Prepared<br>by the<br>customer |

**Figure 6-1** LUNA2000-2.0MWH-2HX/LUNA2000-2.0MWH-HE2HX (6 circuit breakers)





Figure 6-2 LUNA2000-2.0MWH-2HX(3 circuit breakers)



# **6.2 Connecting Socket Circuit Wires**

#### Scenario 1


This procedure applies only to the models listed in the table below.

| Models  | Air Conditioner Position in the Battery Cabin |
|---|---|
| LUNA2000-2.0MWH-1HX                           | 1/3/5/7/9/11                                  |
| LUNA2000-2.0MWH-2HX/<br>LUNA2000-2.0MWH-HE2HX | 1/4/7/10                                      |

#### □ NOTE

- Cables 1733, 1735, 1734 and 1736 are pre-installed. Cables 1751, 1752, 1757, 1760, 2055, 2056, 1761 and 1762 need to be installed.
- The cables to be installed can be obtained from the cable binding position shown in the figure before installing the socket.

Figure 6-3 Before installing the socket



- (1) Cable binding position
- **Step 1** Select a 110 V or 220 V socket as required.
- **Step 2** Connect the live wire and neutral wire.
  - Installing a 110 V socket
    - a. Connect the live wire and neutral wire from the mains to positions 1 and 2 of the XT9 terminal block.





Figure 6-4 Connecting the live wire and neutral wire from the mains

(1) 110 V/220 V socket installing position

- b. Install the 110 V switch.
- c. Connect the live wire (corresponding to cable 2056) and neutral wire (corresponding to cable 2055) from the upper end of the switch to positions 1 and 2 of the XT9 terminal block. Connect the live wire (corresponding to cable 1751) and neutral wire (corresponding to cable 1752) from the lower end of the switch to the socket.


Figure 6-5 Connecting live wires and neutral wires



(1) 110 V switch installing position

#### • Installing a 220 V socket

a. Connect the live wires (corresponding to cables 1757) and neutral wires (corresponding to cables 1760) from the lower end of the terminal block to the socket.



**Step 3** Connecting ground cables: Determine whether the socket ground cables are routed in from the top or bottom.

#### □ NOTE

Step 3 applies to the scenarios where a 220 V or 110 V socket is installed. The following figure uses a 220 V socket as an example.

• If cables are routed in from the top of the socket, the cables (1761) are connected to the ground points. Remove the other end of the cables from the rear panel and connect them to the ground points of the socket.

Figure 6-6 Routing the ground cables in from the top

• If cables are routed in from the bottom of the socket, connect one end of the cables (1762) to the ground points of the socket and the other end to the reserved ground points on the rear panel.

1761 1804H00166

Figure 6-7 Routing the ground cables in from the bottom

----End


#### Scenario 2

This procedure applies only to the models listed in the table below.

| Models              | Air Conditioner Position in the Battery Cabin |
|---------------------|---|
| LUNA2000-2.0MWH-1HX | 1/2/4/5/7/8/10/11                             |
| LUNA2000-2.0MWH-2HX | 1/3/5/7/9/11                                  |
| LUNA2000-2.0MWH-2HX | 2/4/6/8/10/12                                 |

#### □ NOTE

- Cables 1755, 1758, 2066, 2065, 1761, and 1766 are pre-installed. Cables 1756, 1751, 1759, 1752, 1757, 1763, 1760, 1765, 1762, and 1764 need to be installed.
- The cables to be installed can be obtained from the cable binding position shown in the figure before installing the socket.




**Figure 6-8** Before installing the socket

(1) Cable binding position

- **Step 1** Select a 110 V or 220 V socket as required.
- **Step 2** Connect the live wire and neutral wire.
  - Installing a 110 V socket
    - a. Connect the live wire and neutral wire from the mains to positions 1 and 2 of the XT9 terminal block.

Figure 6-9 Connecting the live wire and neutral wire from the mains



b. Connect the live wire (corresponding to cable 1751) and neutral wire (corresponding to cable 1752) from the lower end of the switch to positions 1 and 3 of the XT1 terminal block.

9 9 9 9


Figure 6-10 Connecting the live wire and neutral wire from the lower end of the switch

IB04H000146

#### Installing a 220 V socket

Connect the live wire (corresponding to cable 1756) and neutral wire (corresponding to cable 1759) from the lower end of the switch to positions 1 and 3 of the XT1 terminal block.

Figure 6-11 Connecting the live wire and neutral wire from the lower end of the switch




**Step 3** Connect the live wires (corresponding to cables 1757 and 1763) and neutral wires (corresponding to cables 1760 and 1765) from the lower end of the terminal block to the socket.

#### **Ⅲ** NOTE


Steps 3 and 4 apply to the scenarios where a 220 V or 110 V socket is installed. The following figure uses a 220 V socket as an example.

**Figure 6-12** Connecting the live wires and neutral wires from the lower end of the terminal block



- **Step 4** Connecting ground cables: Determine whether the socket ground cables are routed in from the top or bottom.
  - If cables are routed in from the top of the socket, the ground cables (1761 and 1766) are connected. Remove the cables bound to the rear panel and connect the other end to the grounding points of the socket.

Figure 6-13 Routing the ground cables in from the top



• If cables are routed in from the bottom of the socket, connect one end of the cables (1762 and 1764) to the ground points of the socket and the other end to the reserved ground points on the rear panel.




Figure 6-14 Routing the ground cables in from the bottom

----End

# **6.3 Installing DC Power Cables**


#### **Prerequisites**

- The ESS is not powered on.
- The DC power cables have been pre-buried according to the specifications.
- The OT/DT terminals have been crimped according to the specifications. For details, see C Crimping an OT or DT Terminal.

#### **Procedure**


**Step 1** Remove the protective cover

Figure 6-15 Removing the protective cover



**Step 2** Remove the baffle plates for the DC power cables.





**Step 3** Connect the DC power cables.

#### **NOTICE**

- The screw assembly whose model is subject to the delivery should be tightened according to the corresponding standard torque.
- Partially tighten the nuts of the DC power cables to a torque of 5 N·m when securing the cables.
- The wiring terminal must be installed with heat-shrink tubing at the crimping area of the cable conductor to ensure that the electrical clearance between the conductors is greater than 20 mm.
- Lay out the DC power cables according to the design, route the cables to the wiring positions on the corresponding switches, and label the cables.

#### ■ NOTE

- Tighten the nuts using the socket wrench with an extension rod. The length of the extension rod is greater than 30 cm. Secure the screw assembly using an adjustable wrench.
- After connecting the DC power cables, ensure that the OT terminals are properly attached to and aligned with the copper bar, and that the DC power cables point vertically downwards.

IB04W00002

Figure 6-17 DC power cable positions at the bottom

(1) DC power cable hole

- (2) AC input power cable or ground cable hole
- (3) Optical cable or FE communications cable (4) UPS or RS485 cable hole (reserved) hole

#### **NOTICE**

- Pre-install nuts according to the recommended torque of 47 N·m.
- Verify that the torque of the installed bolts is 47 N·m using a torque wrench.
- Mark the nuts whose torque has been verified using a marker.
- Verify the torque promptly after connecting the negative DC power cables, and then connect the positive DC power cables.

#### **Ⅲ** NOTE

When armored cables are used, it is recommended that the armored layer be grounded at the opposite side.

E 15 mm

D 25 35 mm

D 35 -45 mm

D 45 -50 mm

Sealing

Mud


A7 N·m

R > 15xD

DC LV Panel

Figure 6-18 Connect the single-core DC power cables of LUNA2000-2.0MWH-1HX

**Figure 6-19** Connect the single-core DC power cables of LUNA2000-2.0MWH-2HX/LUNA2000-2.0MWH-HE2HX



- (1) Screw assembly
- (2) Spring washer
- (3) Large washer (optional)

- (4) Wiring terminals
- (5) Copper bar
- (6) Flat washer





Figure 6-20 Connect the single-core DC power cables of LUNA2000-2.0MWH-1HX


**Figure 6-21** Connecting two-core DC power cables of LUNA2000-2.0MWH-2HX/LUNA2000-2.0MWH-HE2HX



- (1) Screw assembly
- (2) Spring washer
- (3) Large washer (optional)

- (4) Wiring terminals
- (5) Copper bar
- (6) Flat washer

**Step 4** Install the removed cover.



6.4 Installing AC Input Power Cables (With External Grid Power Supply)

#### **Prerequisites**

- The ESS is not powered on.
- AC input power cables have been pre-buried according to the specifications.
- The OT/DT terminals of the AC input power cables have been crimped according to the specifications. For details, see C Crimping an OT or DT Terminal.

#### **Procedure**

Step 1 Remove the protective cover.





Figure 6-22 Removing the protective cover

**Step 2** Remove the baffle plates for the AC input power cables.

Figure 6-23 Removing the baffle plates for the AC input power cables



**Step 3** Connect AC input power cables.


## **<u>A</u>** CAUTION

When connecting AC input power cables, ensure that the cables are not damaged or disconnected. Ensure that the neutral wire is securely connected. Otherwise, AC power devices in the system may be damaged.

#### **NOTICE**

- The screw assembly whose model is subject to the delivery should be tightened according to the corresponding standard torque.
- Partially tighten the nuts of the AC input power cables to a torque of 5 N·m when securing the cables.
- The wiring terminal must be installed with heat-shrink tubing at the crimping area of the cable conductor to ensure that the electrical clearance between the conductors is greater than 20 mm.
- Lay out the AC input power cables according to the design, route the cable to the wiring positions on the corresponding switches, and label the cables.
- After connecting the DC power cables, ensure that the OT terminals are properly attached to and aligned with the copper bar, and that the DC power cables point vertically downwards.

Figure 6-24 AC input power cable positions at the bottom



(1) DC power cable hole

- (2) AC input power cable or ground cable hole
- hole
- (3) Optical cable or FE communications cable (4) UPS or RS485 cable hole (reserved)

#### NOTICE

- 1. Pre-install nuts according to the recommended torque of 27 N·m.
- 2. Verify that the torque of the installed bolts is 27 N·m using a torque wrench.
- 3. Mark the nuts whose torque has been verified using a marker.

D: <25 mm D: 35-35 mm D: 35-55 mm D: 55-65 mm C: 65-75 mm Sealing Mud

2 3 4

2 3 4


Distribution Transformer

**Figure 6-25** Connecting the four-core AC input power cables (excluding the ground cable and including the neutral wire)

IB04I20002

- (1) Screw assembly
- (2) Spring washer
- (3) Large washer (optional)

- (4) Wiring terminals
- (5) Copper bar
- (6) Flat washer




**Figure 6-26** Connecting the five-core AC input power cable (including the ground cable and the neutral wire)

- (1) Screw assembly
- (2) Spring washer
- (3) Large washer (optional)

- (4) Wiring terminals
- (5) Copper bar
- (6) Flat washer

**Step 4** Install the removed cover.



----End

# 6.5 (Optional) Connecting Single-phase AC Input Power Cables

#### □ NOTE

- This step applies only to some models. The figure is for reference only.
- If a UPS (provided by the customer) or other reliable backup power supplies (provided by the customer) is used to supply power, perform the following steps to change the connection mode of the single-phase AC input power cables.
- Recommended single-phase AC switch (5FCB, provided by the customer): 220/230 V AC; 10 A/2P.

# Scenario 1: The UPS Obtains Power from an External Power Source (Not from the ESS)

- **Step 1** Remove the short-circuiting bar from 1–2 and insert it to 2–3 on the XU terminal block.
- **Step 2** Remove the short-circuiting bar from 6–7 and insert it to 7–8 on the XU terminal block.
- **Step 3** Connect the armored cable to the ground point on the rear panel of the control unit cabin.
- **Step 4** Connect the PE cable (provided by the customer) to the ground bar of the control unit cabin, and connect the L and N wires (provided by the customer) to switch 5FCB2.

M4

1.2 N·m

UPS

M6

B04H00159

Figure 6-27 Wiring diagram

(1) Switch 5FCB2, connected to the UPS output

----End

#### Scenario 2: The UPS Obtains Power from the ESS

- **Step 1** Remove the short-circuiting bar from 1–2 and insert it to 2–3 on the XU terminal block.
- **Step 2** Remove the short-circuiting bar from 6–7 and insert it to 7–8 on the XU terminal block.
- **Step 3** Connect the two armored cables to the ground points on the rear panel of the control unit cabin.
- **Step 4** UPS output: Connect the PE cable (provided by the customer) to the ground bar of the control unit cabin, and connect the L and N wires (provided by the customer) to switch 5FCB2.
- **Step 5** Install a UPS switch 5FCB (provided by the customer).
- **Step 6** Connect the live wire 1775 and neutral wire 1777 (obtained from position 3 in the figure).
- **Step 7** UPS input: Connect the PE cable (provided by the customer) to the ground bar of the control unit cabin, and connect the L and N wires (provided by the customer) to switch 5FCB.




Figure 6-28 Wiring diagram

(1) Switch 5FCB2, connected to (2) Binding positions of live the UPS output wire 1775 and neutral wire 1777 (3) Switch 5FCB, connected to the UPS input

----End

# 6.6 Installing Signal Cables

# **6.6.1 Installing FE Communications Cables**

**Step 1** Remove the protective cover.






Figure 6-29 Removing the protective cover

**Step 2** Remove the baffle plates for the signal cables.





**Step 3** Connect the FE communications cables to the **WAN** ports on the CMU.


IB04W00002

Figure 6-31 Optical cable positions at the bottom

(1) DC power cable hole

- (2) AC input power cable or ground cable hole
- (3) Optical cable or network cable hole
- (4) UPS or RS485 cable hole (reserved)


Figure 6-32 Connecting FE communications cables



- IB04I40002
- (1) White-and-orange (2) Orange
- (3) White-and-green
- (4) Blue

- (5) White-and-blue
- (6) Green
- (7) White-and-brown
- (8) Brown

- **Step 4** Bind the cables.
- **Step 5** Install the removed cover.




----End

# **6.6.2 Installing Optical Cables**

NOTICE

Only professionals are allowed to connect optical cables.

Figure 6-33 Optical Terminal Box (ATB) interior



(1) Fiber spool

(2) Cable clip

**Step 1** Remove the protective cover.





Figure 6-34 Removing the protective cover

**Step 2** Remove the baffle plates for the optical cables.





**Step 3** Remove the external mechanical parts from the ATB.






Figure 6-36 Removing external mechanical parts

**Step 4** Remove the optical cable fastener.





- **Step 5** Connect one end of the optical jumper to the fiber adapter.
- **Step 6** Route the other end of the optical jumper through the cable hole on the side of the ATB, and connect the cable to the ATB.
- **Step 7** Connect the peripheral optical cable to the ATB, splice the optical cable and the optical jumper, and wind the spliced cable around the fiber spool on the ATB.
- **Step 8** Install an optical module on the CMU panel, connect one end of the optical jumper to the optical module, and connect the other end to the fiber adapter.

#### **NOTICE**

Only professionals are allowed to splice fibers.


IB04W00002

Figure 6-38 Optical cable positions at the bottom

(1) DC power cable hole


- (2) AC input power cable or ground cable hole
- (3) Optical cable or FE communications cable (4) UPS or RS485 cable hole (reserved) hole





Step 9 Check that the cables are connected correctly and securely. Then reinstall the optical cable fastener and external mechanical parts.


**Step 10** Install the removed cover.



----End

# 6.7 Sealing the Cable Holes

After the cables are installed, seal the cable holes using the sealing mud delivered with the equipment.



# Checking Before Power-On

| Item                  | No. | Check Item           | Acceptance Criteria  |
|-----------------------|-----|----------------------|--|
| General<br>inspection | 1   | Equipment appearance | <ul> <li>The equipment is intact and free from rust or paint flake-off. If paint flakes off, repaint the equipment.</li> <li>The labels on the equipment are clear. Damaged labels must be replaced.</li> </ul>  |
|                       | 2   | Cable appearance     | <ul><li>Cable sheathings are properly wrapped and not damaged.</li><li>Cable hoses are intact.</li></ul>   |
|                       | 3   | Cable connections    | <ul> <li>Cables are connected in the designed positions.</li> <li>Terminals are prepared as required and securely connected.</li> <li>Labels on both ends of each cable are clear and specific, and attached in the same direction.</li> </ul>   |
|                       | 4   | Cable layout         | <ul> <li>Electrical and ELV cables are routed separately.</li> <li>Cables are neat and tidy.</li> <li>Cable tie joints are evenly cut without burrs.</li> <li>Cables are placed properly and reserve some slack at bending points to avoid stress.</li> <li>Cables are routed neatly without twists or crossovers in the cabinet.</li> </ul> |
|                       | 5   | Switch               | <ul><li>The DC LV Panel switch is set to OFF.</li><li>The battery rack switch is set to OFF.</li></ul>   |
| ESS                   | 1   | Installation         | <ul> <li>The installation meets the design requirements.</li> <li>The ESS is level, and each door can be opened properly.</li> </ul>   |
|                       | 2   | Grounding            | Each ESS has at least two ground points and is grounded securely. The resistance of a bond shall be less than or equal to 0.1 ohms.  |

| Item       | No. | Check Item  | Acceptance Criteria   |  |
|------------|-----|---|---|--|
|            | 3   | Accessory   | The number and positions of external accessories installed meet design requirements.  |  |
|            | 4   | Label   | All labels are correct, clear, and complete.  |  |
|            | 5   | Cleanness   | The ESS is clean and tidy inside, without any unnecessary cables, cable ends, terminals, or tools. No garbage is found outside the equipment. |  |
| Battery    | 1   | Circuit breaker   | The MCCBs are set to OFF.   |  |
| cabin      | 2   | Copper bar  | The copper bar is not deformed, and no foreign objects are placed on the copper bar.  |  |
|            | 3   | Fuse  | There is no indication for broken fuses.  |  |
|            | 4   | Cable   | The bolts for installing the cables are tightened and the cables are not loose.   |  |
|            | 5   | Cable hole sealing  | Cable holes have been sealed.   |  |
|            | 6   | Component   | All components are intact.  |  |
|            | 7   | Foreign object  | Remove all foreign objects from the battery cabin, such as tools and remaining installation materials.  |  |
| Control    | 1   | SPD   | The SPD indicator is green.   |  |
| unit cabin | 2   | AC meter  | The buttons of the AC meter function properly and the screen is free of cracks.   |  |
|            | 3   | Cable   | The bolts for installing the cables are tightened and the cables are not loose.   |  |
|            | 4   | Foreign object  | There are no foreign objects in the control unit cabin, such as packing materials.  |  |
|            | 5   | Component (such as CMU, adapter, extinguishant control panel) | All components are intact.  |  |
|            | 6   | Fire cylinder   | The pressure of fire cylinder is normal.  |  |

# 8 Powering On the System

# 8.1 Installing the PSU

### **Prerequisites**

#### **↑** WARNING

- Do not put your hands into the PSU slot to avoid electric shock.
- When the PSU is running, a high temperature is generated around the air outlet at the rear. Do not touch the PSU or place cables or other objects on it.

## **CAUTION**

Power on the PSU within 24 hours after unpacking. Otherwise, place it in a dry indoor environment without corrosive gas.

#### **Ⅲ** NOTE

The subracks vary with the ESS models. The figure uses one type of subrack as an example.

- If the PSU is damaged, contact the local office.
- Determine the PSU installation position.





Figure 8-1 PSU installation position

### **Procedure**

- **Step 1** Push the locking latch leftward.
- **Step 2** Pull out the handle.
- **Step 3** Gently push the PSU into its slot along the guide rails.
- **Step 4** Push the handle upward.
- **Step 5** Push the locking latch rightward to lock the handle.

Figure 8-2 Installing the PSU



### 8.2 Installing the Solenoid Valve

### **CAUTION**

- If a solenoid valve is configured with a reset device, ensure that the solenoid valve is not activated before installing it on the fire cylinder. For details, see "FAQ".
- Before installing the solenoid valve, ensure that the fire suppression system has been tested and passed the acceptance inspection (Auxiliary power-on is required for the test and acceptance of the fire suppression system.).

### **◯** NOTE

- The appearance of the solenoid valve is for reference only, and that of the actual product may vary.
- The model of the solenoid valve may vary. For details about the applicable installation procedure, see the model of the fire cylinder.

### **Procedure**

### **MARNING**

For non-emergency manual operations, do not remove the safety pull ring.

- Fire cylinder model: GQQ40/2.5
- **Step 1** Remove the solenoid valve from the bracket.
- **Step 2** Remove the screws using a screwdriver and remove the electric control plug from the solenoid valve.
- **Step 3** Tighten the solenoid valve clockwise to the top of the fire cylinder.
- **Step 4** Insert the electric control plug and tighten the screws using a screwdriver.
- **Step 5** Remove the safety pin.




Figure 8-3 Installing the Solenoid Valve

- Fire cylinder models: NCM38UFAA, 227M38UFAA, SPS020-MS-032B-EN
- **Step 1** Remove the solenoid valve from the bracket.
- **Step 2** Remove the reset device at the bottom of the solenoid valve.
- **Step 3** Tighten the solenoid valve clockwise to the top of the fire cylinder.

IB04H00015

Figure 8-4 Installing the Solenoid Valve


----End

- Fire cylinder model: P0009438
- **Step 1** Remove the solenoid valve from the bracket and reinstall the nut and washer.
- **Step 2** Install the solenoid valve on the corresponding stud on the fire cylinder.

### **MOTE**

Nut specifications: outer hexagon HEX17. Nuts are customized and cannot be replaced with common nuts.

Figure 8-5 Installing the Solenoid Valve



### 8.3 Power-on Process


### **NOTICE**

The following figure is used only to guide the power-on sequence of the system. Do not use it for onsite cable connections.

STS 220V STS Auxilliary Transformer SACU Dyn11 0.8/0.4kV 5kVA Dy11-y11 35kV/0.8kV/0.8kV 4 Oconnect to the grid or other STS 1FC 1FC 01 02 03 04 05 06 07 08 09 10 DC LV 6 Panel Distribution Transformer Secondary devices power supply Secondary devices power supply Secondary devices power supply 10 Smart ESS 01

Figure 8-6 Power-on process of LUNA2000-2.0MWH-1HX

IB04P00008



**Figure 8-7** Power-on process of LUNA2000-2.0MWH-2HX/LUNA2000-2.0MWH-HE2HX

### **NOTICE**

- Check the equipment before power-on. For details, see the corresponding user manual.
- Before the first power-on, check that cables are correctly connected.
- Incorrect cable connections may cause damage to the STS or the Smart PCS.
   Verify the cable connections between the STS and the Smart PCS for the initial power-on. If any exception occurs during the power-on process, stop the operation. You can proceed with the operation only after the exception has been handled.
- Before the equipment is put into operation for the first time, ensure that the parameters are set correctly by professional personnel. Incorrect parameter settings may result in noncompliance with local grid connection requirements and affect the normal operations of the equipment.

| Procedure | Item  | Remarks  |
|-----------|---|--|
| 1         | Powering on the STS (including the STS Auxiliary Transformer) | Corresponding<br>to number 1,<br>number 2, and<br>number 3 in the<br>power-on<br>flowchart |

| Procedure | Item                      |   | Remarks  |
|-----------|---------------------------|---|--|
| 2         | Poweri<br>(SACU)          | ng On the Smart Array Controller  | Corresponding<br>to number 4 in<br>the power-on<br>flowchart                               |
| 3         | 1                         | ng on the Distribution Transformer<br>ei or non-Huawei equipment)                       | Corresponding<br>to number 5,<br>number 6, and<br>number 7 in the<br>power-on<br>flowchart |
| 4         | Powe<br>ring<br>On<br>the | Switching on the DC circuit breakers of the rack in the battery cabin                   | Corresponding<br>to number 8 in<br>the power-on<br>flowchart                               |
| 5         | ESS                       | Powering on the secondary devices (turning on the AC switches and then the DC switches) | Corresponding<br>to number 9 in<br>the power-on<br>flowchart                               |
| 6         |                           | Switching on the DC circuit breakers in the control unit cabin                          | Corresponding<br>to number 10 in<br>the power-on<br>flowchart                              |
| 7         |                           | nal) Turning on the switches at battery<br>the DC LV Panel                              | Corresponding<br>to number 11 in<br>the power-on<br>flowchart                              |
| 8         | Powe ring on the          | Turning on the switches at AC side of the Smart PCS                                     | Corresponding<br>to number 12 in<br>the power-on<br>flowchart                              |
| 9         | Smar<br>t PCS             | (Optional) Turning on the switches at DC side of the Smart PCS                          | Corresponding<br>to number 13 in<br>the power-on<br>flowchart                              |

### ₩ NOTE

After the system is powered on, you are advised to use a thermal imager to check whether the DC power cables and AC input power cables in the control unit cabin of the ESS are in good contact.

### 8.4 Powering On the Smart Transformer Station (STS)

- If a Huawei STS is used, see the corresponding product documents.
- If non-Huawei transformer is used, see the corresponding product documents from the manufacturer.

### 8.5 Powering On the Smart Array Controller (SACU)

### **Prerequisites**

- You have completed the power-on check.
- You have put on proper personal protective equipment (PPE).
- Ensure that the power voltage of the SACU is within the operating voltage range, and the three-phase input voltage is within the operating voltage range of the MBUS CCO.

### **Procedure**

- **Step 1** Turn on power switch 3FB3 for the Smart Array Controller in the auxiliary power distribution cabinet of the medium-voltage room.
- **Step 2** Open the cabinet door of the Smart Array Controller and turn on the power switch of the SmartLogger. The running indicator of the SmartLogger starts blinking 30 seconds later.

----End

### 8.6 Powering On the Distribution Transformer



Before connecting the power supply, ensure that all switches of the Distribution Transformer are turned off.

### **Procedure**

- **Step 1** Turn on the SPD switch MCB 6FB7 on the 400 V side of the auxiliary transformer cabinet.
- **Step 2** Turn on the incoming power switch MCCB 6QA on the 800 V side of the auxiliary transformer cabinet.

When the transformer is powered on, a loud buzz will be generated. Then the buzz is weakened rapidly and becomes stably low.

**Step 3** Turn on the meter switch MCB 6FB8 in the auxiliary transformer cabinet.

### □ NOTE

The digital display meter is started, showing that the line voltage at the low-voltage side is about 400 V, the phase voltage is about 230 V, and the current is 0 A.

**Step 4** Turn on the auxiliary circuit switch MCB 6FB9 in the auxiliary transformer cabinet.

### **Ⅲ** NOTE

- The heat exchanger fan starts. The heat exchanger performs the self-check program first, and the internal fan rotates for about 10s. The internal fan stops and the external fan rotates for about 10s. After the self-check is complete, the heat exchanger enters the normal operating mode, and the internal fan keeps running at a low speed.
  - When the smoke sensor is started, the green indicator blinks slowly and no alarm sound is generated.
- The transformer temperature sensor is started to display the current transformer temperature.

----End

### 8.7 Powering On the ESS

### **NOTICE**


- Before turning on the switches in the secondary devices of the ESS, check that the AC voltage of the auxiliary power supply and bus voltage are within the normal ranges.
- If the ESS has not been used for six months or longer after being installed, it must be checked and tested by professionals before operation.
- Perform power-on within two weeks after cables are connected. Otherwise, replace the desiccants with new ones (Montmorillonite desiccant, 500 g).
- Before power-on, remove the desiccants from the cabins and dispose of them according to the applicable local waste disposal act.

The protective film of ESS containers is used to prevent foreign objects from entering the container during storage. Do not remove the protective film before powering on and commissioning the ESS container. 區親風用于存錄时防止异物进入,存據时所必獲毀,需要上电過減的消騰,

- Before power-on, remove the blue protective films with the label
- Before powering on the ESS, ensure that the safety pin is removed from the solenoid valve on the fire cylinder.
- Do not open the battery compartment door after power-on. Otherwise, the system will shut down.

### **Procedure**

Figure 8-8 Switches in the Control Unit Cabin of LUNA2000-2.0MWH-1HX



IB04W00115

(1) AC power switch of (2) Extinguishant
the air conditioner control panel switch,
lighting switch, socket
switch, and CMU

switch, and CMU adapter switch

(3) DC input switch, exhaust fan controller switch, and air conditioner switch in the control unit cabin (4) Battery pack fan switch and Smart Rack Controller switch

- (5) SPD switch
- (6) AC main input switch of the ESS
- (7) DC circuit breaker in the control unit cabin
- (8) Position for the UPS switch (reserved)




Figure 8-9 Switches in the Control Unit Cabin of LUNA2000-2.0MWH-1HX


| (1) AC power switch of the air conditioner | (2) Extinguishant<br>control panel<br>switch, lighting<br>switch, 220/230 V<br>socket switch, and<br>CMU adapter<br>switch | (3) PSU AC input switch, DC input switch, exhaust fan controller switch, and air conditioner switch in the control unit cabin | (4) Battery pack<br>fan switch and<br>Smart Rack<br>Controller switch |
|--|--|---|---|
| (5) SPD switch                             | (6) AC main input<br>switch of the ESS   | (7) DC circuit<br>breaker in the<br>control unit cabin  | -   |

### □ NOTE

- The figures of switches use two of the models as an example.
- Switches labeled SPARE are reserved switches.

**Step 1** Switch on the DC circuit breakers 1Q1–6Q1 of battery racks in the Battery Cabin.

**Figure 8-10** Positions of the DC circuit breakers of battery racks in the battery cabin



- (1) Positions of the DC circuit breakers of battery racks in the battery cabin
- **Step 2** (Optional) Switch on UPS circuit breaker 5FCB (corresponding to number 8 in **the figure of switches**).

### □ NOTE

- The UPS switch position is reserved only in some models. If the UPS switch is needed, install it by yourself.
- Perform this operation only in microgrid or off-grid scenarios.
- **Step 3** Switch on circuit breaker 2FCB1 on the SPD (corresponding to number 5 in **the figure of switches**) and check that the SPD display window is green.
- **Step 4** Switch on the circuit breaker 1QA for the AC input power cable of the ESS. (corresponding to number 6 in **the figure of switches**)

### **<u>A</u>** CAUTION

- After turning on the main switch, immediately check that the L1, L2, and L3 phase voltages are 220 V AC/230 V AC.
- If the phase voltage displayed on the digital display meter is 400 V or other values, the cables between the L1, L2, L3, and N wires may be incorrectly connected. In this case, check the cables. Do not power on devices before checking cables. Otherwise, devices such as air conditioners may be damaged.
- **Step 5** Switch on all circuit breakers of the ESS power distribution system.

**Table 8-1** Switch configuration

| Models                        | Air<br>Conditioner<br>Position in<br>the Battery<br>Cabin | Air<br>Conditioner<br>Switches No.                                   | Battery Pack<br>Fans<br>Switches No.   | Smart Rack<br>Controller<br>Switches No.                      |
|-------------------------------|---|--|--|---|
| LUNA2000-2.<br>0MWH-1HX       | 1/2/4/5/7/8/1<br>0/11                                     | 3FCB1, 3FCB2,<br>3FCB4, 3FCB5,<br>3FCB7, 3FCB8,<br>3FCB10,<br>3FCB11 | 7FCB7-<br>7FCB15,<br>7FCB19-<br>7FCB27 | 7FCB16,<br>7FCB17,<br>7FCB18,<br>7FCB28,<br>7FCB29,<br>7FCB30 |
| LUNA2000-2.<br>0MWH-1HX       | 1/3/5/7/9/11  | 3FCB1, 3FCB3,<br>3FCB5, 3FCB7,<br>3FCB9,<br>3FCB11                   | 7FCB7-<br>7FCB15,<br>7FCB19-<br>7FCB27 | 7FCB16,<br>7FCB17,<br>7FCB18,<br>7FCB28,<br>7FCB29,<br>7FCB30 |
| LUNA2000-2.<br>0MWH-2HX       | 1/3/5/7/9/11  | 3FCB1, 3FCB3,<br>3FCB5, 3FCB7,<br>3FCB9,<br>3FCB11                   | 7FCB7-<br>7FCB15,<br>7FCB19-<br>7FCB27 | 7FCB16,<br>7FCB17,<br>7FCB18                                  |
| LUNA2000-2.<br>0MWH-2HX       | 2/4/6/8/10/12   | 3FCB2, 3FCB4,<br>3FCB6, 3FCB8,<br>3FCB10,<br>3FCB12                  | 7FCB7-<br>7FCB15,<br>7FCB19-<br>7FCB27 | 7FCB16,<br>7FCB17,<br>7FCB18                                  |
| LUNA2000-2.<br>0MWH-2HX       | 1/4/7/10  | 3FCB1, 3FCB4,<br>3FCB7,<br>3FCB10                                    | 7FCB7-<br>7FCB12                       | 7FCB16,<br>7FCB17,<br>7FCB18                                  |
| LUNA2000-2.<br>0MWH-<br>HE2HX | 1/4/7/10  | 3FCB1, 3FCB4,<br>3FCB7,<br>3FCB10                                    | 7FCB7-<br>7FCB12                       | 7FCB16,<br>7FCB17,<br>7FCB18                                  |

- 1. Switch on the AC power circuit breakers of the air conditioner in sequence. (corresponding to number 1 in **the figure of switches**)
- 2. Switch on ESS adapter circuit breaker 5FCB1, extinguishant control panel circuit breaker 5FCB3, lighting system circuit breaker 1FB1 in sequence. (corresponding to number 2 in the figure of switches)
- 3. Switch on 220/230 V socket circuit breaker 1FB2.


### **◯** NOTE

Only some models are equipped with a separate socket circuit breaker.

4. Open the extinguishant control panel and turn on the two power switches inside (applicable only to the JB-QBL-QM210 extinguishant control panel). Switch off extinguishant control panel circuit breaker 5FCB3, make sure it

running well using the battery power supply. Switch on the circuit breaker 5FCB3.

Figure 8-11 Position of the power switch in the extinguishant control panel



- (1) Position of the right power switch in the extinguishant control panel (2) Position of the left power switch in the extinguishant control panel
- 5. Switch on the PSU AC input circuit breaker 6FCB1.

### □ NOTE

If a 3 U subrack is configured, the PSU switch is in the subrack. If a 2 U subrack is configured, the PSU switch is in (2) in the figure that shows switch positions.

- 6. On the subrack, switch on the DC input circuit breakers 7FCB1 and (optional) 7FCB2, the exhaust fan controller circuit breakers 7FCB4 and 7FCB5, and the air conditioner circuit breaker 7FCB6 of the control unit cabin in sequence. (corresponding to number 3 in the figure of switches)
- 7. Switch on the circuit breakers of the battery pack fan in sequence. (corresponding to number 4 in **the figure of switches**)
- 8. Switch on the circuit breakers of the Smart Rack Controller. (corresponding to number 4 in the figure of switches)

**Step 6** Switch on the DC circuit breakers in the control unit cabin. (corresponding to number 7 in **the figure of switches**)

**Table 8-2** Switch configuration

| Models                  | Air Conditioner<br>Position in the Battery<br>Cabin | DC Circuit Breakers No. in the Control Unit Cabin |
|-------------------------|---|---|
| LUNA2000-2.0MWH-1<br>HX | 1/2/4/5/7/8/10/11                                   | 1Q2-6Q2   |
| LUNA2000-2.0MWH-1<br>HX | 1/3/5/7/9/11  | 1Q2-6Q2   |
| LUNA2000-2.0MWH-2<br>HX | 1/3/5/7/9/11  | 1Q2-3Q2   |

| Models                    | Air Conditioner<br>Position in the Battery<br>Cabin | DC Circuit Breakers No. in the Control Unit Cabin |
|---------------------------|---|---|
| LUNA2000-2.0MWH-2<br>HX   | 2/4/6/8/10/12                                       | 1Q2-3Q2   |
| LUNA2000-2.0MWH-2<br>HX   | 1/4/7/10  | 1Q2-6Q2   |
| LUNA2000-2.0MWH-<br>HE2HX | 1/4/7/10  | 1Q2-6Q2   |

### ■ NOTE

The status of DC switches in the control unit cabin is subject to the actual number of PCSs connected.

----End

## 8.8 (Optional) Powering On the Battery Side of the DC LV Panel

### **<u>A</u>** CAUTION

- If any exception occurs during the power-on process, stop the operation. You can proceed with the operation only after the exception has been handled.
- At least two persons are required for the first power-on. One person operates the MCCB on the ESS side, while the other person observes the running status on the DC LV Panel side.

### **Step 1** Power on the battery side of the DC LV Panel.

- 1. Check that DC circuit breakers 1Q2, 2Q2, 3Q2, 4Q2, 5Q2, and 6Q2 in the control unit cabin of the ESS are switched on.
- 2. Switch on the DC circuit breakers on the battery side of the DC LV Panel.

### 8.9 Powering On the Smart PCS

### **Precautions**

### NOTICE

- Before turning on the AC switch between the Smart PCS and the power grid, check whether the AC voltage is within the required range using a multimeter. (See the local power grid standard.)
- If the Smart PCS has not been used for six months or longer after being installed, it must be checked and tested by professionals before operation.

### Procedure

- **Step 1** Turn on the AC switch between the Smart PCS and the power grid.
- **Step 2** Turn on the DC switches between the Smart PCS and the DC LV Panel busbar.
- **Step 3** Observe the LED indicators to check the running status of the Smart PCS.

----End

### **Indicator Description**

You can view the running status of the Smart PCS by observing the LED indicators on the panel.

Figure 8-12 LED indicators




Table 8-3 LED indicators

| No. | Category                 | Indicator<br>Status      | Description  |
|-----|--------------------------|--------------------------|--|
| 1   | DC indication            | Steady green             | The DC side is properly connected, and the voltage on the DC side is greater than or equal to 500 V. |
|     |                          | Blinking<br>green slowly | The device is in standby mode.   |
|     |                          | Blinking red fast        | An environmental fault occurs on the DC side.  |
|     |                          | Off                      | The DC side is not properly connected, or the voltage on the DC side is less than 500 V.             |
| 2   | Running                  | Steady green             | The device is operating in grid-tied mode.   |
|     | indication               | Blinking<br>green slowly | The system environment is normal and the device is not in the working state.                         |
|     |                          | Blinking red fast        | An environmental fault occurs on the AC side.  |
|     |                          | Off                      | The AC side is not connected to the power grid.  |
| 3   | Communication indication | Blinking<br>green fast   | The device receives data through the northbound FE ports.  |
|     |                          | Off                      | The device has not received data through the FE ports in at least 10s.                               |
| 4   | Fault/                   | Steady red               | A major alarm is generated on the device.  |
|     | Maintenance indication   | Blinking red fast        | A minor alarm is generated on the device.  |
|     |                          | Blinking red slowly      | A warning is generated on the device.  |
|     |                          | Blinking<br>green slowly | The device is under local maintenance or shuts down after receiving a command.                       |
|     |                          | Off                      | No alarm is generated, and no local maintenance operations are performed.                            |

### ₩ NOTE

- Local maintenance refers to the operation of inserting a WLAN module or USB data cable into the USB port of the device. For example, connecting to the SUN2000 app through the WLAN module.
- If alarms are generated during the local maintenance, the fault/maintenance indicator shows the local maintenance state first. After the WLAN module or USB cable is removed, the indicator shows the alarm state.

# 9 Deployment and Commissioning (SmartLogger WebUI)

For details about deployment and commissioning in on-grid scenarios, see On-Grid Utility-Scale Energy Storage Solution Quick Guide. For details about deployment and commissioning in microgrid scenarios, see Medium-Voltage Microgrid Energy Storage Solution Quick Guide.

# 10 Powering Off the System

## 10.1 Delivering a Shutdown Command on the SmartLogger

### **Prerequisites**

The system has connected to the grid and is running properly.

### **Procedure**

**Step 1** Log in to the SmartLogger WebUI, choose **Maintenance** > **Connect Device**, and click to shut down the Smart PCS and Smart Rack Controller.

Figure 10-1 Shutdown command



- **Step 2** Choose **Device Monitoring > PCS > Running Info.** Check the device status, active power, and DC voltage to verify that the shutdown is successful.
- **Step 3** Choose **Device Monitoring > CMU > Running Info.** Check the rated power and total output voltage of the rectifier to ensure that the shutdown is successful.


IB04P00008

### 10.2 Power-off Process

STS 220V STS Auxilliary Transformer SACU 6500kVA Dyn11 Dy11-y11 35kV/0.8kV/0.8kV 0.8/0.4kV 5kVA Connect to the grid or other STS 1FC 1FC Dyn11 0.8/0.4kV 210kVA Smar 06 07 08 09 10 PCS DC LV 8 Transformer Secondary devices power supply Secondary devices power supply Secondary devices power supply 7 6 Smart ESS 01

Figure 10-2 Power-off process of LUNA2000-2.0MWH-1HX

**Figure 10-3** Power-off process of LUNA2000-2.0MWH-2HX/LUNA2000-2.0MWH-HE2HX



### 

Before powering off the system, shut down the entire system on the SmartLogger WebUI, including the Smart PCS and the Smart Rack Controller.

| Proced<br>ure | Item  |   | Remarks  |  |
|---------------|---|---|--|--|
| 1             | Powering off the  | Powering off the AC side of the Smart PCS   | Corresponding to number 1 in the power-off flowchart                 |  |
| 2             | Smart<br>PCS  | (Optional) Powering off<br>the DC side of the Smart<br>PCS                                | Corresponding to number 2 in the power-off flowchart                 |  |
| 3             | (Optional) Powering off the battery side of the DC LV Panel |   | Corresponding to number 3 in the power-off flowchart                 |  |
| 4             | Powering<br>off the<br>ESS                                  | Switching off the DC circuit breakers of the rack in the battery cabin                    | Corresponding to number 4 in the power-off flowchart                 |  |
| 5             |   | Switching off the DC circuit breakers in the control unit cabin                           | Corresponding to number 5 in the power-off flowchart                 |  |
| 6             |   | Powering off the secondary devices (turning off the DC switches and then the AC switches) | Corresponding to number 6 in the power-off flowchart                 |  |
| 7             |   | ff the Distribution<br>r (Huawei or non-Huawei  | Corresponding to number 7,<br>8, and 9 in the power-off<br>flowchart |  |

### 10.3 Powering Off the Smart PCS

### **Procedure**

- **Step 1** Wear proper personal protective equipment (PPE).
- **Step 2** Turn off the AC switch between the Smart PCS and the grid.
- **Step 3** Open the AC maintenance compartment door, install a support bar, and use a multimeter to measure the voltage between the AC terminal block and the ground. Ensure that the AC side of the Smart PCS is disconnected.
- Step 4 Turn off the DC switch between the Smart PCS and the DC LV Panel busbar.
- **Step 5** Open the DC maintenance compartment door, install a support bar, and use a multimeter to measure the voltage between the DC terminal block and the ground. Ensure that the DC side of the Smart PCS is disconnected.

## 10.4 (Optional) Powering Off the Battery Side of the DC LV Panel

**Step 1** Turn off the switches on the battery side of the DC LV Panel.

----End

### 10.5 Powering Off the ESS

**Table 10-1** Switch configurations

| Model                       | Air<br>Conditi<br>oner<br>Positio<br>n in<br>the<br>Battery<br>Cabin | Air<br>Conditioner<br>Switch No.                                     | Battery Pack<br>Fan Switch<br>No.      | Smart Rack<br>Controller<br>Switch No.                        | DC<br>Circuit<br>Break<br>er No.<br>in the<br>Contr<br>ol<br>Unit<br>Cabin |
|-----------------------------|--|--|--|---|--|
| LUNA2000<br>-2.0MWH-<br>1HX | 1/2/4/5<br>/7/8/10<br>/11  | 3FCB1, 3FCB2,<br>3FCB4, 3FCB5,<br>3FCB7, 3FCB8,<br>3FCB10,<br>3FCB11 | 7FCB7-<br>7FCB15,<br>7FCB19-<br>7FCB27 | 7FCB16,<br>7FCB17,<br>7FCB18,<br>7FCB28,<br>7FCB29,<br>7FCB30 | 1Q2-<br>6Q2  |
| LUNA2000<br>-2.0MWH-<br>1HX | 1/3/5/7<br>/9/11   | 3FCB1, 3FCB3,<br>3FCB5, 3FCB7,<br>3FCB9, 3FCB11                      | 7FCB7-<br>7FCB15,<br>7FCB19-<br>7FCB27 | 7FCB16,<br>7FCB17,<br>7FCB18,<br>7FCB28,<br>7FCB29,<br>7FCB30 | 1Q2-<br>6Q2  |
| LUNA2000<br>-2.0MWH-<br>2HX | 1/3/5/7<br>/9/11   | 3FCB1, 3FCB3,<br>3FCB5, 3FCB7,<br>3FCB9, 3FCB11                      | 7FCB7-<br>7FCB15,<br>7FCB19-<br>7FCB27 | 7FCB16,<br>7FCB17,<br>7FCB18                                  | 1Q2-<br>3Q2  |
| LUNA2000<br>-2.0MWH-<br>2HX | 2/4/6/8<br>/10/12  | 3FCB2, 3FCB4,<br>3FCB6, 3FCB8,<br>3FCB10,<br>3FCB12                  | 7FCB7-<br>7FCB15,<br>7FCB19-<br>7FCB27 | 7FCB16,<br>7FCB17,<br>7FCB18                                  | 1Q2-<br>3Q2  |

| Model   | Air<br>Conditi<br>oner<br>Positio<br>n in<br>the<br>Battery<br>Cabin | Air<br>Conditioner<br>Switch No. | Battery Pack<br>Fan Switch<br>No. | Smart Rack<br>Controller<br>Switch No. | DC<br>Circuit<br>Break<br>er No.<br>in the<br>Contr<br>ol<br>Unit<br>Cabin |
|---|--|----------------------------------|-----------------------------------|--|--|
| LUNA2000<br>-2.0MWH-<br>2HX/<br>LUNA2000<br>-2.0MWH-<br>HE2HX | 1/4/7/1<br>0   | 3FCB1, 3FCB4,<br>3FCB7, 3FCB10   | 7FCB7-<br>7FCB12                  | 7FCB16,<br>7FCB17,<br>7FCB18           | 1Q2-<br>6Q2  |

- **Step 1** Turn off the DC circuit breakers 1Q1–6Q1 of the battery racks in the ESS battery cabins.
- **Step 2** Turn off the DC switches in the ESS control unit cabin (as shown by 7 in the switch position diagram).
- **Step 3** Turn off all switches in the power distribution system of the ESS.
  - 1. Turn off the AC power switches of air conditioners (as shown by 1 in the switch position diagram).
  - 2. Turn off the extinguishant control panel switch 5FCB3, open the extinguishant control panel, turn off the internal power switch, and turn off the lighting system switch 1FB1, (optional) 220 V socket switch 1FB2, and CMU adapter switch 5FCB1 in sequence (as shown by 2 in the switch position diagram).
  - 3. Turn off the battery pack fan switches (as shown by 4 in the **switch position diagram**).
  - 4. Turn off the Smart Rack Controller switches (as shown by 4 in the **switch position diagram**).
  - 5. On the embedded subrack, turn off the DC input switches 7FCB1 and (optional) 7FCB2, the exhaust fan controller switches 7FCB4 and 7FCB5, and the air conditioner switch 7FCB6 of the control unit cabin in sequence (as shown by 3 in the switch position diagram).
  - 6. Turn off the PSU AC input switch 6FCB1.
- **Step 4** Turn off the general AC cable inlet switch 1QA of the ESS (as shown by 6 in the switch position diagram).
- **Step 5** If the extinguishant control panel has been powered off for more than 24 hours, the battery switch in the extinguishant control panel must be turned off or cables between the extinguishant control panel and the battery must be disconnected.
- **Step 6** Turn off the SPD switch 2FCB1 (as shown by 5 in the switch position diagram).

**Step 7** (Optional) Turn off the UPS cable inlet switch 5FCB (as shown by 8 in the **switch position diagram**).

----End

### 10.6 Powering Off the Distribution Transformer



Follow the relevant power operation procedure. Wear high-voltage insulation gloves, insulation shoes, and safety helmets, and use operation levers.

### **Procedure**

- **Step 1** Turn off the auxiliary circuit switch MCB 6FB9 in the auxiliary transformer cabinet.
- **Step 2** Turn off the meter switch MCB 6FB8 in the auxiliary transformer cabinet.
- **Step 3** Turn off the incoming power switch MCCB 6QA on the 800 V side of the auxiliary transformer cabinet.
- **Step 4** Turn off the SPD switch MCB 6FB7 on the 400 V side of the auxiliary transformer cabinet.

## **11** Alarm Reference

For details about the alarm reference, see LUNA2000-2.0MWH and 1.0MWH Series Smart String ESS Alarm Reference.

# 12 Emergency Handling

If an accident (including but not limited to the following) occurs on the site, ensure the safety of onsite personnel first and contact the Company's service engineers.

### **Battery Falling or Strong Impact**

- If a battery has obvious damage or abnormal odor, smoke, or fire occurs, evacuate the personnel immediately, call emergency services, and contact the professionals. The professionals shall use fire extinguishing facilities to extinguish the fire under safety protection.
- If the appearance is not deformed or damaged, and there is no obvious abnormal odor, smoke, or fire, ensure safety and perform the following operations:
  - Warehouse: Evacuate personnel, transfer the battery to an open and safe place by professionals using mechanical tools, and contact the Company's service engineers. Leave the battery for an hour and ensure that the battery temperature is within the room temperature range (tolerance: ±10°C) before handling.
  - ESS onsite: Evacuate personnel, close the doors of the ESS, transfer the battery to an open and safe place by professionals using mechanical tools, and contact the Company's service engineers. Leave the battery for an hour before handling.

### Flood

- Power off the system if it is safe to do so.
- If any part of the batteries is submerged in water, do not touch the batteries to avoid electric shock.
- Do not use batteries that have been soaked in water. Contact a battery recycling company for disposal.

### Fire Alarm Horn/Strobe

When the alarm indicator on the equipment blinks or buzzes:

Do not approach.

- Do not open the door.
- Stay away immediately.
- Cut off the power supply remotely only when your safety is guaranteed.

### **Gas Exhaust**

- Onsite personal protection: Do not directly face the exhaust vents.
- Post-disaster product maintenance: Contact the Company's service engineers for evaluation.

### **Extinguishant Release or Fire**

- Suggestions for onsite O&M personnel:
  - a. When a fire occurs, evacuate from the building or equipment area, press the fire alarm bell, and immediately call the fire emergency service.

    Notify the professional firefighters and provide them with relevant product information, including but not limited to battery pack types, ESS capacity, and battery pack location and distribution.
  - b. Do not enter the affected building or equipment area under any circumstances, and do not open the doors of the ESS. Isolate and monitor the site. Keep irrelevant personnel away from the site.
  - c. After calling the fire emergency service, remotely power off the system (such as the Smart Transformer Station, Smart PCS, auxiliary power supply devices, and combiner box power supply) while ensuring your own safety.
  - d. After professional firefighters arrive, provide relevant product information, including but not limited to battery pack types, ESS capacity, battery pack location and distribution, and user manuals.
  - e. After the fire is extinguished, the site must be handled by professionals in accordance with local laws and regulations. Do not open the doors of the ESS without permission.
  - f. Post-disaster product maintenance: Contact the Company's service engineers for evaluation.
- Suggestions for professional firefighters:
  - For product information, see the information provided by O&M personnel, including but not limited to battery pack types, ESS capacity, battery pack location and distribution, and user manuals.
  - b. Do not open the doors of the ESS before it is deemed safe by professionals.
  - c. Follow local fire fighting regulations.

**13** FAQ

## 13.1 (Optional) How to Level the ESS When Doors Cannot Be Opened or Closed

This procedure applies only to some models.

**Step 1** Use a jack to support the ESS.

- Jack specification: 30 t
- Position requirements: on the control unit cabin side or its opposite side (the short side of the ESS container).

**NOTE** 

Wood sleepers can be used in the following circumstances.

- Insufficient jack height: Place wood sleepers underneath the jack.
- Earth ground: Use wood sleepers to extend contact area.

**Step 2** Adjust the height using leveling washers from the control unit cabin.


**Scenario 1:** The Upper Part of the Lock Tongue Interferes With the Upper Surface of the Lock Base

Use leveling washers to raise ESS by 5–10 mm on the foundation under the door hinge.

**□** NOTE

The raising height leveling washers may vary according to the actual conditions.

**Figure 13-1** The Upper Part of the Lock Tongue Interferes With the Upper Surface of the Lock Base




(1) Position of leveling washers

**Scenario 2:** The Lower Part of the Lock Tongue Interferes With the Lower Surface of the Lock Base

Use leveling washers to raise ESS by 5–10 mm on the foundation under the lock base farthest to the door hinge.

**Figure 13-2** The Lower Part of the Lock Tongue Interferes With the Lower Surface of the Lock Base




(1) Position of leveling washers

----End

## 13.2 How to Ensure that the Solenoid Valve Is Not Activated

- **Step 1** Check whether the solenoid valve is not activated.
- **Step 2** If it is activated, reset it. The reset procedure is as follows:

- 1. Insert the reset device into the solenoid valve to reset the ejector pin.
- 2. After resetting, remove the solenoid valve reset device.



----End

## 13.3 How to Connect the ESS to the Smart PV Management System

- **Step 1** Enter https://SmartPVMS IP address: 31943 in the address box of a browser, and press **Enter**. The login page is displayed.
- Step 2 Enter the username or mobile number, and password, and click Log In.



----End

### 13.4 How to Create a Plant

- **Step 1** Choose **Plants** > **Plant Management** from the main menu.
- **Step 2** On the **Plant Management** page, click **Add Plant**.



**Step 3** Perform the next step as prompted.



----End

## 13.5 Why Does the PSU Not Start After the Water and Fire Alarms Are Cleared

**Step 1** Choose **Monitoring > Running Param > Fire suppression > Starting up** on the SmartLogger WebUI.

Figure 13-3 Page of restoring the power supply



## 13.6 What Should I Do If the ESU Cable Connection Detection Abnormal Alarm Is Generated on the WebUI?

**Step 1** Press the reset button ( ) in the upper right corner of the ESU screen. The ESU restarts cable connection detection.

■ NOTE

If the alarm persists, contact your dealer or technical support.

----End

## 13.7 How Do I Perform a Dielectric Voltage Withstand Test on the AC Side of an ESS?


### **Prerequisites**

1. Turn on the main switch of the AC circuit breaker, as shown by ① in the figure. Turn off other switches.

Make sure the power switch of the 3 U or 2 U subrack is off, as shown by ② in the figure.

- 2. Remove the SMU from the 3 U or 2 U subrack, as shown by ③ in the figure.
- 3. Disconnect the power meter fuse, as shown by ④ in the figure.
- 4. Disconnect the main neutral wire, as shown by ⑤ in the figure.

Figure 13-4 3U subrack positions



1B04W00097

Figure 13-5 2U subrack positions

### **Test Instrument**

Withstand voltage tester

### **Test Items and Criteria**

| No. | Test Item  | Procedure  | Criteria   |
|-----|--|--|--|
| 1   | Withstand<br>voltage of<br>the main<br>ground after<br>L1, L2, L3,<br>and N are<br>short-<br>circuited | <ol> <li>Short-circuit L1, L2, L3, and N.</li> <li>Select the withstand voltage test function for the tester. Connect one end to the short-circuit point of the phase wire and the other end to the main ground point. Set the dielectric withstand voltage to 2121 V DC, rise time to 10s, and hold time to 60s.</li> </ol> | <ul> <li>The leakage current<br/>during the test is less<br/>than 10 mA.</li> <li>No breakdown or<br/>flashover occurs<br/>during the test.</li> </ul> |

| No. | Test Item  | Procedure   | Criteria  |
|-----|--|---|---|
| 2   | Main ground<br>insulation<br>resistance<br>after L1, L2,<br>L3, and N<br>are short-<br>circuited | <ol> <li>Short-circuit L1, L2, L3, and N.</li> <li>Select the insulation resistance test function for the tester. Connect one end of the tester to the short-circuit point of the phase wire and the other end to the main ground point. Set the test voltage to 1 kV DC and record the test resistance.</li> </ol> | <ul> <li>The test voltage is 1 kV.</li> <li>The stable insulation resistance is greater than or equal to 1 MΩ.</li> </ul> |

Note: If the result of the first test does not meet the requirements, perform the test again following the prerequisites. If the test result still fails to meet the requirements, contact the Company's service engineers immediately.

### Follow-up Procedure

Remove the short-circuit cable and restore all switches to factory settings.

# **14** Technical Specifications

**Table 14-1** Technical specifications

| Item   | LUNA2000-2.<br>0MWH-1H0<br>(320 Ah Cell)                     | LUNA2000-2.<br>0MWH-2H0<br>(320 Ah Cell)                       | LUNA2000-2.<br>0MWH-1H1<br>(280 Ah Cell)                     | LUNA2000-2.<br>0MWH-2H1<br>(280 Ah Cell)                       | LUNA2000-2.0<br>MWH-HE2H1<br>(280 Ah Cell)                     |
|--|--|--|--|--|--|
| Rated<br>voltage on<br>the bus<br>side of the<br>Smart<br>Rack<br>Controller   | 1200 V   | 1200 V   | 1250 V   | 1250 V   | 1250 V   |
| Maximum<br>voltage on<br>the bus<br>side of the<br>Smart<br>Rack<br>Controller | 1500 V   | 1500 V   | 1500 V   | 1500 V   | 1500 V   |
| Smart<br>Rack<br>Controller<br>model   | ESC360KW-F   | ESC360KW-F   | ESC360KW-F   | ESC360KW-F   | ESC360KW-F   |
| Smart<br>Rack<br>Controller<br>configurati<br>on                               | One battery rack is configured with a Smart Rack Controller. | Two battery racks are configured with a Smart Rack Controller. | One battery rack is configured with a Smart Rack Controller. | Two battery racks are configured with a Smart Rack Controller. | Two battery racks are configured with a Smart Rack Controller. |
| Rated<br>voltage of<br>a battery<br>rack                                       | 1075.2 V   | 1075.2 V   | 1209.6 V   | 1209.6 V   | 1094.4 V   |

| Item  | LUNA2000-2.<br>0MWH-1H0<br>(320 Ah Cell)              | LUNA2000-2.<br>0MWH-2H0<br>(320 Ah Cell)              | LUNA2000-2.<br>0MWH-1H1<br>(280 Ah Cell)              | LUNA2000-2.<br>0MWH-2H1<br>(280 Ah Cell)                    | LUNA2000-2.0<br>MWH-HE2H1<br>(280 Ah Cell)            |
|---|---|---|---|---|---|
| Voltage<br>range of a<br>battery<br>rack          | 907-1227 V  | 907-1227 V  | 1020-1365 V   | 1020-1365 V   | 923-1235 V  |
| Battery<br>pack<br>model                          | ESM51320AS1   | ESM51320AS1   | ESM-57280AS<br>1                                      | ESM-57280AS<br>1  | ESM57280AS1   |
| Battery<br>pack<br>configurati<br>on per<br>rack  | One battery rack is configured with 21 battery packs. | One battery rack is configured with 21 battery packs. | One battery rack is configured with 21 battery packs. | One battery rack is configured with 21 or 19 battery packs. | One battery rack is configured with 19 battery packs. |
| Nominal<br>capacity<br>of a<br>battery<br>rack    | 344.1 kWh   | 344.1 kWh   | 338.7 kWh   | 338.7 kWh   | 306.4 kWh   |
| Nominal<br>power                                  | 6 x 344 kW  | 3 x 344 kW  | 6 x 339 kW  | 3 x 339 kW  | 3 x 306 kW  |
| Rated bus<br>charge/<br>discharge<br>current      | 6 x 287 A   | 3 x 287 A   | 6 x 271 A   | 3 x 271 A   | 3 x 245 A   |
| Maximum<br>bus<br>charge/<br>discharge<br>current | 6 x 320 A   | 3 x 320 A   | 6 x 280 A   | 3 x 280 A   | 3 x 280 A   |
| Maximum<br>battery<br>current                     | 320 A   | 160 A   | 280 A   | 140 A   | 140 A   |
| Charge/<br>Discharge<br>rate                      | ≤ 1C @ 40°C   | ≤ 0.5C @ 40°C   | ≤ 1C @ 40°C   | ≤ 0.5C @ 40°C   | ≤ 0.5C @ 40°C   |
| Intra-rack<br>balancing<br>mode                   | Pack-level<br>active<br>balancing                     | Pack-level<br>active<br>balancing                     | Pack-level<br>active<br>balancing                     | Pack-level<br>active<br>balancing                           | Pack-level active balancing                           |
| Number<br>of battery<br>racks per<br>ESS          | 6   | 6   | 6   | 6   | 6   |

| Item  | LUNA2000-2.<br>0MWH-1H0<br>(320 Ah Cell)    | LUNA2000-2.<br>0MWH-2H0<br>(320 Ah Cell)    | LUNA2000-2.<br>0MWH-1H1<br>(280 Ah Cell)    | LUNA2000-2.<br>0MWH-2H1<br>(280 Ah Cell)    | LUNA2000-2.0<br>MWH-HE2H1<br>(280 Ah Cell) |
|---|---|---|---|---|--|
| Nominal<br>battery<br>capacity<br>per ESS                       | 2064 kWh                                    | 2064 kWh                                    | 2032 kWh                                    | 2032 kWh                                    | 1838 kWh                                   |
| ESS<br>container<br>dimension<br>s (W x H x<br>D)               | 20 ft: 6058<br>mm x 2896<br>mm x 2438<br>mm | 20 ft: 6058 mm<br>x 2896 mm x<br>2438 mm   |
| Weight  | ≤ 30 t                                      | ≤ 30 t                                      | ≤ 30 t                                      | ≤ 30 t                                      | ≤ 30 t                                     |
| Ingress<br>protection<br>(IP) rating                            | IP55  | IP55  | IP55  | IP55  | IP55                                       |
| Operating temperatu re range                                    | -30°C to<br>+55°C                           | −30°C to<br>+55°C                           | -30°C to<br>+55°C                           | −30°C to<br>+55°C                           | −30°C to +55°C                             |
| Storage<br>temperatu<br>re range                                | -40°C to<br>+60°C                           | -40°C to<br>+60°C                           | -40°C to<br>+60°C                           | -40°C to<br>+60°C                           | -40°C to +60°C                             |
| Operating humidity range  | 0%–100%<br>(non-<br>condensing)             | 0%–100%<br>(non-<br>condensing)             | 0%–100%<br>(non-<br>condensing)             | 0%–100%<br>(non-<br>condensing)             | 0%–100% (non-<br>condensing)               |
| DC surge<br>protection  | Type II                                     | Type II                                     | Type II                                     | Type II                                     | Type II                                    |
| Maximum operating altitude                                      | 4000 m                                      | 4000 m                                      | 4000 m                                      | 4000 m                                      | 4000 m <sup>[1]</sup>                      |
| Battery<br>temperatu<br>re control<br>mode                      | Industrial air<br>conditioning              | Industrial air<br>conditioning              | Industrial air<br>conditioning              | Industrial air<br>conditioning              | Industrial air<br>conditioning             |
| Number<br>of air<br>conditione<br>rs in the<br>battery<br>cabin | 8   | 6   | 8 or 6                                      | 6 or 4                                      | 4  |
| Fire<br>suppressio<br>n system                                  | FM-200 or<br>FK-5-1-12                      | FM-200 or<br>FK-5-1-12                      | FM-200 or<br>FK-5-1-12                      | FM-200 or<br>FK-5-1-12                      | FK-5-1-12                                  |

| Item                                     | LUNA2000-2.<br>0MWH-1H0<br>(320 Ah Cell)                  | LUNA2000-2.<br>0MWH-2H0<br>(320 Ah Cell)                  | LUNA2000-2.<br>0MWH-1H1<br>(280 Ah Cell)                  | LUNA2000-2.<br>0MWH-2H1<br>(280 Ah Cell)                  | LUNA2000-2.0<br>MWH-HE2H1<br>(280 Ah Cell)            |
|--|---|---|---|---|---|
| System communic ations interface         | Ethernet/<br>Optical fiber<br>(standard<br>configuration) | Ethernet/<br>Optical fiber<br>(standard<br>configuration) | Ethernet/<br>Optical fiber<br>(standard<br>configuration) | Ethernet/<br>Optical fiber<br>(standard<br>configuration) | Ethernet/Optical<br>fiber (standard<br>configuration) |
| System<br>communic<br>ations<br>protocol | Modbus TCP  | Modbus TCP  | Modbus TCP  | Modbus TCP  | Modbus TCP  |


Note [1]: To use the product at an altitude higher than 4000 m, contact technical support.



# **A.1 CMU WebUI Operations**

# A.1.1 WebUI Layout

Figure A-1 WebUI layout



| No. | Function             | Description   |
|-----|----------------------|---|
| 1   | First-level menu     | Choose the corresponding first-level menu before you perform any operation over the WebUI.                          |
| 2   | Second-level<br>menu | Under the first-level menu, choose the device to be queried or the parameter to be set under the second-level menu. |
| 3   | Third-level menu     | After choosing a second-level menu, choose a third-level menu to access the query or setting page.                  |
| 4   | Details page         | Displays details of the queried information or parameter setting.   |
| 5   | System time          | Displays the current system time.   |

| No. | Function         | Description  |
|-----|------------------|--|
| 6   | Display language | Selects the display language or chooses to log out.  |
| 7   | Alarm icon       | Displays the severities and number of active system alarms. You can click a number to access the alarm page. |

# A.1.2 Icon Description

| Icon     | Description   | Icon     | Description  |
|----------|---|----------|--|
|          | Click the About icon to query the WebUI version information.  | >        | Click the Drop-down icon to choose a parameter or time.  |
|          | Click the Exit icon to log out.   | <u> </u> | Alarms are classified into major, minor, and warning ones. Click the Alarm icon to query an alarm. |
| •        | Click the Increase/<br>Decrease icon to<br>adjust time.   |          | Click the Start icon to start the device.  |
| <b>◎</b> | The Select icon indicates that a parameter is selected.   |          | Click the Stop icon to shut down the device.   |
|          | The Select icon indicates that a parameter is not selected. Click the icon to select a parameter.   |          | Click the Reset icon to reset the device.  |
| * *      | Hide icon and Display icon  | •        | The CMU is in <b>Running</b> state.  |
|          | <ul> <li>The device is in Disconnection state.</li> <li>When the device is in Disconnection state, its parameters cannot be set.</li> </ul> |          | The CMU is in <b>Loading</b> state.  |

| Icon | Description  | Icon | Description  |
|------|--|------|--|
|      | The CMU is in Initializing, Power-off, Idle or other state in which the device is not feeding power into the grid. | •    | Ascending order or descending order icon. Click the icon to sort parameters in ascending or descending order for the corresponding column. |

## A.1.3 WebUI Menus

Table A-1 WebUI menus

| Main Menu  | Second-Level Menu | Third-Level<br>Menu | Function   |
|------------|-------------------|---------------------|--|
| Overview   | ESS information   | -                   | Queries ESS information.   |
|            | Active Alarm      | -                   | Queries active alarms.   |
|            | Performance Data  | -                   | Queries or exports performance data.   |
| Monitoring | СМИ               | Running Info.       | Queries the running information.   |
|            |                   | Active Alarm        | Queries active alarms.   |
|            |                   | Running<br>Param.   | Set running parameters.  |
|            |                   | Module(M1)          | Queries the expansion module.  |
|            |                   | About               | Queries the version and communication information.                                       |
| Query      | Alarm History     | -                   | Query historical alarms.   |
|            | Operation Log     | -                   | Queries operation logs.  |
|            | Export Data       | -                   | Exports historical alarms, energy yield, operation logs, and power grid scheduling data. |
| Settings   | User parameters   | Date&Time           | Sets the date and time.  |
|            | Comm. Param.      | Wireless<br>Network | Sets parameters for the built-in WLAN.   |
|            |                   |                     | <ul> <li>Sets mobile data (4G/3G/2G)<br/>parameters.</li> </ul>                          |
|            |                   | Wired<br>Network    | Sets wired network parameters.   |

| Main Menu   | Second-Level Menu                | Third-Level<br>Menu | Function   |
|-------------|----------------------------------|---------------------|--|
|             |                                  | RS485               | Sets RS485 parameters.   |
|             |                                  | Modbus TCP          | Sets Modbus TCP parameters.  |
|             | Other parameters                 | -                   | -  |
| Maintenance | Software Upgrade                 | -                   | Upgrades the CMU software.   |
|             | Product Information              | -                   | Queries product information.   |
|             | Security Settings  System Maint. | -                   | <ul> <li>Changes the user password.</li> <li>Sets the automatic logout time.</li> <li>Upload a network security certificate.</li> <li>Updates the key.</li> <li>Sets web TLS1.0.</li> <li>Sets digital signature verification.</li> <li>Resets the system.</li> <li>Restore factory settings.</li> <li>Clears data.</li> <li>Exports all configuration files.</li> <li>Imports all configuration files.</li> </ul> |
|             | Device Log                       | -                   | Exports device logs.   |
|             | Device Mgmt.                     | Connect<br>Device   | <ul><li>Adds or removes a device.</li><li>Imports or exports configurations.</li></ul>   |
|             |                                  | SmartModule         | <ul><li>Removes the SmartModule.</li><li>Sets the authentication password.</li></ul>   |
|             |                                  | Clear Alarm         | Clears device alarms.  |

# **A.2 Maintenance Operations**

# A.2.1 Preparations and WebUI Login

### **Prerequisites**

- The operating system of Windows 7 or later is supported.
- Browser: Chrome 52, Firefox 58, or Internet Explorer 9, or a later version is recommended.

#### **Procedure**

- **Step 1** Connect the network cable between the network port of the PC and the WAN or LAN port of the CMU.
- **Step 2** Set the IP address for the PC on the same network segment as the CMU IP address.
  - When the CMU is connected to the SACU

| Connected<br>Port | Item            | CMU Default<br>Value | Example PC<br>Setting |
|-------------------|-----------------|----------------------|-----------------------|
| LAN port          | IP address      | 192.168.8.10         | 192.168.8.11          |
|                   | Subnet mask     | 255.255.255.0        | 255.255.255.0         |
|                   | Default gateway | 192.168.8.1          | 192.168.8.1           |
| WAN port          | IP address      | 192.168.0.10         | 192.168.0.11          |
|                   | Subnet mask     | 255.255.255.0        | 255.255.255.0         |
|                   | Default gateway | 192.168.0.1          | 192.168.0.1           |

When the CMU is not connected to the SACU

| SACU LAN Port IP<br>Address | CMU WAN Port IP<br>Address | CMU LAN Port IP<br>Address |
|-----------------------------|----------------------------|----------------------------|
| 192.168.8.10                | 192.168.8.XXX              | 192.168.3.10               |
| XXX.XXX.XXXX                | XXX.XXX.XXX.XXXa           | 192.168.8.10               |

Note a: When you set the IP address of the SACU LAN port, the IP address of the CMU WAN port changes with the IP address of the SACU LAN port. You can view the IP address on the SACU WebUI or SUN2000 app.

**Step 3** Set LAN parameters.

#### **NOTICE**

- If the CMU is connected to a local area network (LAN) and a proxy server has been set, you need to cancel the proxy server settings.
- If the CMU is connected to the Internet and the PC is connected to the LAN, do not cancel the proxy server settings.
- 1. Open Internet Explorer.
- 2. Choose **Tools** > **Internet Options**.
- 3. Click the **Connections** tab and then click **LAN settings**.
- 4. Clear Use a proxy server for your LAN.



Figure A-2 LAN settings

5. Click OK.


#### Step 4 Log in to the CMU WebUI.

 In the address box of a browser, enter https://XX.XX.XX.XX (XX.XX.XX is the IP address of the CMU) and press Enter. The login page is displayed. If you log in to the WebUI for the first time, a security risk warning is displayed. Click Continue to this website to log in to the WebUI.

#### 

- It is recommended that users use their own certificates. If the certificate is not replaced, the security risk warning will be displayed during each login.
- After logging in to the WebUI, you can import a certificate under Maintenance > Security Settings > Network Security Certificate.
- The imported security certificate needs to be bound to the CMU IP address. Otherwise, the security risk warning will still be displayed during login.

Figure A-3 Security risk warning



2. Specify Language, User Name, and Password, and click Log In.

Language English 
User Name admin 
Password Log In Reset

**Figure A-4** Login page (Initial login when the user name is displayed as admin)

#### **MOTE**

In this scenario, you need to update the software version to V800R021C10SPC020 or later.

| Parameter | Description  |
|-----------|--|
| Language  | Set this parameter as required.  |
| User Name | Default value: admin   |
| Password  | <ul> <li>The initial password is Changeme1234.</li> <li>Use the initial password upon first power-on and change it immediately after login. Then, use the new password to log in again.</li> </ul> |

#### **□** NOTE

Updating the CMU to V800R021C10SPC020 or later:

- Method 1: Log in as admin using your new password.
- Method 2: Log in as installer using your app login password (the initial password is 00000a).




Figure A-5 Login page (Initial login when the user name is null)

IL03J00002

#### **MOTE**

In this scenario, the software version is V800R021C10SPC020 or later.

| Parameter | Description                         |
|-----------|-------------------------------------|
| Language  | Set this parameter as required.     |
| User Name | Log in as installer.                |
| Password  | Set the login password as prompted. |

#### □ NOTE

- Protect the password by changing it periodically, and keep it secure. If you lose the
  password, the device must be restored to its factory settings. Huawei will not be
  held liable for any losses resulting from improper password management.
- You will be locked out for 10 minutes after five failed password attempts in five minutes.
- A dialog box with recent login information is displayed after login. Click **OK**.

#### ----End

#### Follow-up Procedure

If any page is blank or a menu cannot be accessed after you log in to the WebUI, clear the cache, refresh the page, or log in again.

# A.2.2 Upgrading the Software Version


#### **Prerequisites**

- Before upgrade, check whether an ESU alarm is generated. If yes, clear the alarm by referring to the alarm handling suggestions and then perform the upgrade.
- Before upgrade, ensure that the SOC of the battery rack is greater than 30%.
   Otherwise, the delayed upgrade function may be triggered (only software is loaded without performing the upgrade).

#### **Procedure**

**Step 1** Upgrade the software.

Figure A-6 Software upgrade



#### ----End

#### **MOTE**

- The Stop Upgrade function applies only to the devices waiting to be upgraded.
- If the system displays a message indicating that the loading is successful instead of the upgrade, the delayed upgrade function is triggered. The system automatically performs the upgrade when the conditions are met.
- If the upgrade fails, contact Huawei technical support.

## A.2.3 Exporting Device Logs

**Step 1** Access the device log page.

Figure A-7 Exporting logs



**Step 2** Select the device whose logs are to be exported and click **Export Log**.

□ NOTE

Logs can be exported for a maximum of six devices of the same type at a time.


- **Step 3** Observe the progress bar and wait until the log export is complete.
- **Step 4** After the export is successful, click **Log archiving** to save the logs.

----End

# A.2.4 Checking Alarms

**Step 1** Choose **Overview** > **Active Alarm**.

Figure A-8 Checking alarms



----End

## A.2.5 Clearing Alarms

You can clear all active and historical alarms for the selected device and re-collect alarm data.

#### **Procedure**

**Step 1** Choose **Maintenance** > **Device Mgmt.** > **Clear Alarm**.

Figure A-9 Clearing alarms



**Step 2** Select the name of the device whose alarms are to be cleared, click **Submit**, and choose **All**, **Locally synchronized alarms**, or **Alarms stored on devices** to clear alarms.

----End

If alarms are cleared for the CMU, you must reset alarms on the management system. Otherwise, the SmartLogger cannot obtain the alarm information collected by the CMU after the alarms are cleared.

# B APP Commissioning

# **B.1 Downloading and Installing the App**

SUN2000 app: Access Huawei AppGallery and search for **SUN2000**, or scan the following QR code (or directly visit https://appgallery.cloud.huawei.com/appdl/C10279542) to download and install the app.

QR code:



# **B.2 Logging In to the App**

#### **Prerequisites**

- The CMU has been powered on.
- The WLAN function has been enabled on your phone.
- Keep the phone within 5 m of the CMU. Otherwise, the communication quality might be poor.

#### **Procedure**

**Step 1** Press and hold the **RST** button for 1s to 3s to power on the CMU's built-in WLAN module.

#### ∩ NOTE

- If the ALM indicator blinks green fast for 2 minutes and other indicators are off, the WLAN module is powered on.
- If the WLAN module is not connected to the app, the WLAN module is automatically powered off after being powered on for 4 hours.
- **Step 2** In the SUN2000 app, select a connection mode.


#### □ NOTE

- The screenshots in this section correspond to the SUN2000 app 6.22.10.117 (Android).
- Use the initial password for the first login and change it immediately after login. To ensure account security, protect the password by changing it periodically, and keep it secure. Your password might be stolen or cracked if it is left unchanged for extended periods. If a password is lost, devices cannot be accessed. In these cases, the Company shall not be liable for any loss caused to the plant.
- 1. Tap **Manual connection** and select a product icon.

#### 

- The CMU has a built-in WLAN module. The initial name of the WLAN hotspot is **SN of the Monitor-CMU**, and the initial password is **Changeme**.
- If Changeme cannot be used for the first login, obtain the initial password from the QR code on the CMU.

Figure B-1 Manual connection



2. Tap **Connect** and scan the QR code on the CMU.

#### **MOTE**

Products delivered earlier do not support connection by scanning the QR code. In this case, manually connect the product.

**Step 3** Select the login user and enter the login password. The main menu screen is displayed.

#### **NOTICE**

- When you log in to the system for the first time, set the login password. To
  ensure account security, protect the password by changing it periodically, and
  keep it secure. Your password might be stolen or cracked if it is left unchanged
  for extended periods. If a password is lost, devices cannot be accessed. In these
  cases, the Company shall not be liable for any loss caused to the plant.
- For the same username, the password for logging in to the app is the same as that for logging in to the CMU WebUI.
- You will be locked out for 10 minutes after five consecutive failed password attempts in 5 minutes.




Figure B-2 Login

----End

# **B.3 Change Password**

#### Changing the WLAN Hotspot Password of a Device

Log in to the app, choose **Settings** > **Communication settings** > **Device WLAN**, and change the WLAN hotspot password of the device.

### Changing the Login Password of a User

After logging in to the app, tap in the upper right corner of the screen, and choose **Change password** to change the login password.

# Crimping an OT or DT Terminal

#### Requirements on an OT or DT Terminal

- If a copper cable is used, use copper wiring terminals.
- If a copper-clad aluminum cable is used, use copper wiring terminals.
- If an aluminum alloy cable is used, use copper-to-aluminum wiring terminals, or aluminum wiring terminals along with copper-to-aluminum washers.

#### **NOTICE**

- Do not connect aluminum wiring terminals to the terminal block. Otherwise electrochemical corrosion may occur, affecting the reliability of cable connections.
- Comply with the IEC 61238-1 requirements when using copper-to-aluminum wiring terminals, or aluminum wiring terminals along with copper-to-aluminum washers.
- Do not mix up the aluminum and copper sides of a copper-to-aluminum washer. Ensure that the aluminum side of the washer contacts the aluminum wiring terminal, and that the copper side contacts the terminal block.




Figure C-1 Requirements on an OT or DT terminal

#### Crimping an OT or DT Terminal

#### **NOTICE**

- Avoid scratching the core wire when stripping a cable.
- The cavity formed after the conductor crimp strip of the OT or DT terminal has been crimped must wrap around the core wire completely. The core wire must make close contact with the OT or DT terminal.
- Wrap the wire crimping area with heat shrink tubing or insulation tape. The heat shrink tubing is used as an example.
- Use a heat gun carefully to avoid heat damage to the equipment.

IS06Z00001


Figure C-2 Crimping an OT terminal

(1) Cable

- (2) Core wire
- (3) Heat shrink tubing

- (4) OT terminal
- (5) Hydraulic pliers
- (6) Heat gun

Figure C-3 Crimping a DT terminal



- (1) Cable
- (4) DT terminal
- (2) Core wire
- (5) Hydraulic pliers
- (3) Heat shrink tubing
- (6) Heat gun

# How Do I Repair Paint Damage?

#### **Prerequisites**

- Do not apply paint in bad weather, such as rain, snow, strong wind, and sandstorm, when there is no shelter outdoors.
- You have prepared the required paint that matches the color palette delivered with equipment.

#### **Paint Repair Description**

The equipment appearance should be intact. If paint has flaked off, repair paint damage immediately.

#### □ NOTE

Check the paint damage on the equipment and prepare appropriate tools and materials. The number of materials depends on site requirements.


Table D-1 Paint repair description

| Paint Damage   | Tool and<br>Material   | Procedure               | Description   |  |
|--|--|-------------------------|---|--|
| Slight scratch<br>(steel base<br>material not<br>exposed)  Smudges and rust<br>that cannot be<br>removed | Spray paint or paint, brush (required for repainting a small area), fine sandpaper, anhydrous alcohol, cotton cloth, and paint spray gun (required for repainting a large area)  | Steps 1, 2, 4, and 5    | <ol> <li>For the color of the finish coat (acrylic acid paint), see the delivered color palette and Pantone number specified on it.</li> <li>For a few scratches, smudges, or rust, manual</li> </ol> |  |
| Deep scratch<br>(primer damaged,<br>steel base<br>material exposed)                                      | Spray paint or paint, zinc-rich primer, brush (required for repainting a small area), fine sandpaper, anhydrous alcohol, cotton cloth, paint spray gun (required for repainting a large area)  | Steps 1, 2, 3, 4, and 5 | paint spraying or brushing is recommended.  3. For many scratches or large-area smudges and rusts, use a paint spray gun.  4. The paint coating should be thin and                                    |  |
| Logo and pattern<br>damage   | If a logo or pattern is damaged, provide the logo size and color number. Seek help from a local supplier of advertisement coatings to formulate a repair solution based on the logo size, color, and damage.   |                         | even. Paint drops are prohibited on the coating. The surface should be smooth.  |  |
| Dent   | <ol> <li>If a dent is less than or equal to 100 mm² in area and less than 3 mm in depth, fill the dent with Poly-Putty base and then perform the same operations as those for processing deep scratches.</li> <li>If a dent is greater than 100 mm² in area or greater than 3 mm in depth, ask the local supplier for an appropriate repainting solution.</li> </ol> |                         | 5. Leave the repainted area for approximately 30 minutes before performing any further operation.   |  |

#### Procedure

**Step 1** Gently polish damaged areas using fine sandpaper to remove smudges or rust.


Figure D-1 Polishing a damaged area using sandpaper



DM9700000

**Step 2** Dip a piece of cotton cloth into anhydrous alcohol and wipe the polished or damaged area to remove the dirt and dust. Then wipe off the anhydrous alcohol with a clean and dry cotton cloth

Figure D-2 Wiping a polished or damaged area using anhydrous alcohol



**Step 3** Paint zinc-rich primer on the damaged coat using a brush or paint spray gun.

#### NOTICE


- If the base material is exposed in the area to be repaired, apply epoxy zinc-rich primer, wait until the paint has dried, and then apply acrylic acid top coat.
- Select epoxy zinc-rich primer or acrylic acid top coat with a color the same as the surface coating color of the equipment.

**Step 4** Apply paint evenly to the damaged area based on the damage degree of the paint using an aerosol spray, brush, or paint spray gun until all damage traces are invisible.

#### **NOTICE**

- Ensure that the painting is thin, even, and smooth.
- In the case that an equipment pattern has different colors, to prevent undamaged areas and those with different colors as the damaged area from being contaminated during repainting, cover such areas using white paper and adhesive tape before repairing paint.

Figure D-3 Repainting a damaged area



**Step 5** Wait for 30 minutes and check whether the painting meets the requirements.

#### □ NOTE

- The color of the repainted area must be consistent with that of the surrounding area.
   Use a colorimeter to measure the color difference, which should be less than or equal to
   3 (ΔΕ ≤ 3). If a colorimeter is unavailable, ensure that there is no visible edge between
   the repainted area and the surrounding area. The paint should be free of bulges,
   scratches, flaking, or cracks.
- If you choose to spray paint, it is recommended that you spray paint three times before checking the result. If the color does not meet the requirements, paint more times until the painting meets the requirements.

----End

#### **Paint Supply Information**

**Table D-2** Paint requirements

| Item                        | Requirement           |  |
|-----------------------------|-----------------------|--|
| Primer thickness            | 60 μm                 |  |
| Intermediate coat thickness | 120 μm                |  |
| Top coat thickness          | 60 μm                 |  |
| Primer type                 | Epoxy zinc-rich paint |  |
| Intermediate coat type      | Zinc-rich paint       |  |

| Item                         | Requirement  |
|------------------------------|--|
| Color number of the top coat | Obtain the color number based on the color palette delivered with the product. |

#### 

The following is a paint model list provided by Huawei. The list may be updated from time to time and is for reference only. The cost of paint and technical services is subject to the local pricing standards.

| Supplier | Position                   | Paint Model   |
|----------|----------------------------|---|
| Hempel   | Equipment surface painting | Zinc-rich primer for pretreatment:<br>HEMPADUR ZINC (shopprimer) 1536C/<br>19830  |
|          |                            | Zinc-rich primer for the entire container:<br>HEMPADUR ZINC (on line) 1536C/19830 |
|          |                            | Intermediate coat: HEMPADUR FAST DRY 15560/12170                                  |
|          |                            | Top coat: HEMPATHANE 55210/17630<br>(RAL9003)                                     |
|          | Logo                       | Red: HEMPATHANE 55210/57200<br>(RAL3020)  |
|          |                            | Black: HEMPATHANE 55210-19990<br>(RAL9005)  |
| СМР      | Equipment surface painting | Zinc-rich primer for pretreatment: EPICON<br>ZINC SC B-2 M (SHOP PRIMER)          |
|          |                            | Zinc-rich primer for the entire container:<br>EPICON ZINC SC B-2 M (ON LINE ZINC) |
|          |                            | Intermediate coat: EPICON SC PRIMER<br>GREY CSC-9107                              |
|          |                            | Top coat: UNYMARINE SC FINISH WHITE CSC-9205 (RAL-9003)                           |
|          | Logo                       | Red: UNYMARINE SC MARKING RAL-3020  |
|          |                            | Black: UNYMARINE SC MARKING<br>RAL-9005   |

# Certificate Management and Maintenance

#### **Preconfigured Certificate Risk Disclaimer**

The Huawei-issued certificates preconfigured on Huawei devices during manufacturing are mandatory identity credentials for Huawei devices. The disclaimer statements for using the certificates are as follows:

- 1. Preconfigured Huawei-issued certificates are used only in the deployment phase, for establishing initial security channels between devices and the customer's network. Huawei does not promise or guarantee the security of preconfigured certificates.
- 2. The customer shall bear consequences of all security risks and security incidents arising from using preconfigured Huawei-issued certificates as service certificates.
- 3. A preconfigured Huawei-issued certificate is valid from the manufacturing date until October 2041.
- 4. Services using a preconfigured Huawei-issued certificate will be interrupted when the certificate expires.
- 5. It is recommended that customers deploy a PKI system to issue certificates for devices and software on the live network and manage the lifecycle of the certificates. To ensure security, certificates with short validity periods are recommended.

### **Application Scenarios of Preconfigured Certificates**

| File Path and Name              | Scenario   | Replacement             |
|---------------------------------|--|-------------------------|
| /mnt/log/smodule_ca.crt         | Authenticates the  | Certificate replacement |
| /mnt/log/<br>smodule_server.crt | validity of the peer extension module for communication with the TLS extension module. | is not supported.       |

| File Path and Name                                   | Scenario  | Replacement  |  |
|--|---|--|--|
| /mnt/log/cmu_ca.crt                                  | Authenticates the   | For details about how to replace a certificate, contact technical support engineers to obtain the corresponding security |  |
| /mnt/log/cmu_client.crt                              | validity of the peer SACU for communication with the SACU through Modbus-TCP. |  |  |
| /mnt/home/cert/web/<br>server.crt                    | Authenticates the validity of the peer web module to be connected.            | maintenance manual.  |  |
| /mnt/log/smodule_ca.crt                              | Authenticates the   | Certificate replacement is not supported.  |  |
| /mnt/log/<br>smodule_server.crt                      | validity of the peer BCU for communication with the BCU TLS.                  |  |  |
| /mnt/log/<br>tcpmb_server_cert/ca.crt                | Authenticates the validity of the peer  |  |  |
| /mnt/log/<br>tcpmb_server_cert/<br>tomcat_client.crt | mobile app for communication with the mobile app through Modbus-TCP.          |  |  |

# Contact Information

If you have any questions about this product, please contact us.



https://digitalpower.huawei.com

Path: About Us > Contact Us > Service Hotlines

To ensure faster and better services, we kindly request your assistance in providing the following information:

- Model
- Serial number (SN)
- Software version
- Alarm ID or name
- Brief description of the fault symptom

#### **◯** NOTE

EU Representative Information: Huawei Technologies Hungary Kft. Add.: HU-1133 Budapest, Váci út 116-118., 1. Building, 6. floor.

Email: hungary.reception@huawei.com

# **G** Acronyms and Abbreviations

В

**BCU** Battery Control Unit

**BMU** Battery Monitoring Unit

C

**CMU** Central Monitoring Unit

Ε

**ESS** Smart String Energy

Storage System

**ETH** Ethernet

**ESU** Energy Storage Unit

**ESC** Smart Rack Controller

**ESR** Battery Rack

**ESM** Battery Pack

L

**LCD** Liquid Crystal Display

Ρ

**PSU** Power Supply Unit

PCS Smart PCS

S

**SACU** Smart Array Controller

**SMU** Site monitoring unit

STS Smart Transformer

Station

Т

**TCU** Temperature Control Unit